


JVC

SERVICE MANUAL

DIGITAL VIDEO CAMERA

GR-D30EK, GR-D30Ex, GR-D30Ey GR-D30Ez, GR-D31EK



Mini DV PAL

For disassembling and assembling of MECHANISM ASSEMBLY, refer to the SERVICE MANUAL No.86700 (MECHANISM ASSEMBLY).

Regarding service information other than these sections, refer to the service manual No. 86730 (GR-D40EX).

Also, be sure to note important safety precautions provided in the service manual.

SPECIFICATION

Camcorder		Connectors	
General		S-Video	
Power supply	: DC 11.0 V $\equiv$ (Using AC Adapter) DC 7.2 V $\equiv$ (Using battery pack)	Output	: Y : 1 V (p-p), 75 Ω , analogue C : 0.29 V (p-p), 75 Ω , analogue
Power consumption		Input*	: Y : 0.8 V (p-p) -1.2 V (p-p), 75 Ω , analogue C : 0.2 V (p-p) -0.4 V (p-p), 75 Ω , analogue
LCD monitor off, viewfinder on	: Approx. 3.4 W	AV	
LCD monitor on, viewfinder off	: Approx. 4.7 W	Video output	: 1 V (p-p), 75 Ω , analogue
Dimensions (W x H x D)	: 69 mm x 94 mm x 143 mm (with the LCD monitor closed and the viewfinder pushed back in)	Video input*	: 0.8 V (p-p) -1.2 V (p-p), 75 Ω , analogue
Weight	: Approx. 525 g	Audio output	: 300 mV (rms), 1 k Ω , analogue, stereo
Operating temperature	: 0°C to 40°C	Audio input*	: 300 mV (rms), 50 k Ω , analogue, stereo
Operating humidity	: 35% to 80%	DV	
Storage temperature	: -20°C to 50°C	Output	: 4-pin, IEEE 1394 compliant
Pickup	: 1/6" CCD	Input*	: 4-pin, IEEE 1394 compliant
Lens	: F 1.6, f = 2.7 mm to 43.2 mm, 16:1 power zoom lens	USB**	: 5-pin
Filter diameter	: $\varnothing$ 37 mm	EDIT	: $\varnothing$ 3.5 mm, 2-pole
LCD monitor	: 2.5" diagonally measured, LCD panel/TFT active matrix system		
Viewfinder	: Electronic viewfinder with 0.24" black/white LCD		
Speaker	: Monaural		
Digital Video Camera			
Format	: DV format (SD mode)	AC Adapter	
Signal format	: PAL standard	Power requirement	: AC 110 V to 240 V $\sim$, 50 Hz/60 Hz
Recording/Playback format	: Video: Digital component recording Audio: PCM digital recording, 32 kHz 4-channel (12-bit), 48 kHz 2-channel (16-bit)	Output	: DC 11 V $\equiv$, 1 A
Cassette	: Mini DV cassette		
Tape speed	: SP : 18.8 mm/s LP : 12.5 mm/s		
Maximum recording time (using 80 min. cassette)	: SP : 80 min. LP : 120 min.		

Specifications shown are for SP mode unless otherwise indicated. E & O.E. Design and specifications subject to change without notice.

GR-D30EK, GR-D30EX, GR-D30EY, GR-D30EZ, GR-D31EK M3D123

DIFFERENCE LIST

DIFFERENT TABLE OF FEATURE

The following table indicate main different points between models GR-D40EX, GR-D30EK, GR-D30EX, GR-D30EY, GR-D30EZ and GR-D31EK.

ITEM	GR-D40EX	GR-D30EK	GR-D30EX	GR-D30EY	GR-D30EZ	GR-D31EK
DIGITAL INTERFACE	USB	NO	←	←	←	←
DV TERMINAL	OUT ONLY	IN/OUT	←	←	←	←
ANALOG INPUT	NO	YES	←	←	←	←
POWER CORD	CEE TYPE	BS TYPE	CEE TYPE	←	←	BS TYPE

DIFFERENT TABLE OF PARTS LIST

The following table indicate different parts number between models GR-D40EX, GR-D30EK, GR-D30EX, GR-D30EY, GR-D30EZ and GR-D31EK.

PACKING AND ACCESSORY ASSEMBLY <M1>

△	REF NO.	ITEM	GR-D40EX	GR-D30EK	GR-D30EX	GR-D30EY	GR-D30EZ	GR-D31EK
	1	PACKING CASE	LY33063-003A	LY33063-007A	←	←	←	LY33063-016A
	2	CUSHION	LY33065-001B	*LY33065-001C	*←	*←	*←	*←
	4	POLY BAG	QPA02003506	YQM30061-3	QPA02003506	←	←	YQM30061-3
△	5	INST BOOK(ENGLISH)	---	LYT1098-001A	---	---	---	LYT1134-001A
△	5	INST BOOK(GERMAN)	LYT1098-002A	---	LYT1098-002A	←	---	---
△	5	INST BOOK(FRENCH)	LYT1098-003A	---	*LYT1098-003B	---	---	---
△	5	INST BOOK(DUTCH)	LYT1098-004A	---	LYT1098-004A	---	---	---
△	5	INST BOOK(SPANISH)	LYT1098-005A	---	LYT1098-005A	---	---	---
△	5	INST BOOK(ITALIAN)	LYT1098-006A	---	LYT1098-006A	---	---	---
△	5	INST BOOK(DANISH)	---	---	---	LYT1098-007A	---	---
△	5	INST BOOK(FINNISH)	---	---	---	LYT1098-008A	---	---
△	5	INST BOOK(SWEDISH)	---	---	---	LYT1098-009A	---	---
△	5	INST BOOK(NORWEGIAN)	---	---	---	LYT1098-010A	---	---
△	5	INST BOOK(RUSSIAN)	---	---	---	---	LYT1098-011A	---
△	5	INST BOOK(CZECH)	---	---	---	---	LYT1098-012A	---
△	5	INST BOOK(POLISH)	---	---	---	---	LYT1098-013A	---
△	5	INST BOOK(HUNGARIAN)	---	---	---	---	LYT1098-014A	---
	6	INST BOOK(SOFT.ENGLISH)	---	---	---	---	---	LYT1135-001A
	6	INST BOOK(SOFT.GERMAN)	LYT1086-002A	---	---	---	---	---
	6	INST BOOK(SOFT.FRENCH)	LYT1086-003A	---	---	---	---	---
	6	INST BOOK(SOFT.DUTCH)	LYT1086-004A	---	---	---	---	---
	6	INST BOOK(SOFT.SPANISH)	LYT1086-005A	---	---	---	---	---
	6	INST BOOK(SOFT.ITALIAN)	LYT1086-006A	---	---	---	---	---
	7	WARRANTY CARD	BT-54013-5	BT-54008-4	BT-54013-5	←	←	BT-54008-4
	8	RESIST.CARD	---	---	---	---	---	YU30878
	9	Q.CARD(JUK)	---	LYT0194-001B	---	---	---	LYT0194-001B
	23	USB CABLE	QAM0451-001	---	---	---	---	---
	24	FERRITE CORE	QQR0491-002	---	---	---	---	---
△	29	POWER CORD	QMPL120-190-JR	QMPP110-190-JR	QMPL120-190-JR	←	←	QMPP110-190-JR
	37	CD ROM ASSY	LY32210-048A	---	---	---	---	LY32210-059A

Note:

Mark ← is same as left.


Mark --- is not used.

Mark * reference model was also changed.

FINAL ASSEMBLY <M2>

△	REF NO.	ITEM	GR-D40EX	GR-D30EK	GR-D30EX	GR-D30EY	GR-D30EZ	GR-D31EK
	101	U.CASE(2.5)ASSY	LY20941-003D	LY20941-007E	←	←	←	←
	101F	SPACER(A)	---	*LY30030-0F2A	*←	*←	*←	*←
	123	STICKER(2)	LY44187-004A	LY44187-005A	←	←	←	←
	126	SPACER(A)	LY30030-0E3A	*LY30030-0E3B	*←	*←	*←	*←
	127	SPACER(A)	---	*LY30030-0E5A	*←	*←	*←	*←
	136	MIC	LY20944-001A	*LY20944-001B	*←	*←	*←	*←
△	145	REAR UNIT	LY20938-001D	*LY20938-001E	*←	*←	*←	*←
	251	OP BLOCK ASSY	LY33085-001B	*LY33085-001E	*←	*←	*←	*←
	256	SPECIAL SCREWX2	LY30018-011A	*LY30018-0E7A	*←	*←	*←	*←
	259	SPACER(A)	---	*LY30029-0Q7A	*←	*←	*←	*←

As for the difference in a "FINAL ASSEMBLY <M2>" drawing, 259 is added.



MAIN BOARD ASSEMBLY <01>

△	REF NO.	ITEM	GR-D40EX	GR-D30EK	GR-D30EX	GR-D30EY	GR-D30EZ	GR-D31EK
	PW1	MAIN BOARD ASSY	YB10404K-02	YB10404G-02	←	←	←	←

Note:

Mark ← is same as left.

Mark --- is not used.

Mark * reference model was also changed.



VICTOR COMPANY OF JAPAN, LIMITED

AV & MULTIMEDIA COMPANY CAMCORDER CATEGORY 12, 3-chome, Moriya-cho, kanagawa-ku, Yokohama, kanagawa-prefecture, 221-8528, Japan

(No.86737)



Printed in Japan
200304WPC

MODEL	MARK	MODEL	MARK
GR-D30EK	A	GR-D30EZ	D
GR-D30EX	B	GR-D31EK	E
GR-D30EY	C		

PARTS LIST

2. PARTS LIST

MAIN BOARD ASSEMBLY <01>

Symbol No.	Part No.	Part Name	Description	Local	Symbol No.	Part No.	Part Name	Description	Local
PW1	YB10404G-02	MAIN BOARD ASSY			Q3701	UMT1N-W	PAIR TRANSISTOR		
IC1001	MN103S33NJC	IC(MICRO C ROM)			Q3701 or	XP4401-W	TRANSISTOR		
IC1001 or	MN103SF33NY4JC	IC(MICRO C ROM)			Q3701 or	BC856S-X	PAIR TRANSISTOR		
IC1002	MB90097PFV149-X	IC(MICRO C ROM)			Q3702	UMZ1N-W	PAIR TRANSISTOR		
IC1003	SN74AHC1G00K-X	IC			Q3702 or	XP4601-W	TRANSISTOR		
IC1003 or	SN74AHC1G00DC-X	IC			Q3704	2SA1774/RS/-X	TRANSISTOR		
IC1004	S-89220ACNC-W	IC			Q3704 or	BC857BT-X	TRANSISTOR		
IC1005	X25330S8I-2.5-X	IC			Q3705	UMT1N-W	PAIR TRANSISTOR		
IC1005 or	AT25320N-10SI-X	IC			Q3705 or	XP4401-W	TRANSISTOR		
IC1005 or	M95320-WMN6-X	IC			Q3705 or	BC856S-X	PAIR TRANSISTOR		
IC1005 or	25LC320-I/SN-X	IC			Q3731	2SC4617/RS/-X	TRANSISTOR		
IC1005 or	CAT25C32SI-X	IC			Q3731 or	2SD2216J/RS/-X	TRANSISTOR		
IC1006	RS5C314-X	IC			Q3731 or	BC847BT-X	TRANSISTOR		
IC1007	IC-PST3423U-X	IC			Q3732	DTC144EE-X	DIGI TRANSISTOR		
IC1007 or	S-80823CNNB-X	IC			Q3732 or	UN9213J-X	DIGI TRANSISTOR		
IC2201	AK4564VQ	IC			Q3732 or	BCR148T-X	DIGI TRANSISTOR		
IC3001	JCY0152	IC			Q3733	UMZ1N-W	PAIR TRANSISTOR		
IC3002	BU2501FV-X	IC			Q3733 or	XP4601-W	TRANSISTOR		
IC3005	JCY0136-X	IC			Q3734	2SC4617/RS/-X	TRANSISTOR		
IC3701	BA7665FS-X	IC			Q3734 or	2SD2216J/RS/-X	TRANSISTOR		
IC3731	MM1504XN-X	IC			Q3734 or	BC847BT-X	TRANSISTOR		
IC3801	JCP8045	IC			Q3735	UMZ1N-W	PAIR TRANSISTOR		
IC4201	HD49340NP-X	IC			Q3735 or	XP4601-W	TRANSISTOR		
IC4202	MM1613AN-X	IC			Q4801	2SC4655/BC/-X	TRANSISTOR		
IC4301	JCY0200	IC			Q4806	2SC4617/QR/-X	TRANSISTOR		
IC4302	R1160N151B-X	IC			Q4806 or	BC847BT-X	TRANSISTOR		
IC4802	BA10358FVM-W	IC			Q4851	2SC4617/RS/-X	TRANSISTOR		
IC4803	BA10358FVM-W	IC			Q4851 or	BC847BT-X	TRANSISTOR		
IC4804	UPC358G2/5/-W	IC			Q6101	SSM5G01TU-X	MOS FET		
IC4851	UPD16879GS-X	IC			Q6102	2SA1577/QR/-X	TRANSISTOR		
IC5501	JCY0185	IC			Q6102 or	BC807-25W-X	TRANSISTOR		
IC6001	FA3698F	IC			Q6201	SSM5G01TU-X	MOS FET		
IC6801	R1224N102G-X	IC			Q6301	SSM5G01TU-X	MOS FET		
Q1001	DTA114EE-X	DIGI TRANSISTOR			Q6302	2SA1577/QR/-X	TRANSISTOR		
Q1001 or	PDTA114EE-X	DIGI TRANSISTOR			Q6302 or	BC807-25W-X	TRANSISTOR		
Q1001 or	RN2102-X	DIGI TRANSISTOR			Q6303	2SC4617/QR/-X	TRANSISTOR		
Q1001 or	BCR183T-X	DIGI TRANSISTOR			Q6303 or	BC847BT-X	TRANSISTOR		
Q1002	UMC3N-W	DIGI TRANSISTOR			Q6401	SSM5G01TU-X	MOS FET		
Q1003	UMC3N-W	DIGI TRANSISTOR			Q6501	SSM5G01TU-X	MOS FET		
Q1004	UMC3N-W	DIGI TRANSISTOR			Q6601	CPH3314-X	MOS FET		
Q1005	DTC143XE-X	DIGI TRANSISTOR			Q6602	UMX1N-W	PAIR TRANSISTOR		
Q1006	UMC3N-W	DIGI TRANSISTOR			Q6602 or	HN1C01FU/G/-X	PAIR TRANSISTOR		
Q1007	2SC4617/QR/-X	TRANSISTOR			Q6602 or	BC847S-X	PAIR TRANSISTOR		
Q1007 or	BC847BT-X	TRANSISTOR			Q6603	2SA1577/QR/-X	TRANSISTOR		
Q1008	DTC124EE-X	DIGI TRANSISTOR			Q6603 or	BC807-25W-X	TRANSISTOR		
Q1008 or	PDTC124EE-X	DIGI TRANSISTOR			Q6604	DTC144EE-X	DIGI TRANSISTOR		
Q1008 or	BCR141T-X	DIGI TRANSISTOR			Q6604 or	BCR148T-X	DIGI TRANSISTOR		
Q1009	2SJ347-X	MOS FET			Q6605	UMT1N-W	PAIR TRANSISTOR		
Q2001	UMX1N-W	PAIR TRANSISTOR			Q6605 or	HN1A01FU/G/-X	PAIR TRANSISTOR		
Q2001 or	BC847S-X	PAIR TRANSISTOR			Q6605 or	BC856S-X	PAIR TRANSISTOR		
Q2002	UMX1N-W	PAIR TRANSISTOR			Q6606	2SC4617/QR/-X	TRANSISTOR		
Q2002 or	BC847S-X	PAIR TRANSISTOR			Q6606 or	BC847BT-X	TRANSISTOR		
Q2003	UMX1N-W	PAIR TRANSISTOR			Q6701	CPH3314-X	MOS FET		
Q2003 or	BC847S-X	PAIR TRANSISTOR			Q6801	FML9-W	TRANSISTOR		
Q2004	UMX1N-W	PAIR TRANSISTOR			D1001	DA221-X	DIODE ARRAY		
Q2004 or	BC847S-X	PAIR TRANSISTOR			D3001	EC2C01C-X	VARI CAP DIODE		
Q2005	UMX1N-W	PAIR TRANSISTOR			D3002	EC2C01C-X	VARI CAP DIODE		
Q2005 or	BC847S-X	PAIR TRANSISTOR			D3003	EC2C01C-X	VARI CAP DIODE		
Q2006	UMX1N-W	PAIR TRANSISTOR			D3004	MA2Z720-X	SB DIODE		
Q2006 or	BC847S-X	PAIR TRANSISTOR			D5501	1SS355-X	SI DIODE		
Q2202	UMX1N-W	PAIR TRANSISTOR			D6601	RB481K-X	SB DIODE		
Q2202 or	BC847S-X	PAIR TRANSISTOR			D6602	RB480Y-W	SB DIODE		
Q2401	2SC4617/QR/-X	TRANSISTOR			D6701	RB160M-30-X	SB DIODE		
Q2401 or	BC847BT-X	TRANSISTOR			D6702	RB160M-30-X	SB DIODE		
Q2403	2SC4617/QR/-X	TRANSISTOR			Δ D6801	RB715F-X	SB DIODE		
Q2403 or	BC847BT-X	TRANSISTOR			C1001	NDCA1HJ-8R0W	C CAPACITOR	8pF 50V J	
Q3001	2SC4617/RS/-X	TRANSISTOR			C1002	NDCA1HJ-100W	C CAPACITOR	10pF 50V J	
Q3001 or	BC847BT-X	TRANSISTOR			C1004	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
Q3002	2SC4617/RS/-X	TRANSISTOR			C1005	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
Q3002 or	BC847BT-X	TRANSISTOR			C1007	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
					C1008	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
					C1009	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	

MODEL	MARK	MODEL	MARK
GR-D30EK	A	GR-D30EZ	D
GR-D30EX	B	GR-D31EK	E
GR-D30EY	C		

△ Symbol No.	Part No.	Part Name	Description	Local	△ Symbol No.	Part No.	Part Name	Description	Local
C1010	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C3011	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1011	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C3012	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1012	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C3013	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1013	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C3015	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1014	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C3016	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1015	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C3017	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1019	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z		C3020	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1020	NCBA1EK-682W	C CAPACITOR	6800pF 25V K		C3021	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1021	NCBA1EK-682W	C CAPACITOR	6800pF 25V K		C3022	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1022	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z		C3023	NDCA1HJ-330W	C CAPACITOR	33pF 50V J	
C1024	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z		C3024	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C1025	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z		C3025	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1029	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z		C3026	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C1030	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C3027	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C1032	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z		C3028	NDCA1EJ-271W	C CAPACITOR	270pF 25V J	
C1035	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z		C3029	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1036	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C3030	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1037	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z		C3031	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1038	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z		C3032	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C1039	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z		C3033	NDCA1HJ-220W	C CAPACITOR	22pF 50V J	
C1040	NDCA1HJ-100W	C CAPACITOR	10pF 50V J		C3036	NDCA1HJ-8R0W	C CAPACITOR	8pF 50V J	
C1041	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C3037	NDCA1HJ-8R0W	C CAPACITOR	8pF 50V J	
C1042	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C3038	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1043	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C3039	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1044	NDCA1HJ-470W	C CAPACITOR	47pF 50V J		C3042	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1045	NDCA1HJ-470W	C CAPACITOR	47pF 50V J		C3043	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1046	NCF31AZ-105X	C CAPACITOR	1uF 10V Z		C3044	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1047	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z		C3045	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1048	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z		C3046	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1049	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z		C3047	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C1050	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z		C3048	NCB31CK-473X	C CAPACITOR	0.047uF 16V K	
C1051	NCB31CK-223X	C CAPACITOR	0.022uF 16V K		C3049	NCBA1HK-222W	C CAPACITOR	2200pF 50V K	
C1052	NCB31CK-223X	C CAPACITOR	0.022uF 16V K		C3050	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1053	NCB31CK-223X	C CAPACITOR	0.022uF 16V K		C3055	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1054	NCB31CK-223X	C CAPACITOR	0.022uF 16V K		C3059	NBE20GM-226X	TA E CAPACITOR	22uF 4V M	
C1055	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C3060	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C1064	NBE20JM-226X	TA E CAPACITOR	22uF 6.3V M		C3064	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C2201	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C3066	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2202	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C3067	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C2203	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C3069	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2204	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C3701	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2205	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C3702	NDCA1HJ-560W	C CAPACITOR	56pF 50V J	
C2209	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C3703	NDCA1HJ-270W	C CAPACITOR	27pF 50V J	
C2210	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C3704	NDCA1HJ-680W	C CAPACITOR	68pF 50V J	
C2211	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C3705	NDCA1HJ-270W	C CAPACITOR	27pF 50V J	
C2212	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C3706	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2213	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C3707	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C2214	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C3708	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2215	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C3709	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C2216	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C3712	NEA70GM-337X	E CAPACITOR	330uF 4V M	
C2217	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C3713	NEA70GM-337X	E CAPACITOR	330uF 4V M	
C2218	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C3715	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C2223	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C3731	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C2224	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C3732	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C2401	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C3733	NDCA1HJ-3R0W	C CAPACITOR	3pF 50V J	
C2402	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C3734	NDCA1HJ-5R0W	C CAPACITOR	5pF 50V J	
C2403	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C3735	NDCA1HJ-330W	C CAPACITOR	33pF 50V J	
C2404	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C3736	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C2405	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C3738	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C2406	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C3739	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C2603	NCBA1CK-153W	C CAPACITOR	0.015uF 16V K		C3740	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2604	NCBA1CK-153W	C CAPACITOR	0.015uF 16V K		C3741	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2605	NCBA1EK-472W	C CAPACITOR	4700pF 25V K		C3742	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2606	NCBA1EK-472W	C CAPACITOR	4700pF 25V K		C3743	NDCA1HJ-3R0W	C CAPACITOR	3pF 50V J	
C2607	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		C3744	NDCA1HJ-5R0W	C CAPACITOR	5pF 50V J	
C2608	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		C3745	NDCA1HJ-330W	C CAPACITOR	33pF 50V J	
C2611	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C3746	NCB20JM-475X	C CAPACITOR	4.7uF 6.3V M	
C2612	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C3747	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C2613	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C3801	NCB21AK-105X	C CAPACITOR	1uF 10V K	
C2614	NDCA1HJ-101W	C CAPACITOR	100pF 50V J		C3802	NCB21AK-105X	C CAPACITOR	1uF 10V K	
C2615	NDCA1HJ-101W	C CAPACITOR	100pF 50V J		C3803	NBE20GM-476X	TA E CAPACITOR	47uF 4V M	
C3001	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C3804	NBE20GM-476X	TA E CAPACITOR	47uF 4V M	
C3003	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C3805	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3005	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C3806	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3006	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C3807	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3007	NCB10JK-106X	C CAPACITOR	10uF 6.3V K		C3808	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3008	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C3809	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C3009	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C3810	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	

MODEL	MARK	MODEL	MARK
GR-D30EK	A	GR-D30EZ	D
GR-D30EX	B	GR-D31EK	E
GR-D30EY	C		

△ Symbol No.	Part No.	Part Name	Description	Local	△ Symbol No.	Part No.	Part Name	Description	Local
C3811	NCB31CK-104X	C CAPACITOR	0.1uF 16V K		C5516	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3812	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C5517	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C3813	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C5518	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3814	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5519	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3815	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6002	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C3816	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6003	NEA71CM-106X	E CAPACITOR	10uF 16V M	
C3817	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6004	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C3818	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6021	NCB21CK-104X	C CAPACITOR	0.1uF 16V K	
C3819	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C6022	NCB21CK-104X	C CAPACITOR	0.1uF 16V K	
C4201	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C6023	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4202	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6024	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4203	NCB21AK-105X	C CAPACITOR	1uF 10V K		C6025	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4204	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6026	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4205	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6027	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C4206	NCB21CK-105X	C CAPACITOR	1uF 16V K		C6029	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4207	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6030	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4208	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C6031	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4209	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6032	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4210	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6033	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C4211	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6034	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4212	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6035	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4213	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6036	NDCA1HJ-101W	C CAPACITOR	100pF 50V J	
C4214	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6037	NCB21CK-473X	C CAPACITOR	0.047uF 16V K	
C4216	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6038	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C4301	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6039	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4302	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6040	NCB31CK-473X	C CAPACITOR	0.047uF 16V K	
C4303	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6041	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C4304	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6042	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C4305	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6043	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C4306	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6044	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C4307	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6045	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4308	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6101	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4309	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6103	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C4310	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6104	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4311	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6105	NCBA1HK-561W	C CAPACITOR	560pF 50V K	
C4312	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6106	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4313	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C6201	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4314	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6203	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C4315	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6204	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C4316	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C6301	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4317	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6303	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C4803	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C6304	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4804	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C6401	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4806	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C6403	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4808	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C6405	NCB31CK-683X	C CAPACITOR	0.068uF 16V K	
C4809	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C6501	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4810	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C6503	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4811	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C6505	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4812	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C6601	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4813	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C6602	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4814	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C6603	NCB11EK-105X	C CAPACITOR	1uF 25V K	
C4815	NCB31HK-152X	C CAPACITOR	1500pF 50V K		C6605	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4819	NCB31CK-104X	C CAPACITOR	0.1uF 16V K		C6606	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4851	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C6607	NCB11EK-105X	C CAPACITOR	1uF 25V K	
C4852	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z		C6608	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4853	NBE21AM-335X	TA E CAPACITOR	3.3uF 10V M		C6609	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4854	NBE21AM-106X	TA E CAPACITOR	10uF 10V M		C6701	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4855	NCB31CK-104X	C CAPACITOR	0.1uF 16V K		C6703	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4858	NDCA1HJ-330W	C CAPACITOR	33pF 50V J		C6801	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4859	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K		C6802	NBE40JM-476X	TA E CAPACITOR	47uF 6.3V M	
C4860	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K		C6804	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4861	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C6807	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C4862	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C6809	NDCA1HJ-151W	C CAPACITOR	150pF 50V J	
C4864	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M						
C4865	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		R1001	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
C5501	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		R1002	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
C5503	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		R1003	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
C5504	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		R1006	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
C5506	NBE40GM-476X	TA E CAPACITOR	47uF 4V M		R1007	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
C5507	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		R1008	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
C5508	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		R1009	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
C5509	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		R1010	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
C5510	NBP21VM-105X	TA E CAPACITOR	1uF 35V M		R1011	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
C5511	NBZ0003-475X	TA E CAPACITOR	4.7uF 20V M		R1012	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
C5512	NBE21AM-106X	TA E CAPACITOR	10uF 10V M		R1013	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
C5513	NCB31CK-104X	C CAPACITOR	0.1uF 16V K		R1014	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
C5514	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		R1015	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
C5515	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		R1016	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	

MODEL	MARK	MODEL	MARK
GR-D30EK	A	GR-D30EZ	D
GR-D30EX	B	GR-D31EK	E
GR-D30EY	C		

△ Symbol No.	Part No.	Part Name	Description	Local	△ Symbol No.	Part No.	Part Name	Description	Local
R1017	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J		R2002	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1018	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J		R2003	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1019	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R2004	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1020	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R2005	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1021	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R2006	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1022	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R2007	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1023	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R2008	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1024	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R2009	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1025	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R2010	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1027	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R2011	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1030	NRSA6AJ-753W	MG RESISTOR	75kΩ 1/16W J		R2012	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1031	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J		R2201	NRSA6AJ-684W	MG RESISTOR	680kΩ 1/16W J	
R1032	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R2202	NRSA6AJ-564W	MG RESISTOR	560kΩ 1/16W J	
R1033	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R2203	NRSA6AJ-393W	MG RESISTOR	39kΩ 1/16W J	
R1034	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R2204	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J	
R1035	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R2206	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R1037	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J		R2207	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R1038	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R2208	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J	
R1039	NRSA6AJ-152W	MG RESISTOR	1.5kΩ 1/16W J		R2209	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J	
R1040	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R2210	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1041	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R2211	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1042	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R2212	NRSA6AJ-2R7W	MG RESISTOR	2.7Ω 1/16W J	
R1043	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R2213	NRSA6AJ-2R7W	MG RESISTOR	2.7Ω 1/16W J	
R1044	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R2217	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R1045	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J		R2218	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R1046	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R2219	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1047	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R2220	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1048	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R2221	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1049	NRSA6AJ-623W	MG RESISTOR	62kΩ 1/16W J		R2222	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R1050	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J		R2223	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R1051	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J		R2224	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R1052	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R2225	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1053	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R2226	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1054	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R2229	NRSA6AJ-564W	MG RESISTOR	560kΩ 1/16W J	
R1055	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J		R2230	NRSA6AJ-564W	MG RESISTOR	560kΩ 1/16W J	
R1056	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J		R2231	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1057	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R2401	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R1058	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R2402	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R1059	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R2403	NRSA6AJ-183W	MG RESISTOR	18kΩ 1/16W J	
R1060	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R2406	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1061	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J		R2407	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R1062	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J		R2601	NRSA6AJ-182W	MG RESISTOR	1.8kΩ 1/16W J	
R1063	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R2602	NRSA6AJ-182W	MG RESISTOR	1.8kΩ 1/16W J	
R1064	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R2607	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R1065	NRSA6AJ-153W	MG RESISTOR	15kΩ 1/16W J		R2608	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R1066	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R2609	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J	
R1067	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J		R2610	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J	
R1068	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R3002	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1069	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R3004	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1070	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J		R3005	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R1071	NRSA6AJ-272W	MG RESISTOR	2.7kΩ 1/16W J		R3006	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J	
R1072	NRSA6AJ-183W	MG RESISTOR	18kΩ 1/16W J		R3007	NRSA6AJ-562W	MG RESISTOR	5.6kΩ 1/16W J	
R1073	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R3008	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R1074	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R3009	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1075	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J		R3010	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1076	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J		R3011	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	
R1077	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R3013	NRSA6AJ-242W	MG RESISTOR	2.4kΩ 1/16W J	
R1078	NRSA6AJ-393W	MG RESISTOR	39kΩ 1/16W J		R3014	NRSA6AJ-392W	MG RESISTOR	3.9kΩ 1/16W J	
R1079	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J		R3015	NRSA6AJ-392W	MG RESISTOR	3.9kΩ 1/16W J	
R1080	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J		R3016	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D	
R1081	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R3017	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D	
R1082	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J		R3018	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D	
R1083	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R3019	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D	
R1084	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R3020	NRVA6AD-512W	CMF RESISTOR	5.1kΩ 1/16W D	
R1085	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R3021	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1086	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R3025	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1087	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R3027	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1088	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R3029	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J	
R1089	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R3030	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	
R1091	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R3031	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	
R1092	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R3032	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R1093	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R3034	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R1094	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R3036	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1095	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R3037	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J	
R1096	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R3057	NRSA6AJ-151W	MG RESISTOR	150Ω 1/16W J	
R1097	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R3066	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J	
R1099	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R3067	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J	
R2001	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J		R3068	NRSA6AJ-181W	MG RESISTOR	180Ω 1/16W J	

MODEL	MARK	MODEL	MARK
GR-D30EK	A	GR-D30EZ	D
GR-D30EX	B	GR-D31EK	E
GR-D30EY	C		

△ Symbol No.	Part No.	Part Name	Description	Local	△ Symbol No.	Part No.	Part Name	Description	Local
R3069	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R4337	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3071	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4338	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R3074	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4339	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3082	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4341	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3701	NRSA6AD-271W	MG RESISTOR	270Ω 1/16W D		R4342	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3702	NRSA6AD-271W	MG RESISTOR	270Ω 1/16W D		R4343	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3703	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R4344	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3704	NRSA6AD-301W	MG RESISTOR	300Ω 1/16W D		R4345	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R3705	NRSA6AD-301W	MG RESISTOR	300Ω 1/16W D		R4346	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R3706	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R4348	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3707	NRSA6AD-680W	MG RESISTOR	68Ω 1/16W D		R4349	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3708	NRSA6AD-680W	MG RESISTOR	68Ω 1/16W D		R4350	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3709	NRSA6AD-680W	MG RESISTOR	68Ω 1/16W D		R4351	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3710	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R4352	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3711	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R4353	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3712	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J		R4354	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3713	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R4355	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3714	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J		R4356	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3715	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4804	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R3722	NRSA6AD-131W	MG RESISTOR	130Ω 1/16W D		R4805	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R3724	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R4806	NRSA6AJ-683W	MG RESISTOR	68kΩ 1/16W J	
R3725	NRSA6AD-131W	MG RESISTOR	130Ω 1/16W D		R4807	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
R3726	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R4808	NRSA6AJ-243W	MG RESISTOR	24kΩ 1/16W J	
R3727	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R4809	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J	
R3728	NRSA6AD-131W	MG RESISTOR	130Ω 1/16W D		R4810	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R3730	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R4811	NRSA6AJ-824W	MG RESISTOR	820kΩ 1/16W J	
R3731	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R4812	NRSA6AJ-153W	MG RESISTOR	15kΩ 1/16W J	
R3732	NRSA6AJ-101W	MG RESISTOR	100Ω 1/16W J		R4814	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R3733	NRSA6AD-561W	MG RESISTOR	560Ω 1/16W D		R4815	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R3734	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J		R4816	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R3735	NRSA6AD-182W	MG RESISTOR	1.8kΩ 1/16W D		R4817	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
R3736	NRSA6AJ-183W	MG RESISTOR	18kΩ 1/16W J		R4818	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J	
R3737	NRSA6AJ-183W	MG RESISTOR	18kΩ 1/16W J		R4819	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R3738	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J		R4820	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R3739	NRSA6AJ-821W	MG RESISTOR	820Ω 1/16W J		R4821	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R3740	NRSA6AJ-821W	MG RESISTOR	820Ω 1/16W J		R4822	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R3741	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R4823	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R3742	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R4824	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R3743	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R4827	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3744	NRSA6AD-561W	MG RESISTOR	560Ω 1/16W D		R4828	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3745	NRSA6AD-152W	MG RESISTOR	1.5kΩ 1/16W D		R4833	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R3746	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R4836	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R3747	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R4841	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3748	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J		R4842	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3801	NRSA6AJ-101W	MG RESISTOR	100Ω 1/16W J		R4843	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3802	NRSA6AD-821W	MG RESISTOR	820Ω 1/16W D		R4844	NRSA6AJ-151W	MG RESISTOR	150Ω 1/16W J	
R3803	NRSA6AD-273W	MG RESISTOR	27kΩ 1/16W D		R4854	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3804	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D		R4856	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R3805	NRSA6AD-821W	MG RESISTOR	820Ω 1/16W D		R4857	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R3807	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J		R4858	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R4201	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J		R4859	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4202	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4860	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4203	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4862	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R4204	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J		R4863	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R4205	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J		R4864	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4301	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J		R4865	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4303	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4866	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4304	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4867	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4306	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4868	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4307	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J		R4870	NRSA6AJ-271W	MG RESISTOR	270Ω 1/16W J	
R4308	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J		R4871	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4309	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4874	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4310	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4875	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4315	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R5501	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4317	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R5503	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R4319	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R5504	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R4321	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R5505	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R4326	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J		R5506	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4327	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R5507	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4328	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R5509	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R4329	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R5511	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R4330	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R5512	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4331	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R5513	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4332	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R5514	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4333	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R6021	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4334	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R6022	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4335	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R6023	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4336	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R6024	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	

MODEL	MARK	MODEL	MARK
GR-D30EK	A	GR-D30EZ	D
GR-D30EX	B	GR-D31EK	E
GR-D30EY	C		


△ Symbol No.	Part No.	Part Name	Description	Local	△ Symbol No.	Part No.	Part Name	Description	Local
R6025	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		RA1007	NRZ0034-102W	NET RESISTOR	1kΩ 1/32W J	
R6026	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		RA1008	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J	
R6027	NRSA6AD-103W	MG RESISTOR	10kΩ 1/16W D		RA3001	NRZ0034-560W	NET RESISTOR	56Ω 1/32W J	
R6028	NRSA6AD-751W	MG RESISTOR	750Ω 1/16W D		RA3002	NRZ0034-560W	NET RESISTOR	56Ω 1/32W J	
R6029	NRSA6AD-103W	MG RESISTOR	10kΩ 1/16W D		RA3003	NRZ0034-100W	NET RESISTOR	10Ω 1/32W J	
R6030	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J		RA3004	NRZ0034-103W	NET RESISTOR	10kΩ 1/32W J	
R6031	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		RA3005	NRZ0040-0R0X	NET RESISTOR	0Ω 1/16W J	
R6033	NRSA6AJ-562W	MG RESISTOR	5.6kΩ 1/16W J		L1001	NQL402M-100X	COIL	10uH M	
R6034	NRSA6AJ-153W	MG RESISTOR	15kΩ 1/16W J		L1002	NQL402M-100X	COIL	10uH M	
R6035	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		L2401	NQL402M-100X	COIL	10uH M	
R6036	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		L2402	NQL402M-100X	COIL	10uH M	
R6037	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D		L2604	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R6038	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		L3001	NQR0129-002X	FERRITE BEADS		
R6039	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		L3002	NQR0129-002X	FERRITE BEADS		
R6040	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		L3004	NQR0006-001X	FERRITE BEADS		
R6042	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J		L3005	NQR0006-001X	FERRITE BEADS		
R6044	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J		L3007	NQL085J-2R2X	COIL	2.2uH J	
R6102	NRVA6AD-223W	CMF RESISTOR	22kΩ 1/16W D		L3008	NQL085J-120X	COIL	12uH J	
R6103	NRVA6AD-103W	CMF RESISTOR	10kΩ 1/16W D		L3012	NQR0129-002X	FERRITE BEADS		
R6104	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J		L3014	NQL38DK-100X	P COIL	10uH K	
R6105	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		L3015	NQR0006-001X	FERRITE BEADS		
R6106	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		L3701	NQL38DK-100X	P COIL	10uH K	
R6107	NRSA6AD-183W	MG RESISTOR	18kΩ 1/16W D		L3731	NQL085J-6R8X	COIL	6.8uH J	
R6108	NRSA6AD-123W	MG RESISTOR	12kΩ 1/16W D		L3732	NQL085J-6R8X	COIL	6.8uH J	
R6109	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J		L3801	NQR0129-002X	FERRITE BEADS		
R6202	NRSA6AD-123W	MG RESISTOR	12kΩ 1/16W D		L3802	NQR0129-002X	FERRITE BEADS		
R6203	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D		L3803	NQR0006-001X	FERRITE BEADS		
R6302	NRSA6AD-183W	MG RESISTOR	18kΩ 1/16W D		L3804	NQL38DK-100X	P COIL	10uH K	
R6303	NRSA6AD-472W	MG RESISTOR	4.7kΩ 1/16W D		L4201	NQR0129-002X	FERRITE BEADS		
R6305	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		L4301	NQR0129-002X	FERRITE BEADS		
R6306	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J		L4302	NQR0129-002X	FERRITE BEADS		
R6308	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J		L4802	NQL302N-100X	COIL	10uH N	
R6309	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J		L4851	NQR0129-002X	FERRITE BEADS		
R6402	NRSA6AD-243W	MG RESISTOR	24kΩ 1/16W D		L4852	NQL315K-100X	COIL	10uH K	
R6403	NRSA6AD-302W	MG RESISTOR	3kΩ 1/16W D		L4853	NQL315K-100X	COIL	10uH K	
R6405	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J		L5501	NQL315K-100X	COIL	10uH K	
R6406	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		L5502	NQR0129-002X	FERRITE BEADS		
R6407	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		L5503	NQR0129-002X	FERRITE BEADS		
R6502	NRSA6AD-473W	MG RESISTOR	47kΩ 1/16W D		L5504	NQR0129-002X	FERRITE BEADS		
R6503	NRSA6AD-562W	MG RESISTOR	5.6kΩ 1/16W D		L5505	NQL315K-100X	COIL	10uH K	
R6505	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J		L5506	NQL315K-100X	COIL	10uH K	
R6506	NRSA6AJ-273W	MG RESISTOR	27kΩ 1/16W J		L6001	NQLZ011-4R7X	COIL	4.7uH N	
R6602	NRSA6AD-114W	MG RESISTOR	110kΩ 1/16W D		L6002	NQLZ011-4R7X	COIL	4.7uH N	
R6603	NRSA6AD-392W	MG RESISTOR	3.9kΩ 1/16W D		L6101	NQL52EM-390X	COIL	39uH M	
R6604	NRSA6AD-114W	MG RESISTOR	110kΩ 1/16W D		L6201	NQL52EM-390X	COIL	39uH M	
R6605	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		L6301	NQL52EM-390X	COIL	39uH M	
R6606	NRSA6AD-104W	MG RESISTOR	100kΩ 1/16W D		L6302	NQL144K-220X	P COIL	22uH K	
R6607	NRSA6AD-473W	MG RESISTOR	47kΩ 1/16W D		L6401	NQL52EM-470X	COIL	47uH M	
R6608	NRSA6AJ-273W	MG RESISTOR	27kΩ 1/16W J		L6501	NQL52EM-470X	COIL	47uH M	
R6609	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J		L6601	NQL52EM-221X	COIL	220uH M	
R6610	NRSA6AD-473W	MG RESISTOR	47kΩ 1/16W D		L6701	NQL73EM-100X	COIL	10uH M	
R6611	NRSA6AD-683W	MG RESISTOR	68kΩ 1/16W D		L6801	NQL034K-470X	P COIL	47uH K	
R6612	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		CN101	QGF0528F1-40X	CONNECTOR	FFC/FPC (1-40)	
R6613	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J		CN102	QGF0505F1-22X	CONNECTOR	FFC/FPC (1-22)	
R6614	NRSA6AD-104W	MG RESISTOR	100kΩ 1/16W D		CN104	QGA1002C1-11X	CONNECTOR	W-B (1-11)	
R6615	NRSA6AD-104W	MG RESISTOR	100kΩ 1/16W D		CN105	QGB0509M1-30X	CONNECTOR	B-B (1-30)	
R6616	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		CN106	QGA1201C2-05X	CONNECTOR	W-B (1-5)	
R6617	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J		CN107	QGF0503C1-20X	CONNECTOR	FFC/FPC (1-20)	
R6618	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		CN108	QGF0503C1-24V	CONNECTOR	FFC/FPC (1-24)	
R6619	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J		CN109	QGF0503F1-16X	CONNECTOR	FFC/FPC (1-16)	
R6701	NRZ0058-R20X	MG RESISTOR	0.2Ω 1/2W J		CN110	QGF0528F1-40X	CONNECTOR	FFC/FPC (1-40)	
R6702	NRSA6AD-114W	MG RESISTOR	110kΩ 1/16W D		CN111	QGF0528F1-40X	CONNECTOR	FFC/FPC (1-40)	
R6703	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D		△F6001	NMFZ007-2R0X-K	FUSE	2A 32V	
R6704	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J		△F6301	NMFZ007-1R25X-K	FUSE	1.25A 32V	
R6706	NRSA6AD-823W	MG RESISTOR	82kΩ 1/16W D		△F6701	NMFZ007-1R25X-K	FUSE	1.25A 32V	
R6707	NRSA6AD-333W	MG RESISTOR	33kΩ 1/16W D		△F6801	NMFZ007-R50X-K	FUSE	0.5A 50V	
R6801	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		J501	NNZ0041-001X	D CONNECTOR	IEEE1394(4pin)	
R6803	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		X1001	NAX0578-001X	CRYSTAL		
R6804	NRVA6AD-563W	CMF RESISTOR	56kΩ 1/16W D		X1002	NAX0564-001X	CRYSTAL		
△R6805	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		X3002	NAX0480-001X	CRYSTAL	24.576MHz	
R6813	NRVA6AD-273W	CMF RESISTOR	27kΩ 1/16W D		X5501	NAX0587-001X	CXO		
R6815	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J		OT1	LY30030-069A	SPACER(A)		
R8059	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J		OT2	LY44158-001A	SHEET(SHIELD)		
RA1001	NRZ0034-473W	NET RESISTOR	47kΩ 1/32W J		WR1	QAL0474-001	FPC	MAIN-PREMDA CN401	
RA1002	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J		WR2	QAL0474-001	FPC	MAIN-PREMDA CN408	
RA1004	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J						
RA1005	NRZ0034-103W	NET RESISTOR	10kΩ 1/32W J						
RA1006	NRZ0034-102W	NET RESISTOR	1kΩ 1/32W J						

JVC

SERVICE MANUAL

DIGITAL VIDEO CAMERA

GR-D20EK, GR-D20Ex, GR-D20Ey, GR-D20Ez, GR-D21EK,
GR-D40EK, GR-D40Ex, GR-D40Ey, GR-D40Ez



Mini **DV** PAL

For disassembling and assembling of MECHANISM ASSEMBLY, refer to the SERVICE MANUAL No.86700 (MECHANISM ASSEMBLY).

SPECIFICATION

Camcorder		Connectors	
General		S-Video	
Power supply	: DC 11.0 V $\overline{\text{---}}$ (Using AC Adapter) DC 7.2 V $\overline{\text{---}}$ (Using battery pack)	Output	: Y : 1 V (p-p), 75 Ω , analogue C : 0.29 V (p-p), 75 Ω , analogue
Power consumption		Input*	: Y : 0.8 V (p-p) -1.2 V (p-p), 75 Ω , analogue C : 0.2 V (p-p) -0.4 V (p-p), 75 Ω , analogue
LCD monitor off, viewfinder on	: Approx. 3.4 W	AV	
LCD monitor on, viewfinder off	: Approx. 4.7 W	Video output	: 1 V (p-p), 75 Ω , analogue
Dimensions (W x H x D)	: 69 mm x 94 mm x 143 mm (with the LCD monitor closed and the viewfinder pushed back in)	Video input*	: 0.8 V (p-p) -1.2 V (p-p), 75 Ω , analogue
Weight	: Approx. 525 g	Audio output	: 300 mV (rms), 1 k Ω , analogue, stereo
Operating temperature	: 0°C to 40°C	Audio input*	: 300 mV (rms), 50 k Ω , analogue, stereo
Operating humidity	: 35% to 80%	DV	
Storage temperature	: -20°C to 50°C	Output	: 4-pin, IEEE 1394 compliant
Pickup	: 1/6" CCD	Input*	: 4-pin, IEEE 1394 compliant
Lens	: F 1.6, f = 2.7 mm to 43.2 mm, 16:1 power zoom lens	USB**	: 5-pin
Filter diameter	: $\varnothing$ 37 mm	EDIT	: $\varnothing$ 3.5 mm, 2-pole
LCD monitor	: 2.5" diagonally measured, LCD panel/TFT active matrix system	* GR-D50/D30 only	
Viewfinder	: Electronic viewfinder with 0.24" black/white LCD	** GR-D50/D40 only	
Speaker	: Monaural		
Digital Video Camera		AC Adapter	
Format	: DV format (SD mode)	Power requirement	AC 110 V to 240 V $\sim$, 50 Hz/60 Hz
Signal format	: PAL standard		Output : DC 11 V $\overline{\text{---}}$, 1 A
Recording/Playback format	: Video: Digital component recording Audio: PCM digital recording, 32 kHz 4-channel (12-bit), 48 kHz 2-channel (16-bit)		
Cassette	: Mini DV cassette		
Tape speed	: SP : 18.8 mm/s LP : 12.5 mm/s		
Maximum recording time (using 80 min. cassette)	: SP : 80 min. LP : 120 min.		

Specifications shown are for SP mode unless otherwise indicated. E & O.E. Design and specifications subject to change without notice.

GR-D20EK, GR-D20EX, GR-D20EY, GR-D20EZ, GR-D21EK, GR-D40EK, GR-D40EX, GR-D40EY, GR-D40EZ M3D122, M3D124

COPYRIGHT © 2003 VICTOR COMPANY OF JAPAN, LTD.

No.86730
2003/04

TABLE OF CONTENTS

1	PRECAUTIONS	1-3
1.1	SAFTY PRECAUTIONS	1-3
2	SPECIFIC SERVICE INSTRUCTIONS	1-5
2.1	BEFORE ASSEMBLY AND DISASSEMBLY	1-5
2.2	ASSEMBLY AND DISASSEMBLY OF CABINET PARTS	1-6
2.3	ASSEMBLY AND DISASSEMBLY OF CAMERA SECTION AND BOARD ASSEMBLY	1-10
2.4	ASSEMBLY AND DISASSEMBLY OF [8]VF ASSEMBLY	1-12
2.5	ASSEMBLY AND DISASSEMBLY OF [10]MONITOR ASSEMBLY (CABINET PARTS)	1-13
2.6	ASSEMBLY AND DISASSEMBLY OF [2]OP BLOCK ASSEMBLY / CCD BOARD ASSEMBLY (CAMERA SECTION AND BOARD ASSEMBLY)	1-14
2.7	SERVICE NOTE	1-15
2.8	TAKE OUT CASSETTE TAPE	1-16
2.9	EMERGENCY DISPLAY	1-17
3	ADJUSTMENT	1-18
3.1	PREPARATION	1-18
3.2	TOOLS REQUIRED FOR ADJUSTMENT	1-18
3.3	JIG CONNECTOR CABLE	1-20
3.4	MECHANISM ADJUSTMENT	1-21
3.5	ELECTRICAL ADJUSTMENT	1-22
CHARTS AND DIAGRAMS		
	BOARD INTERCONNECTIONS	2-3
	MAIN IF SCHEMATIC DIAGRAM	2-5
	CPU SCHEMATIC DIAGRAM	2-7
	AUDIO SCHEMATIC DIAGRAM	2-9
	DV MAIN SCHEMATIC DIAGRAM	2-11
	VIDEO I/O SCHEMATIC DIAGRAM	2-13
	CAMERA DSP SCHEMATIC DIAGRAM	2-15
	OP DRIVER SCHEMATIC DIAGRAM	2-17
	TG SCHEMATIC DIAGRAM	2-19
	REG SCHEMATIC DIAGRAM	2-21
	AV STRM SCHEMATIC DIAGRAM	2-23
	MONI-BW SCHEMATIC DIAGRAM	2-25
	BL-2.5 SCHEMATIC DIAGRAM	2-27
	CCD SCHEMATIC DIAGRAM	2-28
	JACK SCHEMATIC DIAGRAM	2-29
	PREMDA IF SCHEMATIC DIAGRAM	2-30
	MDA SCHEMATIC DIAGRAM	2-31
	PRE/REC SCHEMATIC DIAGRAM	2-33
	B/W-VF SCHEMATIC DIAGRAM	2-35
	ZOOM UNIT SCHEMATIC DIAGRAM	2-36
	MAIN CIRCUIT BOARD	2-37
	COMPONENT PARTS LOCATION GUIDE <MAIN>	2-41
	COMPONENT PARTS LOCATION GUIDE <PREMDA>	2-42
	PREMDA CIRCUIT BOARD	2-43
	MONI-BW CIRCUIT BOARD	2-47
	BL-2.5 CIRCUIT BOARD	2-48
	JACK CIRCUIT BOARD	2-49
	CCD CIRCUIT BOARD	2-50
	B/W-VF CIRCUIT BOARD	2-50
	POWER SYSTEM BLOCK DIAGRAM	2-51
	VIDEO BLOCK DIAGRAM	2-53
	VOLTAGE CHARTS	2-57
PARTS LIST		
1.	EXPLODED VIEW	3-1
1.1	PACKING AND ACCESSORY ASSEMBLY <M1>	3-1
1.2	FINAL ASSEMBLY <M2>	3-2
1.3	MECHANISM ASSEMBLY <M3>	3-4
1.4	ELECTRONIC VIEWFINDER ASSEMBLY <M4>	3-5
1.5	MONITOR ASSEMBLY (2.5 INCH) <M5>	3-6
2.	PARTS LIST	3-7

MODEL	GR-D20EK	GR-D20EX	GR-D20EY	GR-D20EZ	GR-D21EK	GR-D40EK	GR-D40EX	GR-D40EY	GR-D40EZ
DIGITAL INTERFACE	NO	NO	NO	NO	NO	USB	USB	USB	USB
POWER CORD	BS TYPE	CEE TYPE	CEE TYPE	CEE TYPE	BS TYPE	BS TYPE	CEE TYPE	CEE TYPE	CEE TYPE
USB CABLE	NO	NO	NO	NO	NO	YES	YES	YES	YES
CD-ROM	NO	NO	NO	NO	NO	YES	YES	YES	YES

SECTION 1 PRECAUTIONS

1.1 SAFTY PRECAUTIONS

Prior to shipment from the factory, JVC products are strictly inspected to conform with the recognized product safety and electrical codes of the countries in which they are to be sold. However, in order to maintain such compliance, it is equally important to implement the following precautions when a set is being serviced.

1.1.1 Precautions during Servicing

- (1) Locations requiring special caution are denoted by labels and inscriptions on the cabinet, chassis and certain parts of the product. When performing service, be sure to read and comply with these and other cautionary notices appearing in the operation and service manuals.

- (2) Parts identified by the $\triangle$ symbol and shaded () parts are critical for safety.

Replace only with specified part numbers.

NOTE :

Parts in this category also include those specified to comply with X-ray emission standards for products using cathode ray tubes and those specified for compliance with various regulations regarding spurious radiation emission.

- (3) Fuse replacement caution notice.
Caution for continued protection against fire hazard.
Replace only with same type and rated fuse(s) as specified.
- (4) Use specified internal wiring. Note especially:
 - Wires covered with PVC tubing
 - Double insulated wires
 - High voltage leads
- (5) Use specified insulating materials for hazardous live parts.
Note especially:
 - Insulation Tape
 - PVC tubing
 - Spacers
 - Insulation sheets for transistors
 - Barrier
- (6) When replacing AC primary side components (transformers, power cords, noise blocking capacitors, etc.) wrap ends of wires securely about the terminals before soldering.




Fig.1-1-1

- (7) Observe that wires do not contact heat producing parts (heatsinks, oxide metal film resistors, fusible resistors, etc.)
- (8) Check that replaced wires do not contact sharp edged or pointed parts.
- (9) When a power cord has been replaced, check that 10-15 kg of force in any direction will not loosen it.



Fig.1-1-2

- (10) Also check areas surrounding repaired locations.
- (11) Products using cathode ray tubes (CRTs) In regard to such products, the cathode ray tubes themselves, the high voltage circuits, and related circuits are specified for compliance with recognized codes pertaining to X-ray emission. Conse-

quently, when servicing these products, replace the cathode ray tubes and other parts with only the specified parts. Under no circumstances attempt to modify these circuits. Unauthorized modification can increase the high voltage value and cause X-ray emission from the cathode ray tube.

- (12) Crimp type wire connector

In such cases as when replacing the power transformer in sets where the connections between the power cord and power transformer primary lead wires are performed using crimp type connectors, if replacing the connectors is unavoidable, in order to prevent safety hazards, perform carefully and precisely according to the following steps.

- **Connector part number** : E03830-001

- **Required tool** : Connector crimping tool of the proper type which will not damage insulated parts.

- **Replacement procedure**

- a) Remove the old connector by cutting the wires at a point close to the connector.

Important : Do not reuse a connector (discard it).




Fig.1-1-3

- b) Strip about 15 mm of the insulation from the ends of the wires. If the wires are stranded, twist the strands to avoid frayed conductors.




Fig.1-1-4

- c) Align the lengths of the wires to be connected. Insert the wires fully into the connector.




Fig.1-1-5

- d) As shown in Fig.1-1-6, use the crimping tool to crimp the metal sleeve at the center position. Be sure to crimp fully to the complete closure of the tool.




Fig.1-1-6

- e) Check the four points noted in Fig.1-1-7.




Fig.1-1-7

1.1.2 Safety Check after Servicing

Examine the area surrounding the repaired location for damage or deterioration. Observe that screws, parts and wires have been returned to original positions. Afterwards, perform the following tests and confirm the specified values in order to verify compliance with safety standards.

(1) Insulation resistance test

Confirm the specified insulation resistance or greater between power cord plug prongs and externally exposed parts of the set (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.).

See table 1 below.

(2) Dielectric strength test

Confirm specified dielectric strength or greater between power cord plug prongs and exposed accessible parts of the set (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.). See Fig.1-1-11 below.

(3) Clearance distance

When replacing primary circuit components, confirm specified clearance distance (d), (d') between soldered terminals, and between terminals and surrounding metallic parts. See Fig.1-1-11 below.




Fig.1-1-8

(4) Leakage current test

Confirm specified or lower leakage current between earth ground/power cord plug prongs and externally exposed accessible parts (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.).

Measuring Method : (Power ON)

Insert load Z between earth ground/power cord plug prongs and externally exposed accessible parts. Use an AC voltmeter to measure across both terminals of load Z. See Fig.1-1-9 and following Fig.1-1-12.





Fig.1-1-9

(5) Grounding (Class 1 model only)

Confirm specified or lower grounding impedance between earth pin in AC inlet and externally exposed accessible parts (Video in, Video out, Audio in, Audio out or Fixing screw etc.).

Measuring Method:

Connect milli ohm meter between earth pin in AC inlet and exposed accessible parts. See Fig.1-1-10 and grounding specifications.



Grounding Specifications

Region	Grounding Impedance (Z)
USA & Canada	$Z \leq 0.1 \text{ ohm}$
Europe & Australia	$Z \leq 0.5 \text{ ohm}$

Fig.1-1-10

AC Line Voltage	Region	Insulation Resistance (R)	Dielectric Strength	Clearance Distance (d), (d')
100 V	Japan	$R \geq 1 \text{ M}\Omega/500 \text{ V DC}$	AC 1 kV 1 minute	$d, d' \geq 3 \text{ mm}$
100 to 240 V			AC 1.5 kV 1 minute	$d, d' \geq 4 \text{ mm}$
110 to 130 V	USA & Canada	$1 \text{ M}\Omega \leq R \leq 12 \text{ M}\Omega/500 \text{ V DC}$	AC 1 kV 1 minute	$d, d' \geq 3.2 \text{ mm}$
110 to 130 V 200 to 240 V	Europe & Australia	$R \geq 10 \text{ M}\Omega/500 \text{ V DC}$	AC 3 kV 1 minute (Class II) AC 1.5 kV 1 minute (Class I)	$d \geq 4 \text{ mm}$ $d' \geq 8 \text{ mm}$ (Power cord) $d' \geq 6 \text{ mm}$ (Primary wire)

Fig.1-1-11

AC Line Voltage	Region	Load Z	Leakage Current (i)	a, b, c
100 V	Japan	$1 \text{ k}\Omega$	$i \leq 1 \text{ mA rms}$	Exposed accessible parts
110 to 130 V	USA & Canada	$0.15 \mu\text{F}$ in parallel with $1.5 \text{ k}\Omega$	$i \leq 0.5 \text{ mA rms}$	Exposed accessible parts
110 to 130 V 220 to 240 V	Europe & Australia	$2 \text{ k}\Omega$	$i \leq 0.7 \text{ mA peak}$ $i \leq 2 \text{ mA dc}$	Antenna earth terminals
		$50 \text{ k}\Omega$	$i \leq 0.7 \text{ mA peak}$ $i \leq 2 \text{ mA dc}$	Other terminals

Fig.1-1-12

NOTE :

These tables are unofficial and for reference only. Be sure to confirm the precise values for your particular country and locality.

SECTION 2

SPECIFIC SERVICE INSTRUCTIONS

2.1 BEFORE ASSEMBLY AND DISASSEMBLY

2.1.1 Precautions

1. Be sure to disconnect the power supply unit prior to mounting and soldering of parts.
2. Prior to removing a component part that needs to disconnect its connector(s) and its screw(s), first disconnect the wire(s) from the connector(s), and then remove the screw(s).
3. When connecting/disconnecting wires, pay enough attention not to damage the connectors.
4. Be careful in removing or handling the part to which some spacer or shield is attached for reinforcement or insulation.
5. When replacing chip parts (especially IC parts), first remove the solder completely to prevent peeling of the pattern.
6. Tighten screws properly during the procedures. Unless specified otherwise, tighten screws at a torque of 0.088N•m (0.9kgf•cm).

2.1.2 Assembly and disassembly

[Example]

STEP No.	PART	Fig. No.	POINT	NOTE
[1]	TOP COVER ASSEMBLY	Fig.C1	S1,2(L1)	-
[2]	UPPER ASSEMBLY (Inc. VF ASSEMBLY, SPEAKER/MONITOR)	Fig.C2-1	S2a,2(S2b),3(S2c) 2(S2d),S2e,S2c L2,CN2a,b	-
[8]	VF ASSEMBLY	Fig.C2-2	2(S8),L8,CN8a	NOTE 8a NOTE 8b
(1)	(2)	(3)	(4)	(5)

(1) Order of steps in Procedure

When reassembling, preform the step(s) in the reverse order. These numbers are also used as the identification (location) No. of parts Figures.

(2) Part to be removed or installed.

(3) Fig. No. showing Procedure or Part Location.

C = CABINET

D = CAMERA AND BOARD ASSEMBLY

(4) Identification of part to be removed, unhooked, unlocked, released, unplugged, unclamped or unsoldered.

P = Spring

W = Washer

S = Screw

* = Unhook, unlock, release, unplug or unsolder.

2(S3) = 2 Screws (S3)

CN = Connector

(5) Adjustment information for installation.

2.1.3 Destination of connectors

Two kinds of double-arrows in connection tables respectively show kinds of connector/wires.

⇔ : Flat wire

↔ : Wire

[Example]

CONN. No.	CONNECTOR				Pin No.
CN2a	MAIN	CN101	⇔	MONIBW CN761	40
CN2b	MAIN	CN103	⇔	MINIBW CN762	10

Remove the parts marked in .

2.1.4 Disconnection of connectors (Wires)

Pull both ends of the connector in the arrow direction, remove the lock and disconnect the flat wire.




Fig.2-1-1

Extend the locks in the direction of the arrow for unlocking and then pull out the wire. After removing the wire, immediately restore the locks to their original positions because the locks are apt to come off the connector.




Fig.2-1-2

2.1.5 Tools required for disassembly and assembly






1	Torque driver YTU94088	2	Bit YTU94088-003
			
3	Tweezers P-895	4	Chip IC replacement jig PTS40844-2
			
5	Cleaning cloth KSMM-01		
			

Fig.2-1-3

1.Torque driver

Be sure to use to fastening the mechanism and exterior parts because those parts must strictly be controlled for tightening torque.

2.Bit

This bit is slightly longer than those set in conventional torque drivers.

3.Tweezers

To be used for removing and installing parts and wires.

4.Chip IC replacement jig

To be used for replacement of IC.


5.Cleaning cloth

Recommended cleaning cloth to wipe down the video heads, mechanism (tape transport system), optical lens surface.

2.2 ASSEMBLY AND DISASSEMBLY OF CABINET PARTS

2.2.1 Disassembly flow chart

This flowchart indicates the disassembly step for the cabinet parts and board assembly in order to gain access to item(s) to be serviced. When reassembling, perform the step(s) in reverse order.



2.2.2 Disassembly method

STEP No.	PART	Fig. No.	POINT	NOTE
[1]	TOP COVER ASSEMBLY	Fig.C1	S1,2(L1)	-
[2]	UPPER ASSEMBLY (Inc. VF ASSEMBLY, SPEAKER/MONITOR)	Fig.C2-1	S2a,2(S2b),3(S2c) 2(S2d),S2e,S2c L2,CN2a,b	-
[8]	VF ASSEMBLY	Fig.C2-2	2(S8),L8,CN8a	NOTE 8a NOTE 8b
[9]	COVER(UPPER)	Fig.C2-3	2(S9),L9	-
/[10]	MONITOR ASSEMBLY		2(S10a),CN10a,2(S10b),L10	NOTE 10a NOTE 10b
[11]	MONI-BW BOARD ASSEMBLY	Fig.C2-4	2(S11a),2(S11b),4(S11c)	NOTE 11a
/[12]	SPEAKER		BKT(HINGE),KNOB(SLIDE)	NOTE 11b NOTE 11c
[3]	FRONT COVER ASSEMBLY (Inc.MIC)	Fig.C3	COVER(JACK),S3,L3a,L3b CN4	NOTE 3
[4]	MIC		S4	
[5]	COVER(ZOOM)	Fig.C4	S5a,3(S5b),2(L5)	-
/[6]	REAR UNIT		CN6,S6	
/[7]	LOWER ASSEMBLY		CN7a,b,S7a,3(S7b)	

CONN. No.	CONNECTOR					Pin No.
CN2a	MAIN	CN101	↔	MONI-BW	CN761	40
CN2b	MAIN	CN103	↔	MONI-BW	CN762	10
CN8a	MONI-BW	CN763	↔	VF ASSEMBLY	-	20
CN10a	MONI-BW	CN765	↔	BL-2.5/3.5	-	32
CN4	MAIN	CN106	↔	MIC	-	5
CN6	MAIN	CN104	↔	REAR UNIT	-	11
CN7a	MAIN	CN102	↔	JACK	CN501	22
CN7b	MAIN	CN109	↔	ZOOM UNIT	-	16

Remove the parts marked in .

NOTE 8a:

Take care not to cut the FPC wire when and after removing the VF ASSEMBLY.

NOTE 8b:

As for disassembly/assembly of [8]VF ASSEMBLY, see 2.4 ASSEMBLY AND DISASSEMBLY OF [8] VF ASSEMBLY.

NOTE 10a:

Take care not to cut the FPC when and after removing the MONITOR ASSEMBLY.

NOTE 10b:

As for disassembly/assembly of [10] MONITOR ASSEMBLY, see 2.5 ASSEMBLY AND DISASSEMBLY OF [10] MONITOR ASSEMBLY.

NOTE 11a:

Before removing the MONI-BW BOARD ASSEMBLY, check whether MEMORY CARD is inserted or not. If MEMORY CARD is inserted, pull out the MEMORY CARD before removing the MONI-BW BOARD ASSEMBLY.

NOTE 11b:

Since the SPEAKER is soldered to the MONI-BW BOARD ASSEMBLY, the SPEAKER should not be separated from the MONI-BW BOARD ASSEMBLY except when replacing the SPEAKER.

NOTE 11c:

Take care not to lose the KNOB(SLIDE). When attaching the KNOB(SLIDE), attach the KNOB(SLIDE) in a proper position.

NOTE 3:

After removing the FRONT COVER ASSEMBLY, OP BLOCK ASSEMBLY is not covered with anything. Take care not to damage the OP BLOCK ASSEMBLY when and after removing the FRONT COVER ASSEMBLY.




Fig.C1




Fig.C2-2




Fig.C2-1




Fig.C2-3




Fig.C3




Fig.C2-4




Fig.C4


2.3 ASSEMBLY AND DISASSEMBLY OF CAMERA SECTION AND BOARD ASSEMBLY

2.3.1 Disassembly flow chart

This flowchart indicates the disassembly step for the cabinet parts and board assembly in order to gain access to item(s) to be serviced. When reassembling, perform the step(s) in reverse order.

NOTE:

Please see Service Manual No. 86700 (MECHANISM ASSY).



2.3.2 Disassembly method

STEP No.	PART	Fig. No.	POINT	NOTE
[1]	MAIN BOARD ASSEMBLY	Fig.D1	CN1a,b,2(S1),CN1c,d	-
[2]/[5]	OP BLOCK ASSEMBLY / CCD BOARD ASSEMBLY	Fig.D2	S2,L2	NOTE 2
[3]	PREMDA BOARD ASSEMBLY	Fig.D3	2(S3a),L3,SHIELD COVER(PR) CN3a,b,c,d,e,f,2(S3b)	-
[4]	MECHANISM ASSEMBLY		3(S4),BKT(MECHA)	-

CONN. No.	CONNECTOR				Pin No.
CN1a	MAIN	CN108	⇔	OP BLOCK ASSEMBLY CN501	24
CN1b	MAIN	CN107	⇔	CCD CN5001	20
CN1c	MAIN	CN111	⇔	PREMDA CN408	40
CN1d	MAIN	CN110	⇔	PREMDA CN401	40
CN3a	PREMDA	CN406	⇔	SENSOR -	16
CN3b	PREMDA	CN405	⇔	CAPSTAN MOTOR -	18
CN3c	PREMDA	CN404	⇔	DRUM MOTOR -	11
CN3d	PREMDA	CN402	⇔	HEAD -	8
CN3e	PREMDA	CN403	⇔	LOADING MOTOR -	6
CN3f	PREMDA	CN407	⇔	ROTARY ENCODER -	6

Remove the parts marked in .

NOTE 2:

As for disassembly/assembly of [2] OP BLOCK ASSEMBLY, see 2.6 ASSEMBLY AND DISASSEMBLY OF [2] OP BLOCK ASSEMBLY.




Fig.D1




Fig.D2




Fig.D3

2.4 ASSEMBLY AND DISASSEMBLY OF [8]VF ASSEMBLY

2.4.1 Disassembly of VF ASSEMBLY

- (1) Remove the EYE CUP.
- (2) Remove the four screws (1 to 4) and then remove the COVER (VF).
- (3) Remove the two screws (5 and 6) and then remove the FPC BOARD from the hook attaching the FPC BOARD.

NOTE 8a:

During the procedure, be careful not to damage the FPC. When attaching the SW BOARD ASSEMBLY, attach the SW BOARD ASSEMBLY so that the SW BOARD ASSEMBLY comes upwards.

- (4) Remove the four screws (7 to 10), and then pull out and remove the FPC from the VF HINGE ASSEMBLY.

NOTE 8b:

During the procedure, be careful not to damage the FPC and the SWITCH.

- (5) Remove the five screws (11 to 15).
- (6) Remove the UPPER CASE(VF) R.
- (7) Remove the UPPER CASE(VF) F and then pull out the LENS SA and the LCD UNIT ASSEMBLY with the FPC.

NOTE 8c:

In attaching the LCD UNIT ASSEMBLY, put the projections of the LCD UNIT ASSEMBLY in the slots of the BOTTOM CASE(VF). Put the STOPPER of the FPC inside the BOTTOM CASE(VF). In attaching the UPPER CASE(VF) F and the UPPER CASE(VF) R, attach the UPPER CASE(VF) F first and then the UPPER CASE(VF) R and be careful to keep the FPC inside the BOTTOM CASE(VF).

2.4.2 Disassembly of the LENS SA

- (1) Remove the LEVER(LENS).
- (2) Remove the SHEET(LENS).
- (3) Remove the LENS ASSEMBLY from the GUIDE LENS(VF).

NOTE 8d:

Be careful not to lose the SPRING(LENS).




Fig.2-4-2




Fig.2-4-1

2.5 ASSEMBLY AND DISASSEMBLY OF [10]MONITOR ASSEMBLY (CABINET PARTS)

2.5.1 Disassembly of MONITOR ASSEMBLY (2.5 INCH)

NOTE:

Be careful in removing or handling the monitor assembly, especially not to soil or scratch the monitor screen during the disassembly procedure.

- (1) While removing the four screws (1 to 4) in numerical order and then disengaging the four hooks (L10a-L10d) in alphabetical order, open and remove the MONITOR COVER ASSEMBLY.
- (2) Remove the SENSOR BOARD ASSEMBLY from the MONITOR CASE.
- (3) Disconnect the FPC in the connectors CN10a and CN10b in this order, and then remove the MONI.HINGE ASSEMBLY.
- (4) Disconnect the FPC of the LCD MODULE from the connector CN10c.
- (5) Remove one screw (5) and then remove the BL BOARD ASSEMBLY together with the BACK LIGHT ASSEMBLY.

NOTE 10a:

It depends on the inch size of the monitor assembly whether the backlight is supplied as an assembly or as separated parts.

In replacing the backlight assembly, see the Parts List.

NOTE 10b:

Since the BACK LIGHT ASSEMBLY is soldered to the BL BOARD ASSEMBLY, the BACK LIGHT should not be separated from the BL BOARD ASSEMBLY except when replacing them.

- (6) Remove the DIFF.SHEET.
- (7) Remove the LCD FRAME together with the LCD MODULE.
- (8) Remove the SHIELD CASE.




Fig.2-5-1

2.6 ASSEMBLY AND DISASSEMBLY OF [2]OP BLOCK ASSEMBLY / CCD BOARD ASSEMBLY (CAMERA SECTION AND BOARD ASSEMBLY)

2.6.1 Precautions

- (1) Take care in handling the CCD IMAGE SENSOR, OP LPF and lens components when performing maintenance etc., especially with regard to surface contamination, attached dust or scratching. If fingerprints are present on the surface they should be wiped away using either a silicon paper, clean chamois or the cleaning cloth.
- (2) The CCD IMAGE SENSOR may have been shipped with a protective sheet attached to the transmitting glass. When replacing the CCD IMAGE SENSOR, do not peel off this sheet from the new part until immediately before it is mounted in the OP BLOCK ASSEMBLY.
- (3) The orientation of the OP LPF is an important factor for installation. If there is some marking on the OP LPF, be sure to note it down before removing and to reassemble it very carefully as it was referring to the marking.

2.6.2 Disassembly of CCD BOARD ASSEMBLY and CCD BASE ASSEMBLY

- (1) Unsolder the CCD BOARD ASSEMBLY by the 14 points (SD2) and then remove it.
- (2) Remove the two screws (1, 2) and remove the CCD BASE ASSEMBLY.
- (3) Remove the SPACER.
- (4) Remove the SHEET.
- (5) Remove the OP LPF.

2.6.3 Assembly of CCD BASE ASSEMBLY and CCD BOARD ASSEMBLY

- (1) Set the OP LPF to the OP BLOCK ASSEMBLY so that the OP side touches the OP BLOCK ASSEMBLY.

NOTE 2a:

- Pay careful attention to the orientation of the OP LPF.
- (2) Set the SHEET to the OP LPF not to come off the right position.
- (3) Attach the SPACER to the OP BLOCK ASSEMBLY.
- (4) Fasten them together with the two screws (1, 2).
- (5) Set the CCD BOARD ASSEMBLY in the CCD BASE ASSEMBLY, and then solder it by the 14 points (SD2).

2.6.4 Replacement of service repair parts

The service repair parts for the OP BLOCK ASSEMBLY are as listed below.

Before replacement of these parts, remove the BRACKET (OP BLOCK ASSEMBLY) as required.

Take special care not to disconnect any of the FPC wires or cause any damage due to soldering (excessive heating).

- (1) FOCUS MOTOR
- (2) ZOOM MOTOR
- (3) IRIS MOTOR UNIT

NOTE 2b:

When replacing the FOCUS MOTOR or the ZOOM MOTOR, solder the FPC at a space of about 1 mm above the terminal pin.

NOTE 2c:

The IRIS MOTOR UNIT includes the FPC ASSEMBLY and two sensors.




Fig.2-6-1

2.7 SERVICE NOTE

Use the following chart to manage screws

<CABINET PART>												
Symbol No.	[1]											
Removing order of screw	1	2	3	4	5	6	7	8	9	10	11	12
Place to stick screw												
Reference drawing (Fig.No.)	C2-1											
Screw tightening torque	I											

<CAMERA AND BOARD ASSEMBLY>												
Symbol No.	[1]											
Removing order of screw	1	2	3	4	5	6	7	8	9	10	11	12
Place to stick screw												
Reference drawing (Fig.No.)	D1											
Screw tightening torque	I											

<VF ASSEMBLY>												
Symbol No.	[8]											
Removing order of screw	1	2	3	4	5	6	7	8	9	10	11	12
Place to stick screw					*	*						
Reference drawing (Fig.No.)	2-4-1											
Screw tightening torque	IV											

<VF ASSEMBLY>												
Symbol No.	[10]											
Removing order of screw	1 2 3 4 5											
Place to stick screw	Place to stick screw											
Reference drawing (Fig.No.)	2-5-1											
Screw tightening torque	III V											

<OP BLOCK ASSEMBLY>												
Symbol No.	[2]/[5]											
Removing order of screw	1	2	3	4	5	6	7	8	9	10	11	
Place to stick screw												
Reference drawing (Fig.No.)	2-6-1											
Screw tightening torque	VI IV											

<NOTE>

.* : Don't reuse the screw, because screw lock bond was applied to them.

· Pay careful attention to tightening torque for each screw.

I	: 0.088N·m (0.9kgf·cm)	II	: 0.147N·m (1.5kgf·cm)	III	: 0.069N·m (0.7kgf·cm)
IV	: 0.078N·m (0.8kgf·cm)	V	: 0.098N·m (1.0kgf·cm)	VI	: 0.118N·m (1.2kgf·cm)

2.8 TAKE OUT CASSETTE TAPE

NOTE :

The following procedure describes a simplified method of ejecting the cassette tape in case it is not possible to eject it, due to an electrical failure.

Be careful not to damage any of the parts or the tape when performing repairs or maintenance work.

- (1) Remove the Power Unit (battery, DC code, etc.) from the set.
- (2) Open the CASSETTE COVER.
- (3) Attach a piece of PVC TAPE at the front of the CASSETTE HOUSING ASSEMBLY.

NOTE:

This helps prevent the tape from being damaged when the CASSETTE HOUSING ASSEMBLY is moved upward at the unloading end.

- (4) Apply DC 3V to the electrode on the top surface of the LOADING MOTOR ASSEMBLY to set the MECHANISM ASSEMBLY to the EJECT mode.
Unloading end is EJECT mode.
- (5) If there is any slack tape in the tape transport system, wind it inside the DVC CASSETTE TAPE by turning the REEL DISK ASSEMBLY (SUP) from the backside of the SLIDE DECK ASSEMBLY.
- (6) Peel off the PVC TAPE and take out the DVC CASSETTE TAPE from the CASSETTE HOUSING ASSEMBLY.

NOTE:

Make sure that grease or a similar substance is not attached to the surface of the tape.

Similarly, also make sure that grease or a similar substance is not attached on the MECHANISM ASSEMBLY.




Fig.2-8-1


2.9 EMERGENCY DISPLAY

Whenever some abnormal signal is input to the syscon CPU, an error number (E01, as an example) is displayed on the LCD monitor or (in the electronic view finder).

In every error status, such the message as shown below alternately appear over and over.

- In an emergency mode, all operations except turning on/off the POWER switch are ineffectual.

Example (in case of the error number E01):



LCD display	Emergency mode	Details	Possible cause
E01	LOADING	In the case the encoder position is not shifted to the next point though the loading motor has rotated in the loading direction for 4 seconds or more. This error is defined as [E01].	1. The mechanism is locked during mode shift. 2. The mechanism is locked at the mechanism loading end, because the encoder position is skipped during mechanism mode shift. 3. No power is supplied to the loading MDA.
E02	UNLOADING	In the case the encoder position is not shifted to the next point though the loading motor has rotated in the unloading direction for 4 seconds or more. This error is defined as [E02].	1. The mechanism is locked during mode shift. 2. The mechanism is locked at the mechanism loading end, because the encoder position is skipped during mechanism mode shift.
E03	TU & SUP REEL FG	In the case no REEL FG is produced for 4 seconds or more in the capstan rotation mode after loading was complete, the mechanism mode is shifted to STOP with the pinch roller set off. This error is defined as [E03]. However, no REEL EMG is detected in the SLW/STILL mode.	1. The idler gear does not engage with the reel disk well. 2. Though the idler gear and reel disk are engaged with each other, the tape is not wound because of overload to the mechanism. 3. No FG pulse is output from the reel sensor. 4. No power is supplied to the reel sensor. 5. Tape transport operation takes place with a cassette having no tape inside. 6. The tape slackens and no pulse is produced until the slack is taken up and the tape comes into the normal status.
E04	DRUM FG	In the case there is no DRUM FG input in the drum rotation mode for 4 seconds or more. This error is defined as [E04], and the mechanism mode is shifted to STOP with the pinch roller set off.	1. The drum cannot be started or drum rotation is stopped because tape transport load is too high. 1) Tape tension is extremely high. 2) The tape is damaged or soiled with grease, etc. 2. The DRUM FG signal is not received by the syscon CPU. 1) Disconnection in the middle of the signal line. 2) Failure of the DRUM FG pulse generator (hall element). 3. No drum control voltage is supplied to the MDA. 4. No power is supplied to the DRUM MDA.
E05	-	-	-
E06	CAPSTAN FG	In the case no CAPSTAN FG is produced in the capstan rotation mode for 2 seconds or more. This error is defined as [E06], and the mechanism mode is shifted to STOP with the pinch roller set off. However, no CAPSTAN EMG is detected in the STILL/FF/REW mode.	1. The CAPSTAN FG signal is not received by the syscon CPU. 1) Disconnection in the middle of the signal line. 2) Failure of the CAPSTAN FG pulse generator (MR element). 2. No capstan control voltage is supplied to the MDA. 4. The capstan cannot be started or capstan rotation is stopped because tape transport load is too high. 1) Tape tension is extremely high. (Mechanical locking) 2) The tape is damaged or soiled with grease, etc. (Tape tangling occurs, etc.)

Fig.2-9-1

SECTION 3 ADJUSTMENT

3.1 PREPARATION

(1) Precaution

This model does not contain adjustment controls (VR). General deck system, camera system and monitor system adjustment are not required. However, if MAIN board need replacement, please use original EEP ROM on to new board. Then adjustment are not required. And if parts such as the following need replacement, special computerized adjustment are required. 3.5.1 Electrical adjustment with personal computer is setup and it adjusts using a service support system. Please contact to JVC Service for detail information.

- OP BLOCK ASSEMBLY
- EEP ROM (IC1005 of MAIN board)
- MONITOR / VF ASSEMBLY

In the event of malfunction with electrical circuits, troubleshooting with the aid of proper test instruments must be done first, and then commence necessary repair, replacement and adjustment, etc.

- a) In case of wiring to chip test points for measurement, use IC clips, etc. to avoid any stress.
- b) Since connectors are fragile, carefully handle them in disconnecting and connecting.
- c) Short circuit between operation unit and DECK chassis.

(2) Required test equipment

- a) Color TV monitor.
- b) AC power adapter
- c) Oscilloscope (dual-trace type, observable 100 MHz or higher frequency)
 - It is recommended to use one observable 300 MHz or higher frequency.
- d) Digital voltmeter
- e) Frequency counter (with threshold level adjuster)
- f) Personal computer

3.2 TOOLS REQUIRED FOR ADJUSTMENT














1	Alignment tape MC-2	2	Guide driver (Hexagonal) D-770-1.27
			
3	INF adjustment lens YTU92001B	4	INF lens holder YTU94087
			
5	Camera stand YTU93079	6	Light box assembly YTU93096A
			
7	Gray scale chart YTU94133A	8	Color bar chart YTU94133C
			
9	Jig connector cable YTU93106B	10	Extension connector YTU94145C-30
			
11	Communication cable YTU93107A	12	PC cable QAM0099-005
			
13	Service support system YTU94057-67	14	Cleaning cloth KSMM-01
			

Fig.3-2-1

1. Alignment tape

To be used for check and adjustment of interchangeability of the mechanism.

2. Guide driver (Hexagonal)

To be used to turn the guide roller to adjustment of the linearity of playback envelope.

3. INF adjustment lens

To be used for adjustment of the camera system. For the usage of the INF adjustment lens, refer to the Service Bulletin No. YA-SB-10035.

4. INF lens holder

To be used together with the Camera stand (6) for operating the Videocamera in the stripped-down condition such as the status without the exterior parts or for using commodities that are not yet conformable to the interchangeable ring. For the usage of the INF lens holder, refer to the Service Bulletin No. YA-SB-10035.

5. Camera stand

To be used together with the INF adjustment lens holder. For the usage of the Camera stand, refer to the Service Bulletin No. YA-SB-10035.

6. Light box assembly

To be used for adjustment of the camera system. For the usage of the Light box assembly, refer to the Service Bulletin No. YA-SB-10035.

7. Gray scale chart

To be used for adjustment of the camera system. For the usage of the INF adjustment lens, refer to the Service Bulletin No. YA-SB-10035.

8. Color bar chart

To be used for adjustment of the camera system. For the usage of the INF adjustment lens, refer to the Service Bulletin No. YA-SB-10035.

9. Jig connector cable

Connected to CN105 of the main board and used for electrical adjustment, etc.

NOTE:

Only some of the connectors in the JIG connector (YTU93106B) are soldered to wires.

It is desirable that you solder all the connectors to wires before using the JIG connector (YTU93106B), but you should solder only the connectors shown in the following JIG connector schematic diagram to wires because they are used in this model.

As for the details, see 3.3 JIG CONNECTOR CABLE.

10. Extension connector

Connect this extension connector to the connector of the jig connector cable for extending the cable connector.

NOTE:

removing the cover (for jig), use this extension connector triple for connecting the jig connector cable.

11. Communication Cable

Connect the Communication cable between the PC cable and Jig connector cable when performing a PC adjustment.

12. PC cable

To be used to connect the Videocamera and a personal computer with each other when a personal computer issued for adjustment.

13. Service support system

To be used for adjustment with a personal computer. Software can be downloaded also from JS-net.

14. Cleaning cloth

Recommended the Cleaning cloth to wipe down the video heads, mechanism (tape transport system), optical lens surface.

3.3 JIG CONNECTOR CABLE

Nine wires have been soldered to the JIG CONNECTOR CABLE (YTU93106B).
Solder another nine wires to the JIG CONNECTOR CABLE (YTU93106B) to use in this set.
See the JIG CONNECTOR SCHEMATIC DIAGRAM and JIG CONNECTOR BOARD to solder the nine wires.

3.3.1 JIG CONNECTOR SCHEMATIC DIAGRAM




Fig.3-3-1

3.3.2 JIG CONNECTOR BOARD




Fig.3-3-2

3.4 MECHANISM COMPATIBILITY ADJUSTMENT

3.4.1 Tape pattern check

- (1) Connect the JIG CONNECTOR CABLE to the set.
As for the connection procedure, JIG CONNECTOR BOARD and see 3.5 ELECTRICAL ADJUSTMENT.
- (2) Remove the COVER(ADJUST)
- (3) Play back the compatibility adjustment tape.
- (4) While triggering the HID1, observe the waveform of ENV_OUT.
- (5) Confirm that the waveform is free from remarkable level-down, and entirely parallel and straight.
- (6) In case any level-down is observed on the left hand side, straighten the level by turning the GUIDE ROLLER (SUP) of the POLE BASE ASSEMBLY.
In case any level-down is observed on the right hand side, however, straighten the level by turning the GUIDE ROLLER (TU) of the POLE BASE ASSEMBLY.
- (7) After adjustment, try the unloading motion once, and confirm that the waveform is flat (straight) when the tape has been played back again.
Moreover, perform readjustment as required.
- (8) When the recording has been played back again, play back the self-recording to confirm that the waveform is flat.




Fig.3-4-1




Fig.3-4-2




Fig.3-4-3

3.5 ELECTRICAL ADJUSTMENT

3.5.1 Electrical adjustment with personal computer

- Electrical adjustment is performed by using PERSONAL COMPUTER. As for the connection of cables, see Fig. 3-5-1. Read README.TXT file to use the software for SERVICE SUPPORT SYSTEM properly.
- Remove the COVER (JIG) to perform adjustment.




Fig.3-5-1



VICTOR COMPANY OF JAPAN, LIMITED

AV & MULTIMEDIA COMPANY CAMCORDER CATEGORY 12, 3-chome, Moriya-cho, kanagawa-ku, Yokohama, kanagawa-prefecture, 221-8528, Japan

(No.86730)



Printed in Japan
200304WPC


JVC

SCHEMATIC DIAGRAMS

DIGITAL VIDEO CAMERA

GR-D20EK, GR-D20EX, GR-D20EY, GR-D20EZ, GR-D21EK,
GR-D40EK, GR-D40EX, GR-D40EY, GR-D40EZ

CD-ROM No.SML200305



For disassembling and assembling of MECHANISM ASSEMBLY, refer to the SERVICE MANUAL No.86700 (MECHANISM ASSEMBLY).

SPECIFICATION

Camcorder		Connectors	
General		S-Video	
Power supply	: DC 11.0 V $\overline{\text{---}}$ (Using AC Adapter) DC 7.2 V $\overline{\text{---}}$ (Using battery pack)	Output	: Y : 1 V (p-p), 75 Ω , analogue C : 0.29 V (p-p), 75 Ω , analogue
Power consumption		Input*	: Y : 0.8 V (p-p) -1.2 V (p-p), 75 Ω , analogue C : 0.2 V (p-p) -0.4 V (p-p), 75 Ω , analogue
LCD monitor off, viewfinder on	: Approx. 3.4 W	AV	
LCD monitor on, viewfinder off	: Approx. 4.7 W	Video output	: 1 V (p-p), 75 Ω , analogue
Dimensions (W x H x D)	: 69 mm x 94 mm x 143 mm (with the LCD monitor closed and the viewfinder pushed back in)	Video input*	: 0.8 V (p-p) -1.2 V (p-p), 75 Ω , analogue
Weight	: Approx. 525 g	Audio output	: 300 mV (rms), 1 k Ω , analogue, stereo
Operating temperature	: 0°C to 40°C	Audio input*	: 300 mV (rms), 50 k Ω , analogue, stereo
Operating humidity	: 35% to 80%	DV	
Storage temperature	: -20°C to 50°C	Output	: 4-pin, IEEE 1394 compliant
Pickup	: 1/6" CCD	Input*	: 4-pin, IEEE 1394 compliant
Lens	: F 1.6, f = 2.7 mm to 43.2 mm, 16:1 power zoom lens	USB**	: 5-pin
Filter diameter	: $\varnothing$ 37 mm	EDIT	: $\varnothing$ 3.5 mm, 2-pole
LCD monitor	: 2.5" diagonally measured, LCD panel/TFT active matrix system		
Viewfinder	: Electronic viewfinder with 0.24" black/white LCD		
Speaker	: Monaural		
Digital Video Camera		AC Adapter	
Format	: DV format (SD mode)	Power requirement	: AC 110 V to 240 V $\sim$, 50 Hz/60 Hz
Signal format	: PAL standard	Output	: DC 11 V $\overline{\text{---}}$, 1 A
Recording/Playback format	: Video: Digital component recording Audio: PCM digital recording, 32 kHz 4-channel (12-bit), 48 kHz 2-channel (16-bit)		
Cassette	: Mini DV cassette		
Tape speed	: SP : 18.8 mm/s LP : 12.5 mm/s		
Maximum recording time (using 80 min. cassette)	: SP : 80 min. LP : 120 min.		

Specifications shown are for SP mode unless otherwise indicated. E & O.E. Design and specifications subject to change without notice.

GR-D20EK, GR-D20EX, GR-D20EY, GR-D20EZ, GR-D21EK, GR-D40EK, GR-D40EX, GR-D40EY, GR-D40EZ M3D122, M3D124

COPYRIGHT © 2003 VICTOR COMPANY OF JAPAN, LTD.

No.86730SCH
2003/04

CHARTS AND DIAGRAMS

NOTES OF SCHEMATIC DIAGRAM

Safety precautions

The Components identified by the symbol  are critical for safety. For continued safety, replace safety critical components only with manufacturer's recommended parts.

1. Units of components on the schematic diagram

Unless otherwise specified.

- 1) All resistance values are in ohm. 1/6 W, 1/8 W (refer to parts list).
Chip resistors are 1/16 W.
K: K Ω (1000 Ω), M: M Ω (1000K Ω)
- 2) All capacitance values are in μ F, (P: PF).
- 3) All inductance values are in μ H, (m: mH).
- 4) All diodes are 1SS133, MA165 or 1N4148M (refer to parts list).

Note: The Parts Number, value and rated voltage etc. in the Schematic Diagram are for references only. When replacing the parts, refer to the Parts List.

2. Indications of control voltage


AUX : Active at high.

$\overline{\text{AUX}}$ or AUX(L) : Active at low.


3. Interpreting Connector indications




Removable connector



Wire soldered directly on board



Non-removable Board connector



Board to Board




Connected pattern on board
The arrows indicate signal path

Note: For the destination of each signal and further line connections that are cut off from the diagram, refer to "BOARD INTERCONNECTIONS"

4. Voltage measurement

- 1) Regulator (DC/DC CONV) circuits
REC : Colour bar signal.
PB : Alignment tape (Colour bar).
— : Unmeasurable or unnecessary to measure.
- 4) Indication on schematic diagram
Voltage Indications for REC and PB mode on the schematic diagram are as shown below.




Note: If the voltages are not indicated on the schematic diagram, refer to the voltage charts.


5. Signal path Symbols

The arrows indicate the signal path as follows.

NOTE : The arrow is DVC unique object.



(Example)



6. Indication of the parts for adjustments

The parts for the adjustments are surrounded with the circle as shown below.



7. Indication of the parts not mounted on the circuit board

"OPEN" is indicated by the parts not mounted on the circuit board.




CIRCUIT BOARD NOTES

1. Foil and Component sides

- 1) Foil side (B side) :
Parts on the foil side seen from foil face (pattern face) are indicated.
- 2) Component side (A side) :
Parts on the component side seen from component face (parts face) indicated.

2. Parts location guides


Parts location are indicated by guide scale on the circuit board.




Note: For general information in service manual, please refer to the Service Manual of GENERAL INFORMATION Edition 4 No. 82054D (January 1994).

■ BOARD INTERCONNECTIONS


NOTE)*:The number of patch cords
are indicated by inter connected.



■ MAIN IF SCHEMATIC DIAGRAM



■ CPU SCHEMATIC DIAGRAM




NOTE: The parts with marked (※) is not used.

y10332001a_rev0.1

■ AUDIO SCHEMATIC DIAGRAM

0 1 MAIN(AUDIO)



NOTE: The parts with marked (※) is not used.

DV_MAIN SCHEMATIC DIAGRAM


5

4

3

2

1




DIFFERENT PARTS LIST

	R30B1	R30B2	R30B3
NON_PIXELA	OPEN	0Ω	OPEN
PIXELA	470Ω	OPEN	0Ω

NOTE: The parts with marked (*) is not used.

VIDEO I/O SCHEMATIC DIAGRAM




NOTE: The parts with marked (※) is not used.

CAMERA DSP SCHEMATIC DIAGRAM

5
4
3
2
1

01 MAIN(CAMERA DSP)




	R4302	R4303
NTSC	0 Ω	※
PAL	※	0 Ω

NOTE: The parts with marked (※) is not used.


OP DRIVER SCHEMATIC DIAGRAM

0 1 MAIN(OP DRIVER)



NOTE: The parts with marked (※) is not used.

■ TG SCHEMATIC DIAGRAM





3

2

1

B

2-21 D

E

G

5




3

2

1


■ MONI-BW SCHEMATIC DIAGRAM



NOTE: The parts with marked (※) is not used.


y10337001a_rev0.1

■ BL-2.5 SCHEMATIC DIAGRAM




■ CCD SCHEMATIC DIAGRAM

NOTES : • IC5001 is incorporated in the CCD base assembly.
When IC 5001 needs replacement, replace the CCD base assembly in whole because it cannot be replaced alone.




	Q5002	R5005
DSC MODEL	2SC4081/QR/-X	4.7K
NON DSC MODEL	※	※


JACK SCHEMATIC DIAGRAM




PREMDA IF SCHEMATIC DIAGRAM



■ MDA SCHEMATIC DIAGRAM




■ PRE/REC SCHEMATIC DIAGRAM



NOTE: The parts with marked (※) is not used.


■ B/W-VF SCHEMATIC DIAGRAM



y40104001a_rev0.1

■ ZOOM UNIT SCHEMATIC DIAGRAM


NOTES : ● The schematic diagram is only for reference. Avoid replacing individual parts.
Replace the entire unit only.



■ MAIN CIRCUIT BOARD

<01> MAIN
YB 10404-01-01


FOIL SIDE(B)



■ MAIN CIRCUIT BOARD

<01> MAIN
YB 10404-01-01

COMPONENT SIDE(A)




COMPONENT PARTS LOCATION GUIDE <MAIN> YB 10404-01-01

REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION
CAPACITOR																					
C1001	A C 4B	C3011	A C 2A	C4214	A C 3B	C6604	B C 1A	IC1006	A C 4A	Q3704	B C 5B	R1084	B C 5B	R3068	A C 2A	R4355	A C 3C	R6309	A C 2A		
C1002	A C 4B	C3012	A C 2A	C4216	A C 3B	C6605	B C 1B	IC1007	A C 4A	Q3705	B C 5B	R1085	A C 4A	R3069	A C 2A	R4356	A C 3C	R6402	B C 1A		
C1003	A C 4B	C3013	A C 3B	C4301	A C 3B	C6606	B C 1B	IC2101	A C 5B	Q3731	B C 5A	R1086	B C 4A	R3071	A C 2A	R4804	B C 5C	R6403	B C 1A		
C1003	A C 4A	C3015	A C 2A	C4302	A C 3C	C6607	B C 1B	IC2201	A C 5A	Q3732	B C 5A	R1087	B C 4A	R3072	A C 2A	R4805	B C 5C	R6405	B C 1A		
C1004	A C 4A	C3016	A C 2A	C4303	A C 3C	C6608	B C 1B	IC3001	A C 3A	Q3733	B C 5A	R1088	B C 5A	R3073	A C 2A	R4806	B C 6C	R6406	B C 1A		
C1005	A C 5A	C3017	A C 3B	C4304	A C 3B	C6609	B C 2B	IC3002	A C 2B	Q3734	B C 5A	R1089	B C 5A	R3074	A C 2A	R4807	B C 6C	R6407	B C 1A		
C1006	A C 4A	C3020	A C 2A	C4305	A C 2C	C6701	B C 2C	IC3005	A C 2B	Q3735	B C 5A	R1091	B C 4A	R3075	A C 2B	R4808	B C 5C	R6502	B C 1A		
C1007	A C 3A	C3021	A C 2A	C4306	A C 3B	C6703	B C 2C	IC3701	B C 5A	Q4801	B C 5C	R1092	A C 4B	R3081	A C 3B	R4809	B C 5C	R6503	B C 1A		
C1008	A C 3A	C3022	A C 2B	C4307	A C 3B	C6704	B C 1A	IC3731	B C 5A	Q4802	B C 5C	R1093	B C 4B	R3082	A C 3B	R4810	B C 5C	R6505	B C 1A		
C1009	A C 4B	C3023	A C 2B	C4308	A C 3C	C6801	B C 1C	IC3801	A C 5B	Q4803	B C 5B	R1094	A C 4B	R3083	A C 3B	R4811	B C 5C	R6506	B C 1A		
C1010	B C 5B	C3024	A C 2B	C4309	A C 3C	C6802	B C 1B	IC3802	B C 5B	Q4804	B C 5C	R1095	A C 5A	R3701	B C 6B	R4812	B C 5C	R6602	B C 1A		
C1011	B C 5B	C3025	A C 3A	C4310	A C 2C	C6803	B C 2C	IC3851	B C 2C	Q4805	B C 5C	R1096	A C 4A	R3702	B C 5B	R4813	B C 5C	R6603	B C 1A		
C1012	B C 5B	C3026	A C 2B	C4311	A C 2C	C6804	B C 1B	IC4201	A C 3B	Q4806	B C 5C	R1097	A C 4A	R3703	B C 5A	R4814	B C 5C	R6604	B C 1A		
C1013	B C 5B	C3027	A C 3A	C4312	A C 2B	C6805	B C 2B	IC4202	A C 3C	Q4851	A C 5C	R1099	A C 3A	R3704	B C 5B	R4815	B C 5C	R6605	B C 1A		
C1014	B C 5B	C3028	A C 2A	C4313	A C 2B	C6806	B C 1C	IC4301	A C 3C	Q6101	B C 1B	R2001	A C 4B	R3705	B C 5B	R4816	B C 5C	R6606	B C 1B		
C1015	B C 4A	C3029	A C 3A	C4314	A C 2B	C6807	B C 1B	IC4302	A C 2B	Q6102	A C 2A	R2002	A C 4B	R3706	B C 5A	R4817	B C 5C	R6607	B C 1B		
C1016	B C 4A	C3030	A C 3B	C4315	A C 2B	C6809	B C 1C	IC4303	A C 2C	Q6201	A C 1B	R2003	A C 4B	R3707	B C 5A	R4818	B C 5C	R6608	B C 1B		
C1017	B C 4A	C3031	A C 2A	C4316	A C 3C	R8001	B C 3B	IC4802	B C 6C	Q6301	A C 1A	R2004	A C 4B	R3708	B C 6A	R4819	B C 5C	R6609	B C 1B		
C1018	A C 4A	C3032	A C 3B	C4317	A C 2C	R8002	B C 4B	IC4803	B C 5C	Q6302	A C 2A	R2005	A C 4B	R3709	B C 6A	R4820	B C 5C	R6610	B C 1B		
C1019	B C 5A	C3033	A C 3B	C4318	A C 3B	R8003	B C 3C	IC4804	B C 5C	Q6303	A C 2A	R2006	A C 4B	R3710	B C 5A	R4821	B C 5C	R6611	B C 1B		
C1020	B C 4A	C3036	A C 3B	C4803	B C 6B	R8004	B C 3C	IC4807	B C 5C	Q6401	A C 1A	R2007	A C 4B	R3711	B C 5A	R4822	B C 5C	R6612	B C 1B		
C1021	B C 4A	C3037	A C 3B	C4804	B C 5B	R8005	B C 3B	IC4851	A C 5B	Q6501	A C 5B	R2008	A C 4B	R3712	B C 5A	R4823	B C 5C	R6613	B C 1B		
C1022	A C 4B	C3038	A C 3A	C4806	B C 5C	R8006	B C 3B	IC5501	A C 4B	Q6601	B C 1B	R2009	A C 3B	R3713	B C 5A	R4824	B C 5C	R6614	B C 1B		
C1024	A C 3A	C3039	A C 3A	C4807	B C 5C	R8007	B C 3A	IC6001	B C 1A	Q6602	B C 1B	R2010	A C 3B	R3714	B C 5A	R4825	B C 5B	R6615	B C 1B		
C1025	A C 4B	C3040	A C 3B	C4808	B C 5C	R8008	B C 3B	IC6801	B C 1C	Q6603	B C 1B	R2011	A C 4B	R3715	B C 5A	R4826	B C 5C	R6616	B C 1A		
C1029	A C 4A	C3042	A C 3A	C4809	B C 6C	R8010	B C 4B	IC6802	B C 2C	Q6604	B C 1B	R2012	A C 3B	R3722	B C 5B	R4827	B C 5C	R6617	B C 2B		
C1030	A C 4A	C3043	A C 3B	C4810	B C 5C	R8011	B C 3B	IC8001	B C 4B	Q6605	B C 1B	R2013	A C 4B	R3724	B C 5B	R4828	B C 5C	R6618	B C 2B		
C1032	A C 4A	C3044	A C 2A	C4811	B C 5C	R8012	B C 3B	IC8002	B C 4B	Q6606	B C 2B	R2014	A C 4B	R3725	B C 5B	R4829	B C 5C	R6619	A C 1B		
C1035	A C 4A	C3045	A C 3A	C4812	B C 5C	R8013	B C 3B	IC8003	B C 4C	Q6701	B C 2C	R2015	A C 4B	R3726	B C 5B	R4830	B C 5B	R6701	B C 2C		
C1036	B C 5B	C3046	A C 3A	C4813	B C 5C	R8014	B C 3B	IC8004	B C 4C	Q6801	B C 1B	R2016	A C 3B	R3727	B C 5B	R4831	B C 5C	R6702	B C 1A		
C1037	A C 4A	C3047	A C 3B	C4814	B C 5C	R8015	B C 4B	IC8006	B C 4B	Q6802	B C 2C	R2017	A C 3B	R3728	B C 5B	R4833	B C 5C	R6703	B C 1A		
C1038	A C 4A	C3048	A C 2A	C4815	B C 4C	R8016	B C 3B	IC8007	B C 3C	Q6803	B C 2C	R2018	A C 3B	R3730	B C 5A	R4836	B C 5C	R6704	B C 1A		
C1039	B C 4A	C3049	A C 3A	C4819	B C 5C	R8017	B C 4B	IC8301	B C 3C	Q6804	B C 1C	R2101	A C 5A	R3731	B C 5A	R4837	B C 5C	R6705	B C 1A		
C1040	A C 4A	C3050	A C 3A	C4820	B C 5C	R8018	B C 4B	IC8302	B C 3C	Q6805	B C 1C	R2102	A C 5A	R3732	B C 5A	R4839	B C 5C	R6706	B C 1A		
C1041	A C 4A	C3055	A C 3A	C4822	B C 5C	R8019	B C 4B	IC8701	B C 2B	Q6806	B C 1C	R2105	A C 5A	R3733	B C 5A	R4840	B C 5C	R6707	B C 1A		
C1042	B C 5A	C3056	A C 3B	C4823	B C 5C	R8020	B C 4B	IC8702	B C 2A	Q6807	B C 3B	R2106	A C 5B	R3734	B C 5A	R4841	B C 5B	R6708	B C 1C		
C1043	A C 4A	C3059	A C 2B	C4851	A C 4C	R8021	B C 4B	COIL		Q8002	B C 4B	R2107	A C 4B	R3735	B C 5A	R4842	B C 5C	R6802	B C 1C		
C1044	A C 4A	C3060	A C 2B	C4852	A C 5C	R8022	B C 4B	L1001	B C 4A	RESISTOR		R2108	A C 4B	R3736	B C 5A	R4843	B C 4C	R6803	B C 1C		
C1045	A C 4A	C3064	A C 3B	C4853	A C 6C	R8023	B C 4B	L1002	B C 5A	R1001	A C 4B	R2109	A C 4B	R3737	B C 5A	R4844	B C 5C	R6804	B C 2B		
C1046	B C 5B	C3066	A C 2B	C4854	A C 5C	R8024	B C 4B	L2101	A C 5B	R1002	A C 4B	R2110	A C 4B	R3738	B C 5A	R4845	B C 5C	R6805	B C 1B		
C1047	B C 5B	C3067	A C 2A	C4855	A C 6C	R8025	B C 4B	L2401	A C 5A	R1003	A C 4B	R2111	A C 4B	R3739	B C 5A	R4846	B C 5B	R6806	B C 2C		
C1048	B C 5B	C3068	A C 2A	C4858	A C 5B	R8026	B C 3B	L2402	A C 5A	R1004	A C 4B	R2112	A C 4B	R3740	B C 5A	R4847	B C 5C	R6807	B C 2C		
C1049	B C 5B	C3069	A C 2A	C4859	A C 5B	R8027	B C 3C	L2604	A C 5A	R1005	B C 4A	R2113	A C 4B	R3741	B C 5A	R4849	B C 5B	R6808	B C 2B		
C1050	B C 5B	C3070	A C 2A	C4860	A C 5B	R8028	B C 3C	L3001	A C 2A	R1006	A C 3A	R2114	A C 4B	R3742	B C 6A	R4850	B C 5C	R6809	B C 2C		
C1051	B C 4A	C3701	B C 6B	C4861	A C 5B	R8029	B C 3C	L3002	A C 2B	R1007	A C 4B	R2201	A C 5A	R3743	B C 6A	R4852	A C 5B	R6810	B C 2C		
C1052	B C 5A	C3702	B C 5B	C4862	A C 5B	R8030	B C 3B	L3004	A C 2A	R1008	B C 5A	R2202	A C 5A	R3744	B C 5A	R4854	A C 5B	R6811	B C 1C		
C1053	B C 4A	C3703	B C 5B	C4863	A C 5B	R8301	B C 2C	L3005	A C 2B	R1009	B C 5A	R2203	A C 5A	R3745	B C 5A	R4855	A C 5B	R6812	B C 1C		
C1054	B C 4A	C3704	B C 5B	C4864	A C 5C	R8305	B C 2B	L3007	A C 2B	R1010	A C 4B	R2204	A C 5A	R3746	B C 5A	R4856	A C 5B	R6813	B C 2B		
C1055	B C 5A	C3705	B C 5B	C4865	A C 5C	R8306	B C 2B	L3008	A C 3B	R1011	B C 4A	R2206	A C 5A	R3747	B C 5A	R4857	A C 5C	R6815	B C 1C		
C1056	A C 4B	C3706	B C 5A	C4866	A C 5B	R8307	B C 2B	L3012	A C 2A	R1012	A C 3A	R2207	A C 5A	R3748	B C 5A	R4858	A C 5C	R8001	B C 4B		
C1057	A C 4A	C3707	B C 5A	C5501	A C 4C	R8308	B C 2C	L3014	A C 2B	R1013	A C 3A	R2208	A C 5A	R3801	A C 5B	R4859	A C 5C	R8002	B C 4B		
C1058	A C 4A	C3708	B C 5A	C5503	A C 4C	R8309	B C 2C	L3015	A C 2B	R1014	B C 5B	R2209	A C 5A	R3802	A C 5B	R4860	A C 5C	R8003	B C 4B		
C1059	A C 4A	C3709	B C 5A	C5504	A C 4C	R8310	B C 3C	L3701	A C 6B	R1015	A C 4A	R2210	A C 5A	R3803	A C 5B	R4862	A C 5C	R8004	B C 3B		
C1060	A C 4A	C3712	B C 5A	C5506	A C 5B	R8311	B C 3C	L3731	B C 5A	R1016	A C 3A	R2211	A C 4A	R3804	A C 5B	R4863	A C 5B	R8005	B C 3B		
C1061	A C 4A	C3713	B C 5A	C5507	A C 4C	R8701	B C 2B	L3732	B C 5A	R1017	B C 5B	R2212	A C 5A	R3805	A C 5B	R4864	A C 5B	R8006	B C 3B		
C1062	A C 4A	C3714	B C 5A	C5508	A C 4B	R8702	B C 2B	L3801	A C 5B	R1018	B C 5B	R2213	A C 5A	R3806	A C 5B	R4865	A C 5B	R8007	B C 3C		
C1063	A C 4A	C3715	B C 5B	C5509	A C 4B	R8703	B C 2B	L3802	A C 5B	R1019	A C 4A	R2217	A C 5A	R3807	B C 5B	R4866	A C 5B	R8008	B C 3B		
C1064	B C 4A	C3731	B C 5A	C5510	A C 4C	R8704	B C 2A	L3803	A C 5A	R1020	A C 4A	R2218	A C 5A	R3808	B C 5B	R4867	A C 5B	R8009	B C 3C		
C1065	A C 4A	C3732	B C 5A	C5511	A C 4B	R8705	B C 2B	L3804	A C 5A	R1021	A C 4A	R2219	A C 5A	R3809	B C 5B	R4868	A C 5B	R8010	B C 3B		
C2105	A C 5A	C3733	B C 5A	C5512	A C 4B	R8706	B C 3B	L4201	A C 3C	R1022	A C 4B	R2220	A C 5A	R3851	B C 5B	R4870	A C 5C	R8016	B C 3C		
C2106	A C 5A	C3734	B C 5A	C5513	A C 4B	R8707	B C 3B	L4301	A C 2B	R1023	A C 4B	R2221	A C 5A	R3852	B C 5B	R4871	A C 5B	R8017	B C 4B		
C2107	A C 4B	C3735	B C 5A	C5514	A C 4C	R8708	B C 3B	L4302	A C 2B	R1024	A C 4A	R2222	A C 5A	R3853	B C 5B	R4872	A C 5C	R8020	B C 3C		


■ PREMDA CIRCUIT BOARD

<05> PREMDA
YB 10405-01-01




■ PREMDA CIRCUIT BOARD

<05> PREMDA
YB 10405-01-01




■ MONI-BW CIRCUIT BOARD

COMPONENT SIDE(A)



<02> MONI-BW
YB 10433

FOIL SIDE(B)




<02> MONI-BW
YB 10433

COMPONENT PARTS LOCATION GUIDE <MONI-BW> YB10433

REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION		
CAPACITOR																	
C1	A C 3C	C7827	A C 1C	C7667	B C 1B	L7601	B C 1B	R5	A C 2C	R7613	B C 3C	R7867	A C 2C	ZP1-3	B C 1A		
C10	B C 1A	C7828	B C 3C	C7668	A C 1C	L7602	B C 1B	R6	A C 1C	R7614	B C 3C	R7868	A C 2C	ZP1-4	B C 1A		
C11	B C 1A	C7829	B C 3B	C7669	A C 2C	L7603	B C 1C	R7	A C 2B	R7615	B C 3C	R7869	A C 2C	ZP1-6	B C 1B		
C7601	B C 2B	C7831	B C 4C	CONNECTOR	CN761	B C 1A	L7604	B C 4C	R8	A C 1B	R7616	B C 3C	R7870	B C 2B	ZP1-7	B C 1A	
C7602	B C 2B	C7832	B C 2C		CN762	B C 1B	L7605	B C 1A	R18	B C 1A	R7617	B C 4C	R7872	A C 2C	ZP1-8	B C 1B	
C7603	A C 2B	C7833	B C 2C		CN763	B C 1C	L7606	B C 1B	R19	B C 1A	R7618	B C 4B	R7873	A C 2C	ZP1-9	B C 1A	
C7604	B C 2B	C7834	B C 2C		CN764	B C 1C	L7607	B C 2C	R20	B C 1A	R7619	B C 3B	R7874	A C 2C	ZP2-2	B C 1A	
C7605	B C 2B	C7835	B C 2C	TRANSISTOR	CN765	B C 2B	DIODE	D10	B C 1A	R21	B C 1A	R7620	A C 1C	ZP2-3	B C 1A		
C7606	B C 2B	C7836	B C 3B		CN766	A C 1A		Q7601	B C 3C	R22	B C 1A	R7621	B C 3B	R7875	A C 2C	ZP2-4	B C 1A
C7607	B C 2B	C7837	B C 3B		Q7602	B C 4C		Q7602	B C 3C	R23	B C 1A	R7622	B C 4B	R7876	A C 2C	ZP2-5	B C 1A
C7608	B C 2B	C7841	A C 3B		Q7603	B C 4C		Q7603	B C 4C	R24	B C 1A	R7623	B C 4B	OTHER	SW2	A C 3C	ZP2-6
C7609	B C 2B	C7843	B C 1B	D10	B C 1A	Q7604	B C 4C	R25	B C 1A	R7624	B C 3B	SW3	A C 2C		ZP2-7	B C 1A	
C7613	B C 1B	C7844	B C 1B	D11	B C 1A	Q7605	B C 4B	R26	B C 1A	R7625	B C 3B	SW4	A C 1C		ZP2-8	B C 1A	
C7614	B C 1B	C7845	B C 3C	D12	B C 1A	Q7606	B C 4B	R27	B C 1A	R7626	B C 3B	SW5	A C 2C		ZP2-9	B C 1A	
C7615	B C 1B	C7846	B C 1B	D7601	B C 2C	Q7607	B C 4B	R28	A C 1A	R7627	B C 3B	SW6	A C 3B	ZP3-7	B C 1C		
C7616	B C 2B	C7847	B C 1B	D7602	B C 3C	Q7608	A C 1C	R29	A C 1A	R7628	A C 3B	SW7	A C 2B	ZP3-8	B C 1B		
C7617	B C 2B	C7851	B C 2B	D7603	A C 3B	Q7609	A C 2C	R30	A C 1A	R7629	B C 1B	SW8	A C 1B	ZP3-9	B C 1B		
C7618	B C 1B	C7854	B C 1C	IC	COIL	Q7610	A C 2C	R31	B C 2A	R7630	B C 2B	SW7601	A C 4A	ZP5-1	B C 2B		
C7619	B C 2B	C7855	B C 1C			Q7611	B C 4B	Q7611	B C 4B	R32	B C 1B	R7631	B C 2B	SW7602	A C 4A	ZP5-2	B C 2B
C7620	B C 2B	C7861	B C 2B			Q7612	B C 2B	Q7612	B C 2B	R33	B C 3B	R7632	B C 3B	TM1	A C 4A	ZP5-3	B C 1B
C7621	B C 2B	C7862	B C 2C			Q7613	B C 2C	Q7613	B C 2C	R34	B C 3B	R7633	B C 3B	TM2	A C 4A	ZP5-4	B C 2A
C7622	B C 2B	C7863	B C 2B	RESISTOR	L10	R7608	B C 2C	R7608	B C 2C	R7661	B C 1C	TM5	A C 4A	ZP11-10	B C 1A		
C7623	B C 2C	C7864	B C 2B			R7609	A C 1C	R7609	A C 1C	R7662	B C 1C	TM3	A C 4A	TM1	A C 3A	ZP11-11	B C 1A
C7624	B C 1C	C7865	B C 2C			R7610	A C 1C	R7610	A C 1C	R7663	B C 4C	TM7	A C 3A	TP7601	B C 4A	ZP11-12	B C 1A
C7625	B C 2C	C7866	A C 2C			R7611	A C 1C	R7611	A C 1C	R7664	B C 4C	TP7602	B C 4A	TP7601	B C 4A	ZP11-13	B C 1A
C7626	B C 2C	C7866	A C 2C	R4	A C 2C	R7612	B C 3C	R7612	B C 3C	R7666	A C 2C	TP7602	B C 4A	ZP11-14	B C 1A		


■ BL-2.5 CIRCUIT BOARD

COMPONENT SIDE(A)



<03> BL-2.5
YB 20938


FOIL SIDE(B)



<03> BL-2.5
YB 20938


■ JACK CIRCUIT BOARD

COMPONENT SIDE(A)



<06> JACK
YB 20943-01-01


FOIL SIDE(B)



<06> JACK
YB 20943-01-01


■ CCD CIRCUIT BOARD

COMPONENT SIDE(A)



<04> CCD
YB 20942


FOIL SIDE(B)



<04> CCD
YB 20942


■ B/W-VF CIRCUIT BOARD

COMPONENT SIDE(A)



<07> B/W-VF
YB 20940


FOIL SIDE(B)



<07> B/W-VF
YB 20940

POWER SYSTEM BLOCK DIAGRAM

5
4
3
2
1



*1 WITH ANALOG INPUT MODEL
*2 WITHOUT ANALOG INPUT MODEL
*3 WITH EDIT MODEL
*4 WITH DSC MODEL

VIDEO BLOCK DIAGRAM (1/2)


5

4

3

2

1



*1 WITH ANALOG INPUT MODEL
*2 WITHOUT ANALOG INPUT MODEL
*3 WITH EDIT MODEL
*4 WITH DSC MODEL

VIDEO BLOCK DIAGRAM (2/2)


5

4

3

2

1



A

B

C

D

2-55

2-56

E

F

G

VOLTAGE CHARTS

<MAIN IF>			<CPU>			<DV MAIN>			<VIDEO I/O>			<CDS/DSP>			<OP DRIVE>			<TG>			<REG>			<MDA>			<PRE/REC>			<MONI BW>			<BL 2.5>		<CCD>				
MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	EE	MODE PIN NO.	EE	MODE PIN NO.	EE				
Q2001			IC1001	-	-	Q1009			IC3001	-	-	IC3701			IC4201			IC4802			Q4806			IC6001			Q6303			IC3501			IC7601		Q7612				
1	0	0	IC1002			D	3	3	IC3002			1	0	0	1	1.2	0	1	3.1	3.1	E	1.2	0	1	3.1	3.1	E	0	0	1	0	0	1	2.7	E	4.8			
2	0.5	0.5				S	0	0	2	2.5	2.4	2	2.3	2.3	2	1.2	0	2	2.6	2.6	C	4.8	4.8	2	3	3	C	0.5	0.5	2	0.5	0.5	2	7.2	C	1.1			
3	3.0	3.0				G	3	3	3	0.5	0.5	3	0	0	3	0.5	0	3	2.6	2.6	B	2	0	3	3	3	B	0	0	3	0	0	3	2.4	B	4.8			
4	0	0							3	0.4	0.4	4	0	0	4	0.2	0	4	0	0	Q4851			4	3	3	Q6401			4	0	1.5	4	2.5					
5	0	0							4	1.7	1.7	5	0	0	5	0	3	5	2.6	2.6	E	0	0	5	3	3	1	8.5	8.5	5	2.5	2.5	5	2.4					
6	0	0							5	0.7	0.7	6	0	0	6	0	0	6	2.6	2.6	C	3.5	3.7	6	0	0	2	11.1	11.1	6	2.4	1.6	6	2.5					
Q2002									6	2.4	2.4	7	1.9	1.9	7	0	0	7	2.6	2.6				7	1.2	1.2	3	0	0	7	1.4	0	7	2.4					
1	0	0							7	1.2	1.2	8	0	0	8	0	0	8	4.8	4.8				8	11.1	11.1	4	2.6	2.6	8	0	0	8	2.5					
2	0	0							8	3.1	3.1	9	2.3	2.3	9	1.2	0	9	0	0				9	1	1	5	2.6	2.6	9	1.3	3.1	9	2.4					
3	0	2.9							9	3.1	3.1	10	0	0	10	3	3	10	0	0				10	1.2	1.2	Q6501			10	1.3	1.5	10	0					
4	0	0							10	3.1	3.1	11	2.1	2.1	11	0	0	11	1.3	1.3				11	2.2	2.2	1	9.7	9.7	11	3.1	3.1	11	0					
5	0.5	0							11	3.1	3.1	12	2.1	2.1	12	1.5	1.5	12	0.6	0.6				12	0	0	2	11.1	11.1	12	1.2	1.2	12	5.4					
6	0.5	0							12	2.1	2.1	13	4.8	4.8	13	3	3	13	0	0				13	0	0	3	0	0	13	1.6	1.6	13	4.8	4.8	13	0.2		
Q2003									13	1.1	1.1	14	1.9	1.9	14	2.5	0	14	2.6	2.6				14	0	0	4	1.2	1.2	14	1.5	1.5	14	0	0	14	0.2		
1	0	0							14	0	0	15	1.9	1.9	15	3	0	15	2.6	2.6				15	0	0	5	1.2	1.2	15	0	0	15	0.2					
2	0.5	0.5							15	0	0	16	4.8	4.8	16	2.4	0	16	1.6	2.8				16	0	0	Q6601			16	1.5	1.5	16	12					
3	3.0	2.3							16	3	3	17	3	3	17	2.5	0	17	4.8	4.8				17	0.1	0.1	D	11.1	11.1	17	1.6	1.6	17	0					
4	0	0							17	3	3	18	0	0	18	0	0	18	0	0				18	0	0	S	8	8	18	3.1	3.1	18	0					
5	0	0							18	1.4	1.4	19	3	3	19	3	3	19	1.3	0.3				19	2.2	2.2	G	0	0	19	0.7	0.7	19	2.5					
6	0	0							19	1.3	1.3	20	0	0	20	1.9	0	20	1.6	2.6				20	1	1	Q6602			20	0.4	0.4	20	0.1					
Q2004									20	0	0	21	1.7	1.7	21	1.9	0	21	1.6	0				21	0	0	1	4.3	4.3	21	3.8	1.7	21	6.1					
1	0	0							21	1.5	1.5	22	0	0	22	2	0	22	1.3	3.1				22	2.2	2.2	2	5.1	5.1	22	0	0	22	0					
2	0.5	0							22	0.2	0.2	23	1.9	0	23	1.9	0	23	1.5	3				23	1	1	3	14.5	14.5	23	3.8	1.6	23	0					
3	2.9	0							23	1.5	1.5	24	1.2	0	24	1.2	0	24	1.5	3				24	0.6	0.6	4	4.3	4.3	24	2.6	2.6	24	0					
4	0	0							24	0.2	0.2	25	3	3	25	3	3	25	1	0				25	1	1	5	4.8	4.8	25	3.6	1.6	25	0					
5	0	0							25	0.9	0.9	26	0	0	26	0	0	26	0.6	0.6				26	0.6	0.6	6	15.1	15.1	26	3.8	1.6	26	1.5					
6	0	0							26	0	0	27	0	0	27	0	0	27	1.5	3				27	1	1	Q6603			27	0.7	0.7	27	0					
Q2005									27	0	0	28	1.4	0	28	1.4	0	28	0.3	0.3				28	0.8	0.8	E	15.1	15.1	28	2.3	2.3	28	1.5					
1	0	0							28	1.5	1.5	29	2	0	29	2	0	29	1.5	3				29	1	1	C	12	12	29	3.6	1.7	29	0					
2	0.5	0.5							29	0.2	0.2	30	0.9	0	30	0.9	0	30	4.8	4.8				30	0.6	0.6	B	14.5	14.5	30	3.6	1.7	30	1.4					
3	2.9	2.9							30	2.4	2.4	31	3	3	31	3	3	31	0	0				31	0.3	0.3	Q6604			31	2.2	2.2	31	3.1					
4	0	0							31	0	0	32	0	0	32	0	0	32	1.5	3				32	0.3	0.3	E	0	0	32	0	0	32	3.1					
5	0	0							32	3	3	33	3	3	33	3	3	33																					



VICTOR COMPANY OF JAPAN, LIMITED

AV & MULTIMEDIA COMPANY CAMCORDER CATEGORY 12, 3-chome, Moriya-cho, kanagawa-ku, Yokohama, kanagawa-prefecture, 221-8528, Japan

(No.86733)



Printed in Japan
200304WPC

PARTS LIST

SAFETY PRECAUTION

Parts identified by the $\triangle$ symbol are critical for safety. Replace only with specified part numbers.


BEWARE OF BOGUS PARTS

Parts that do not meet specifications may cause trouble in regard to safety and performance. We recommend that genuine JVC parts be used.

1. EXPLODED VIEW



1.1 PACKING AND ACCESSORY ASSEMBLY <M1>

The instruction manual to be provided with this product will differ according to the destination.




3-2(No.86730)






<UPPER ASSEMBLY>



1.3 MECHANISM ASSEMBLY <M3>




Classification	Part No.	Symbol in drawing
Grease	KYODO-SH-JB	AA
Oil	YTU94027	BB
Grease (HANARL)	RX-410R	CC

NOTE1: The section marked in AA and BB, CC indicate lubrication and greasing areas.


NOTE2: Mark * is not contained in 900A.

1.4 ELECTRONIC VIEWFINDER ASSEMBLY <M4>



1.5 MONITOR ASSEMBLY (2.5 INCH) <M5>

500



MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

2. PARTS LIST

PACKING AND ACCESSORY ASSEMBLY <M1>

△ Symbol No.	Part No.	Part Name	Description	Local
1	LY33063-012A	PACKING CASE		A,B,C,D
1	LY33063-015A	PACKING CASE		E
1	LY33063-003A	PACKING CASE		F,G,H,J
2	LY33065-001B	CUSHION		A,B,C,D,E,F,G
2	LY33065-001C	CUSHION		H,J
3	LY30023-027A	POLY BAG		
4	YQM30061-3	POLY BAG		A,E,F
4	QPA02003506	POLY BAG	20cm x 35cm	B,C,D,G,H,J
△ 5	LYT1134-001A	INST BOOK	(ENGLISH)	E
△ 5	LYT1098-001A	INST BOOK	(ENGLISH)	A,F
△ 5	LYT1098-003A	INST BOOK	(FRENCH)	B,G
△ 5	LYT1098-004A	INST BOOK	(DUTCH)	B,G
△ 5	LYT1098-005A	INST BOOK	(SPANISH)	B,G
△ 5	LYT1098-006A	INST BOOK	(ITALIAN)	B,G
△ 5	LYT1098-002A	INST BOOK	(GERMAN)	B,C,G,H
△ 5	LYT1098-007A	INST BOOK	(DANISH)	C,H
△ 5	LYT1098-008A	INST BOOK	(FINNISH)	C,H
△ 5	LYT1098-009A	INST BOOK	(SWEDISH)	C,H
△ 5	LYT1098-010A	INST BOOK	(NORWEGIAN)	C,H
△ 5	LYT1098-011A	INST BOOK	(RUSSIAN)	D,J
△ 5	LYT1098-012A	INST BOOK	(CZECH)	D,J
△ 5	LYT1098-013A	INST BOOK	(POLISH)	D,J
△ 5	LYT1098-014A	INST BOOK	(HUNGARIAN)	D,J
6	LYT1135-001A	INST BOOK	(SOFT.ENGLISH)	E
6	LYT1086-001A	INST BOOK	(SOFT.ENGLISH)	F
6	LYT1086-003A	INST BOOK	(SOFT.FRENCH)	G
6	LYT1086-004A	INST BOOK	(SOFT.DUTCH)	G
6	LYT1086-005A	INST BOOK	(SOFT.SPANISH)	G
6	LYT1086-006A	INST BOOK	(SOFT.ITALIAN)	G
6	LYT1086-002A	INST BOOK	(SOFT.GERMAN)	G,H
6	LYT1086-007A	INST BOOK	(SOFT.DANISH)	H
6	LYT1086-008A	INST BOOK	(SOFT.FINNISH)	H
6	LYT1086-009A	INST BOOK	(SOFT.SWEDISH)	H
6	LYT1086-010A	INST BOOK	(SOFT.NORWEGIAN)	H
6	LYT1086-011A	INST BOOK	(SOFT.RUSSIAN)	J
7	BT-54008-4	WARRANTY CARD		A,E,F
7	BT-54013-5	WARRANTY CARD		B,C,D,G,H,J
8	YU30878	REGIST. CARD		E,F
9	LYT0194-001B	Q.CARD(JUK)		A,E,F
20	QPA01703005	POLY BAG	17cm x 30cm	
23	QAM0451-001	USB CABLE		F,G,H,J
24	QQR0491-002	FERRITE CORE	TDK (BLACK)	F,G,H,J
25	QAM0212-001	A/V CABLE		
26	QQR0918-002	CORE FILTER		
△ 27	LY20955-001C	AC ADAPTER	AP-V13E	
△ 27	or LY20956-001B	AC ADAPTER	AP-V11E	
28	QQR0917-002	CORE FILTER		
△ 29	QMPP110-190-JR	POWER CORD(EK)	1.9m BLACK	A,E,F
△ 29	QMPL120-190-JR	POWER CORD(EU)	1.9m BLACK	B,C,D,G,H,J
30	QPA02503505P	POLY BAG	25cm x 35cm	
△ 31	LY32566-001A	BATT.PACK ASSY	BN-V408U-B	
32	LY20186-004A	SHOULDER STRAP		
33	LY21020-001A	REMOCON	RM-V718U	
34	QQR0491-002	FERRITE CORE	TDK (BLACK)	
36	LY44002-001B	CAP(HOOD)ASSY		
37	LY32210-059A	CD ROM ASSY		E
37	LY32210-048A	CD ROM ASSY		F,G,H,J
40	QQR0491-002	FERRITE CORE	TDK (BLACK)	
41	QAM0302-001	ADAPTOR PLUG		

FINAL ASSEMBLY <M2>

△ Symbol No.	Part No.	Part Name	Description	Local
101	LY20941-007J	U.CASE(2.5)ASSY		A,B,C,D,E
101	LY20941-003J	U.CASE(2.5)ASSY		F,G,H,J
101A	LY40664-001A	SPACER	(x2)	
101E	LY33042-001A	C.LABEL(VF)		
101F	LY30030-0F2A	SPACER(A)		
102	LY30018-0D6A	SPECIAL SCREW	(x2)	
103	LY33044-001D	BKT(HINGE2.5)		

△ Symbol No.	Part No.	Part Name	Description	Local
104	LY30018-096A	SPECIAL SCREW	(x2)	
105	QAS0126-001	SPEAKER		
106	LY30018-017A	SPECIAL SCREW	(x2)	
108	LY30018-059A	SPECIAL SCREW	(x4)	
109	LY33049-002A	COVER(UPPER2.5)		
110	LY30018-056A	SPECIAL SCREW	(x2)	
111	LY30018-0E6A	SPECIAL SCREW	(x2)	
112	LY33050-002C	COVER(JIG)		
114	QUQ105-4007AA	FFC WIRE MONI CN761-MAIN CN101		
115	LY33033-001A	ORNAMENT(2.5 2)		A,B,C,D,E
115	LY33009-001A	ORNAMENT(2.5 1)		F,G,H,J
116	LY30018-0E6A	SPECIAL SCREW	(x2)	
117	LY30018-0A1A	SPECIAL SCREW		
118	LY30018-096A	SPECIAL SCREW	(x2)	
119	LY30018-096A	SPECIAL SCREW		
120	LY33025-001B	TOP COVER ASSY		
120A	LY40162-001A	BKT		
121	LY30018-096A	SPECIAL SCREW		
122	LY30018-096A	SPECIAL SCREW		
123	LY44187-006A	STICKER(2)		A,B,C,D,E
123	LY44187-004A	STICKER(2)		F,G,H,J
125	LY30018-0E6A	SPECIAL SCREW	(x2)	
126	LY30030-0E3B	SPACER(A)		
127	LY30030-0E5A	SPACER(A)		
135	LY20943-002E	F.COVER ASSY		
135A	LY33056-001B	HOOD		
135B	LY33057-001A	RING		
135C	LY33058-001A	HOOD(SCREW)		
135D	LY33059-001B	BKT(FRONT)		
135E	LY44186-002A	STICKER(1)		
135F	LY30018-0E6A	SPECIAL SCREW		
135G	LY30018-052A	SPECIAL SCREW	(x3)	
136	LY20944-001B	MIC		
137	LY30018-0G6A	SPECIAL SCREW		
△ 145	LY20938-001E	REAR UNIT		
146	LY30018-0G6A	SPECIAL SCREW	(x2)	
147	LY30018-0J1A	SPECIAL SCREW	(x2)	
148	LY30018-0H3A	SPECIAL SCREW		
155	LY20935-002E	LOWER CASE ASSY		
155A	LY33402-001A	COVER(LOWER)		
155B	LY30018-0E6A	SPECIAL SCREW	(x2)	
156	LY20939-001F	ARM ASSY		
156A	LY30002-046B	COMPRES. SPRING	(x2)	
156B	LY43973-001A	TENSION SPRING		
157	QUQ105-2203AA	FFC WIRE JACK CN501-MAIN CN102		
158	LY30018-096A	SPECIAL SCREW		
159	LY30018-059A	SPECIAL SCREW	(x2)	
160	LY30018-096A	SPECIAL SCREW	(x2)	
161	LY10453-001E	ZOOM UNIT		
162	LY30018-0E6A	SPECIAL SCREW		
163	LY33395-001A	BRACKET(ZOOM)		
164	LY30018-059A	SPECIAL SCREW		
165	LY20937-003B	C.COVER ASSY		
165A	LY33027-001B	KNOB(LOCK)		
165B	LY33028-001A	HOLDER(LOCK)		
165C	LY33397-001A	HOOK(G.B)		
165D	LY33039-001A	BKT(G.BELT)		
165E	LY20945-003A	GRIP BELT		
165F	LY44178-001A	SHEET(C.COV)		
165G	LY30018-0E6A	SPECIAL SCREW		
165H	QYSLSF2040D	TAP SCREW	2mm x 4mm(x2)	
165J	QYSLSF2040D	TAP SCREW	2mm x 4mm(x2)	
165K	QYSLSF2040D	TAP SCREW	2mm x 4mm	
165L	LY30018-0H1A	SPECIAL SCREW	(x2)	
166	LY30018-0K3A	SPECIAL SCREW	(x2)	
167	LY30018-096A	SPECIAL SCREW	(x2)	
168	LY30018-059A	SPECIAL SCREW	(x2)	
169	LY31019-001A	BASE		
170	LY30018-0E6A	SPECIAL SCREW	(x2)	
171	LY33396-001B	HOLDER(JACK)		
172	LY30018-0E6A	SPECIAL SCREW		
173	LY33037-001B	COVER(ZOOM)		
174	LY30018-084A	SPECIAL SCREW	(x3)	
175	LY33029-001B	COVER(ADJUST)		
176	LY33024-001C	COVER(JACK)		
178	LY30018-017A	SPECIAL SCREW		
191	LY33019-001B	BKT(MECHA)ASSY		

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
191A	LY42796-003A	BUSH	(x3)	
192	LY30019-028A	SPECIAL SCREW	(x3)	
193	LY30018-056A	SPECIAL SCREW	(x2)	
194	LY40699-002A	LABEL(PUSH)		
195	LY32001-002A	LABEL(HOUSING)		
196	LY33388-001C	SHIELD COVER(PR)		
197	QYSPSPT1414M	SCREW	1.4mm x 1.4mm(x2)	
198	LY30018-096A	SPECIAL SCREW	(x2)	
199	LY30019-038A	SPECIAL SCREW	(x2)	
200	LY30018-096A	SPECIAL SCREW	(x2)	
201	LY30018-017A	SPECIAL SCREW		
202	QUQ105-24X8AA	FPC WIRE OP BLOCK-MAIN CN108		
203	QAL0465-001	FPC CCD CN5001-MAIN CN107		
215	LY43965-001D	BKT(OP)ASSY		
215A	LY30030-095A	SPACER(A)		
215B	LY30030-096A	SPACER(A)		
215C	LY43966-001A	RUBBER(OP)	(x2)	
215D	LY30030-0E5A	SPACER(A)		
216	LY30018-0G9A	SPECIAL SCREW	(x2)	
217	LY30030-057A	SPACER(A)		
218	LY30030-050A	SPACER(A)		
219	LY30030-060A	SPACER(A)		
251	LY33085-001F	OP BLOCK ASSY		
251A	LY30724-001B	FOCUS MOTOR		
251B	LY30723-001B	ZOOM MOTOR		
251C	PTY33085-001	SCREW	(x7)	
251D	PTY31727-116	SCREW	(x2)	
251E	PTY33085-007	IRIS MOTOR UNIT		
252	LY44120-001A	OP LPF		
253	LY44005-001A	SHEET		
254	LY33288-001A	SPACER		
255	LYH30446-002A	CCD BASE ASSY		
256	LY30018-0E7A	SPECIAL SCREW	(x2)	
257	LY30030-093A	SPACER(A)		
258	LY30030-094A	SPACER(A)		
259	LY30029-0Q7A	SPACER(A)		

MECHANISM ASSEMBLY <M3>

△ Symbol No.	Part No.	Part Name	Description	Local
900	YMA0029H	MECHA(A)ASSY		
900A	YMA0029D	MECHA(A)ASSY		
901	LY32870-001G	CASSETTEHOUSING ASSY		
902	YQ43893-8	MINI SCREW	(x3)	
903	LYH30420-001A	UPPER BASE ASSY		
904	QYSPSPU1425M	SCREW		
905	YDV2102B	DRUM ASSY		
906	LY42820-001A	DAMP.SCREW ASSY	(x2)	
907	LY42820-002A	DAMP.SCREW ASSY		
908	LY31538-001F	REEL DISK ASSY		
909	LY31538-002H	REEL DISK ASSY		
910	YQ44246	SLIT WASHER		
911	LY10372-001D	REEL COVER ASSY		
912	LY42120-002A	MINI SCREW		
913	LY41945-003A	MINI SCREW	(x2)	
914	YQ44246	SLIT WASHER		
915	LY43725-001D	TENSION ARM ASSY		
916	LYH40269-001A	SLANT POLE ARM ASSY		
917	LY43731-001F	TU ARM ASSY		
918	LY31531-001D	SWING ARM ASSY		
919	YQ43893	MINI SCREW		
920	LYH30424-001A	SLIDE DECK FINAL ASSY		
921	YQ43893	MINI SCREW	(x2)	
922	LY43023-001A	MINI SCREW		
924	LYH30419-001A	PAD ARM ASSY		
925	YQ44246	SLIT WASHER		
928	LYH40270-001A	TU BRAKE ASSY		
929	YQ44246	SLIT WASHER		
930	LY43684-001A	TENSION CONTROL LEVER ASSY		
931	LY32861-001A	CENTER GEAR		
932	LY31516-001F	PINCH ROLLER ARM FINAL ASSY		
933	YQ44246	SLIT WASHER		
934	LY43681-001A	TENSION CONTROL PLATE ASSY		
935	LY43687-001A	BRAKE CONTROL LEVER ASSY		
936	LYH30421-001A	MOTOR BRACKET ASSY		

△ Symbol No.	Part No.	Part Name	Description	Local
936A	QAR0138-001	LOADING MOTOR		
936B	LY41940-001A	TAPPING SCREW	(x2)	
937	YQ43893	MINI SCREW	(x3)	
938	LYH30422-001A	GUIDE RAIL ASSY		
939	YQ43893	MINI SCREW		
940	YQ44246	SLIT WASHER	(x2)	
941	LY32843-001A	SLIDE LEVER2 ASSY		
942	LY43690-001A	LOADING PLATE ASSY		
943	YQ44246	SLIT WASHER		
944	LY32858-001A	EJECT LEVER		
945	YQ44246	SLIT WASHER		
946	LYH40271-001A	BASE R ASSY		
947	YQ43893	MINI SCREW		
948	LY41945-001B	MINI SCREW		
949	LY43665-001A	MODE GEAR		
950	QSW0876-003	ROTARY ENCODER		
951	YQ43893	MINI SCREW	(x2)	
952	LY32860-001A	GEAR COVER ASSY		
953	YQ43893	MINI SCREW	(x2)	
954	YQ43893-4	MINI SCREW		
955	LY43676-001A	MAIN CAM ASSY		
956	LY41941-001B	SLIDE ARM ASSY		
957	LY43678-001A	CONNECT GEAR 2		
958	LY41954-001C	SUB CAM ASSY		
959	LY42120-001A	MINI SCREW		
960	LY43692-001A	CONTROL ARM ASSY		
961	LY32859-001A	REEL GEAR 1		
962	LY31508-002B	DRUM BASE ASSY		
963	QYSPSPU1425M	SCREW	1.4mm x 2.5mm(x3)	
964	QAR0142-001	CAPSTAN MOTOR		
965	YQ43893	MINI SCREW		
966	LY10367-001D	MAIN DECK ASSY		
976	YQ44246	SLIT WASHER		
977	YQ44246-6	SLIT WASHER		
978	LY42047-005A	WASHER		
979	LY43987-001B	SPACER		

ELECTRONIC VIEWFINDER ASSEMBLY<M4>

△ Symbol No.	Part No.	Part Name	Description	Local
300	LY21043-001E	VF ASSY		
301	LY32995-001B	EYE CUP		
302	LY43961-001B	SHEET(LENS)		
303	LY32472-001A	LENS ASSY		
304	LY43868-001A	SPRING(LENS)		
305	LY32993-001C	GUIDE LENS(VF)		
306	LY33006-001C	LEVER(LENS)		
307	LY33442-001B	LCD UNIT ASSY		
308	LY20931-001B	U.CASE(VF)R		
309	LY20930-001B	U.CASE(VF)F		
310	LY33083-001A	PROTECTOR(VF)	(x2)	
311	QAL0466-002	FPC		
312	NSW0200-001X	LEVER SWITCH VF SW		
313	LY30030-059B	SPACER(A)		
314	LY30018-031A	SPECIAL SCREW	(x2)	
315	LY32996-001B	COVER(VF)		
316	LY30018-022A	SPECIAL SCREW	(x6)	
317	LY20929-001C	B.CASE(VF)		
318	LY33076-001E	VF HINGE ASSY		
318A	LY43962-001C	TOR.SPRING		
318B	LY30019-048A	SPECIAL SCREW		
319	LY30018-084A	SPECIAL SCREW	(x7)	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

MONITOR ASSEMBLY (2.5 INCH) <M5>

△ Symbol No.	Part No.	Part Name	Description	Local
500	LY21042-004B	MONITOR ASSY		
501	LY20932-003E	M.COVER(2.5)ASSY		
501A	LY33007-001C	KNOB(LOCK)M		
501B	LY33008-001A	HOLDER(LOCK)M		
501C	LY30002-047A	COMPRES. SPRING		
501D	LY30018-0C8A	SPECIAL SCREW	(x2)	
501E	LY30030-0E5A	SPACER(A)		
502	LY10407-001C	MONI.CASE(2.5)		
503	QYSPSPT1730R	SCREW	1.7mm x 3mm(x2)	
504	LY30018-0K9A	SPECIAL SCREW	(x2)	
506	LY33011-001C	LCD FRAME(2.5)		
507	QLD0262-001	LCD MODULE		
508	LY30029-0R5A	SPACER(A)	(x3)	
510	LY33010-001A	SHIELD CASE(2.5)		
512	QYSPSPT1720R	SCREW	1.7mm x 2mm	
513	LY33012-001A	DIFF.SHEET(2.5)		
514	LY43938-001A	LIGHT SCREEN		
515	LY33013-003B	MONI.HINGE ASSY		
515A	LY33015-002A	HINGE COVER(U)		
515B	LY32969-002A	HINGE COVER(L)		
515C	LY30018-0K1A	SPECIAL SCREW	(x2)	
516	LY43936-001A	HOLDER(LAMP)	(x2)	
517	LY43396-001A	SHEET(REFLECT)		
518	QLL0142-001	LAMP		

MAIN BOARD ASSEMBLY <01>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	YB10404J-02	MAIN BOARD ASSY		A,B,C,D,E
PW1	YB10404K-02	MAIN BOARD ASSY		F,G,H,J
IC1001	MN103S33NJD	IC(MICRO C ROM)		
IC1001 or	MN103SF33NY4JD	IC(MICRO C ROM)		
IC1002	MB90097PFV149-X	IC(MICRO C ROM)		
IC1003	SN74AHC1G00K-X	IC		
IC1003 or	SN74AHC1G00DC-X	IC		
IC1004	S-89220ACNC-W	IC		
IC1005	X25330S8I-2.5-X	IC		
IC1005 or	AT25320N-10SI-X	IC		
IC1005 or	M95320-WMN6-X	IC		
IC1005 or	25LC320-I/SN-X	IC		
IC1005 or	CAT25C32SI-X	IC		
IC1006	RS5C314-X	IC		
IC1007	IC-PST3423U-X	IC		
IC1007 or	S-80823CNNB-X	IC		
IC2101	AK5355VT-X	IC		F,G,H,J
IC2201	AK4564VQ	IC		
IC3001	JCY0152	IC		
IC3002	BU2501FV-X	IC		
IC3005	JCY0136-X	IC		
IC3701	BA7665FS-X	IC		
IC3851	JCP8055FP	IC		
IC4201	HD49340NP-X	IC		
IC4202	MM1613AN-X	IC		
IC4301	JCY0200	IC		
IC4302	R1160N151B-X	IC		
IC4802	BA10358FVM-W	IC		
IC4803	BA10358FVM-W	IC		
IC4804	UPC358G2/5/-W	IC		
IC4851	UPD16879GS-X	IC		
IC5501	JCY0185	IC		
IC6001	FA3698F	IC		
IC6801	R1224N102G-X	IC		
IC8701	PIX-MC10	IC		F,G,H,J
IC8702	MT48LC1M16TG-6S	IC		F,G,H,J
Q1001	DTA114EE-X	DIGI TRANSISTOR		
Q1001 or	PDTA114EE-X	DIGI TRANSISTOR		
Q1001 or	RN2102-X	DIGI TRANSISTOR		
Q1001 or	BCR183T-X	DIGI TRANSISTOR		
Q1002	UMC3N-W	DIGI TRANSISTOR		
Q1003	UMC3N-W	DIGI TRANSISTOR		
Q1004	UMC3N-W	DIGI TRANSISTOR		
Q1005	DTC143XE-X	DIGI TRANSISTOR		
Q1006	UMC3N-W	DIGI TRANSISTOR		
Q1007	2SC4617/QR/-X	TRANSISTOR		
Q1007 or	BC847BT-X	TRANSISTOR		
Q1008	DTC124EE-X	DIGI TRANSISTOR		
Q1008 or	PDTC124EE-X	DIGI TRANSISTOR		
Q1008 or	BCR141T-X	DIGI TRANSISTOR		
Q1009	2SJ347-X	MOS FET		
Q2001	UMX1N-W	PAIR TRANSISTOR		
Q2001 or	BC847S-X	PAIR TRANSISTOR		
Q2002	UMX1N-W	PAIR TRANSISTOR		
Q2002 or	BC847S-X	PAIR TRANSISTOR		
Q2003	UMX1N-W	PAIR TRANSISTOR		
Q2003 or	BC847S-X	PAIR TRANSISTOR		
Q2004	UMX1N-W	PAIR TRANSISTOR		
Q2004 or	BC847S-X	PAIR TRANSISTOR		
Q2005	UMX1N-W	PAIR TRANSISTOR		
Q2005 or	BC847S-X	PAIR TRANSISTOR		
Q2006	UMX1N-W	PAIR TRANSISTOR		
Q2006 or	BC847S-X	PAIR TRANSISTOR		
Q2202	UMX1N-W	PAIR TRANSISTOR		
Q2202 or	BC847S-X	PAIR TRANSISTOR		
Q2401	2SC4617/QR/-X	TRANSISTOR		
Q2401 or	BC847BT-X	TRANSISTOR		
Q2403	2SC4617/QR/-X	TRANSISTOR		
Q2403 or	BC847BT-X	TRANSISTOR		
Q3001	2SC4617/RS/-X	TRANSISTOR		
Q3001 or	BC847BT-X	TRANSISTOR		
Q3002	2SC4617/RS/-X	TRANSISTOR		
Q3002 or	BC847BT-X	TRANSISTOR		
Q3701	UMT1N-W	PAIR TRANSISTOR		

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
Q3701	or XP4401-W	TRANSISTOR		
Q3701	or BC856S-X	PAIR TRANSISTOR		
Q3702	UMZ1N-W	PAIR TRANSISTOR		
Q3702	or XP4601-W	TRANSISTOR		
Q3704	2SA1774/RS/-X	TRANSISTOR		
Q3704	or BC857BT-X	TRANSISTOR		
Q3705	UMT1N-W	PAIR TRANSISTOR		
Q3705	or XP4401-W	TRANSISTOR		
Q3705	or BC856S-X	PAIR TRANSISTOR		
Q4801	2SC4655/BC/-X	TRANSISTOR		
Q4806	2SC4617/QR/-X	TRANSISTOR		
Q4806	or BC847BT-X	TRANSISTOR		
Q4851	2SC4617/RS/-X	TRANSISTOR		
Q4851	or BC847BT-X	TRANSISTOR		
Q6101	SSM5G01TU-X	MOS FET		
Q6102	2SA1577/QR/-X	TRANSISTOR		
Q6102	or BC807-25W-X	TRANSISTOR		
Q6201	SSM5G01TU-X	MOS FET		
Q6301	SSM5G01TU-X	MOS FET		
Q6302	2SA1577/QR/-X	TRANSISTOR		
Q6302	or BC807-25W-X	TRANSISTOR		
Q6303	2SC4617/QR/-X	TRANSISTOR		
Q6303	or BC847BT-X	TRANSISTOR		
Q6401	SSM5G01TU-X	MOS FET		
Q6501	SSM5G01TU-X	MOS FET		
Q6601	CPH3314-X	MOS FET		
Q6602	UMX1N-W	PAIR TRANSISTOR		
Q6602	or HN1C01FU/G/-X	PAIR TRANSISTOR		
Q6602	or BC847S-X	PAIR TRANSISTOR		
Q6603	2SA1577/QR/-X	TRANSISTOR		
Q6603	or BC807-25W-X	TRANSISTOR		
Q6604	DTC144EE-X	DIGI TRANSISTOR		
Q6604	or BCR148T-X	DIGI TRANSISTOR		
Q6605	UMT1N-W	PAIR TRANSISTOR		
Q6605	or HN1A01FU/G/-X	PAIR TRANSISTOR		
Q6605	or BC856S-X	PAIR TRANSISTOR		
Q6606	2SC4617/QR/-X	TRANSISTOR		
Q6606	or BC847BT-X	TRANSISTOR		
Q6701	CPH3314-X	MOS FET		
Q6801	FML9-W	TRANSISTOR		
D1001	DA221-X	DIODE ARRAY		
D3001	EC2C01C-X	VARI CAP DIODE		
D3002	EC2C01C-X	VARI CAP DIODE		
D3003	EC2C01C-X	VARI CAP DIODE		
D3004	MA2Z720-X	SB DIODE		
D5501	1SS355-X	SI DIODE		
D6601	RB481K-X	SB DIODE		
D6602	RB480Y-W	SB DIODE		
D6701	RB160M-30-X	SB DIODE		
D6702	RB160M-30-X	SB DIODE		
△ D6801	RB715F-X	SB DIODE		
D8702	EMZ6.8N-X	Z DIODE		F,G,H,J
D8703	EMZ6.8N-X	Z DIODE		F,G,H,J
C1001	NDCA1HJ-8R0W	C CAPACITOR	8pF 50V J	
C1002	NDCA1HJ-100W	C CAPACITOR	10pF 50V J	
C1004	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1005	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1007	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1008	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1009	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1010	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1011	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1012	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1013	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1014	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1015	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1019	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1020	NCBA1EK-682W	C CAPACITOR	6800pF 25V K	
C1021	NCBA1EK-682W	C CAPACITOR	6800pF 25V K	
C1022	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1024	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1025	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1029	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1030	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C1032	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1035	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	

△ Symbol No.	Part No.	Part Name	Description	Local
C1036	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1037	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1038	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1039	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1040	NDCA1HJ-100W	C CAPACITOR	10pF 50V J	
C1041	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1042	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1043	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1044	NDCA1HJ-470W	C CAPACITOR	47pF 50V J	
C1045	NDCA1HJ-470W	C CAPACITOR	47pF 50V J	
C1046	NCF31AZ-105X	C CAPACITOR	1uF 10V Z	
C1047	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1048	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1049	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1050	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1051	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C1052	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C1053	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C1054	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C1055	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1064	NBE20JM-226X	TA E CAPACITOR	22uF 6.3V M	
C2105	NCBA1HK-222W	C CAPACITOR	2200pF 50V K	F,G,H,J
C2106	NCBA1HK-222W	C CAPACITOR	2200pF 50V K	F,G,H,J
C2107	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	F,G,H,J
C2108	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C2109	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C2110	NBE20JM-475X	TA E CAPACITOR	4.7uF 6.3V M	F,G,H,J
C2201	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2202	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2203	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2204	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2205	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2209	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2210	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2211	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2212	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2213	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2214	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2215	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2216	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2217	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2218	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2223	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2224	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2401	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2402	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2403	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2404	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2405	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2406	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2603	NCBA1CK-153W	C CAPACITOR	0.015uF 16V K	
C2604	NCBA1CK-153W	C CAPACITOR	0.015uF 16V K	
C2605	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C2606	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C2607	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C2608	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C2611	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2612	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2613	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2614	NDCA1HJ-101W	C CAPACITOR	100pF 50V J	
C2615	NDCA1HJ-101W	C CAPACITOR	100pF 50V J	
C3001	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3003	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3005	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3006	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3007	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C3008	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3009	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3011	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3012	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3013	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3015	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3016	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3017	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3020	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3021	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3022	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3023	NDCA1HJ-330W	C CAPACITOR	33pF 50V J	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local	△ Symbol No.	Part No.	Part Name	Description	Local
C3024	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		C4307	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3025	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4308	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3026	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C4309	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3027	NCBA1EK-472W	C CAPACITOR	4700pF 25V K		C4310	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3028	NDCA1EJ-271W	C CAPACITOR	270pF 25V J		C4311	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3029	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4312	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3030	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4313	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3031	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4314	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3032	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		C4315	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3033	NDCA1HJ-220W	C CAPACITOR	22pF 50V J		C4316	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3036	NDCA1HJ-8R0W	C CAPACITOR	8pF 50V J		C4317	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3037	NDCA1HJ-8R0W	C CAPACITOR	8pF 50V J		C4803	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3038	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4804	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3039	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4806	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3042	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4808	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3043	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4809	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3044	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4810	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3045	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4811	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3046	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4812	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3047	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4813	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3048	NCB31CK-473X	C CAPACITOR	0.047uF 16V K		C4814	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3049	NCBA1HK-222W	C CAPACITOR	2200pF 50V K		C4815	NCB31HK-152X	C CAPACITOR	1500pF 50V K	
C3050	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4819	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C3055	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4851	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3059	NBE20GM-226X	TA E CAPACITOR	22uF 4V M		C4852	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3060	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4853	NBE21AM-335X	TA E CAPACITOR	3.3uF 10V M	
C3064	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		C4854	NBE21AM-106X	TA E CAPACITOR	10uF 10V M	
C3066	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C4855	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C3067	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		C4858	NDCA1HJ-330W	C CAPACITOR	33pF 50V J	
C3069	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4859	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C3701	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C4860	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C3702	NDCA1HJ-560W	C CAPACITOR	56pF 50V J		C4861	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3703	NDCA1HJ-270W	C CAPACITOR	27pF 50V J		C4862	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3704	NDCA1HJ-680W	C CAPACITOR	68pF 50V J		C4864	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3705	NDCA1HJ-270W	C CAPACITOR	27pF 50V J		C4865	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3706	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C5501	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3707	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5503	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3708	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C5504	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3709	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5506	NBE40GM-476X	TA E CAPACITOR	47uF 4V M	
C3712	NEA70GM-337X	E CAPACITOR	330uF 4V M		C5507	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3713	NEA70GM-337X	E CAPACITOR	330uF 4V M		C5508	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3715	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5509	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3801	NCB21AK-105X	C CAPACITOR	1uF 10V K		C5510	NBP21VM-105X	TA E CAPACITOR	1uF 35V M	
C3802	NCB21AK-105X	C CAPACITOR	1uF 10V K		C5511	NBZ0003-475X	TA E CAPACITOR	4.7uF 20V M	
C3803	NBE20GM-476X	TA E CAPACITOR	47uF 4V M		C5512	NBE21AM-106X	TA E CAPACITOR	10uF 10V M	
C3804	NBE20GM-476X	TA E CAPACITOR	47uF 4V M		C5513	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C3851	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5514	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3852	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5515	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3853	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5516	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3854	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5517	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C3855	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C5518	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3856	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5519	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3857	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6002	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C3858	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6003	NEA71CM-106X	E CAPACITOR	10uF 16V M	
C3859	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C6004	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C3860	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6021	NCB21CK-104X	C CAPACITOR	0.1uF 16V K	
C3861	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C6022	NCB21CK-104X	C CAPACITOR	0.1uF 16V K	
C4201	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C6023	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4202	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6024	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4203	NCB21AK-105X	C CAPACITOR	1uF 10V K		C6025	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4204	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6026	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4205	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6027	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C4206	NCB21CK-105X	C CAPACITOR	1uF 16V K		C6029	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4207	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6030	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4208	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C6031	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4209	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6032	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4210	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6033	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C4211	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6034	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4212	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6035	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4213	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6036	NDCA1HJ-101W	C CAPACITOR	100pF 50V J	
C4214	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6037	NCB21CK-473X	C CAPACITOR	0.047uF 16V K	
C4216	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6038	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C4301	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6039	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4302	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6040	NCB31CK-473X	C CAPACITOR	0.047uF 16V K	
C4303	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6041	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C4304	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6042	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C4305	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6043	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C4306	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6044	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local	△ Symbol No.	Part No.	Part Name	Description	Local
C6045	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1038	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
C6101	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1039	NRSA6AJ-152W	MG RESISTOR	1.5kΩ 1/16W J	
C6103	NCB10JK-106X	C CAPACITOR	10uF 6.3V K		R1040	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
C6104	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		R1041	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
C6105	NCBA1HK-561W	C CAPACITOR	560pF 50V K		R1042	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
C6106	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1043	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
C6201	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1044	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
C6203	NCB10JK-106X	C CAPACITOR	10uF 6.3V K		R1045	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
C6204	NCBA1EK-472W	C CAPACITOR	4700pF 25V K		R1046	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
C6301	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1047	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
C6303	NCB10JK-106X	C CAPACITOR	10uF 6.3V K		R1048	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
C6304	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		R1049	NRSA6AJ-623W	MG RESISTOR	62kΩ 1/16W J	
C6401	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1050	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
C6403	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1051	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
C6405	NCB31CK-683X	C CAPACITOR	0.068uF 16V K		R1052	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
C6501	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1053	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
C6503	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1054	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
C6505	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1055	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
C6601	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1056	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
C6602	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1057	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
C6603	NCB11EK-105X	C CAPACITOR	1uF 25V K		R1058	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
C6605	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1059	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
C6606	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1060	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
C6607	NCB11EK-105X	C CAPACITOR	1uF 25V K		R1061	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J	
C6608	NCB31CK-104X	C CAPACITOR	0.1uF 16V K		R1062	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	
C6609	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1063	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
C6701	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1064	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
C6703	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1065	NRSA6AJ-153W	MG RESISTOR	15kΩ 1/16W J	
C6801	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1066	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
C6802	NBE40JM-476X	TA E CAPACITOR	47uF 6.3V M		R1067	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
C6804	NCB21CK-105X	C CAPACITOR	1uF 16V K		R1068	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
C6807	NCB10JK-106X	C CAPACITOR	10uF 6.3V K		R1069	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
C6809	NDCA1HJ-151W	C CAPACITOR	150pF 50V J		R1070	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J	
C8701	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	F,G,H,J	R1071	NRSA6AJ-272W	MG RESISTOR	2.7kΩ 1/16W J	
C8702	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	F,G,H,J	R1072	NRSA6AJ-183W	MG RESISTOR	18kΩ 1/16W J	
C8703	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J	R1073	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
C8704	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J	R1074	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
C8705	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J	R1075	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
C8706	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J	R1076	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
C8707	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J	R1077	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
C8708	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J	R1078	NRSA6AJ-393W	MG RESISTOR	39kΩ 1/16W J	
C8709	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J	R1079	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J	
C8710	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J	R1080	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J	
C8711	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J	R1081	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
C8712	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J	R1082	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J	
C8719	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J	R1083	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1001	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J		R1084	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1002	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R1085	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1003	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R1086	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1006	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R1087	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1007	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R1088	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1008	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R1089	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1009	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R1091	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1010	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R1092	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1011	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R1093	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1012	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R1094	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1013	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R1095	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1014	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R1096	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1015	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R1097	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1016	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R1099	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1017	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J		R2001	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1018	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J		R2002	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1019	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R2003	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1020	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R2004	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1021	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R2005	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1022	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R2006	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1023	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R2007	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1024	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R2008	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1025	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J		R2009	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1027	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R2010	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1030	NRSA6AJ-753W	MG RESISTOR	75kΩ 1/16W J		R2011	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1031	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J		R2012	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1032	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R2101	NRSA6AJ-471W	MG RESISTOR	470Ω 1/16W J	F,G,H,J
R1033	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R2102	NRSA6AJ-471W	MG RESISTOR	470Ω 1/16W J	F,G,H,J
R1034	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R2105	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R1035	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R2107	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R1037	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J		R2108	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
					R2109	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local	△ Symbol No.	Part No.	Part Name	Description	Local
R2110	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J	R3705	NRSA6AD-301W	MG RESISTOR	300Ω 1/16W D	
R2201	NRSA6AJ-684W	MG RESISTOR	680kΩ 1/16W J		R3706	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R2202	NRSA6AJ-564W	MG RESISTOR	560kΩ 1/16W J		R3707	NRSA6AD-680W	MG RESISTOR	68Ω 1/16W D	
R2203	NRSA6AJ-393W	MG RESISTOR	39kΩ 1/16W J		R3708	NRSA6AD-680W	MG RESISTOR	68Ω 1/16W D	
R2204	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J		R3709	NRSA6AD-680W	MG RESISTOR	68Ω 1/16W D	
R2206	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J		R3710	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R2207	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J		R3711	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R2208	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J		R3712	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R2209	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J		R3713	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R2210	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3714	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
R2211	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3715	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R2212	NRSA6AJ-2R7W	MG RESISTOR	2.7Ω 1/16W J		R3722	NRSA6AD-131W	MG RESISTOR	130Ω 1/16W D	
R2213	NRSA6AJ-2R7W	MG RESISTOR	2.7Ω 1/16W J		R3724	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R2217	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R3725	NRSA6AD-131W	MG RESISTOR	130Ω 1/16W D	
R2218	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R3726	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R2219	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3727	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R2220	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3728	NRSA6AD-131W	MG RESISTOR	130Ω 1/16W D	
R2221	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3730	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R2222	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R3807	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R2223	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R3851	NRSA6AJ-101W	MG RESISTOR	100Ω 1/16W J	
R2224	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R3852	NRSA6AD-821W	MG RESISTOR	820Ω 1/16W D	
R2225	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3853	NRSA6AD-273W	MG RESISTOR	27kΩ 1/16W D	
R2226	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3854	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D	
R2229	NRSA6AJ-564W	MG RESISTOR	560kΩ 1/16W J		R3855	NRSA6AD-821W	MG RESISTOR	820Ω 1/16W D	
R2230	NRSA6AJ-564W	MG RESISTOR	560kΩ 1/16W J		R4201	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R2231	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R4202	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2401	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R4203	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2402	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R4204	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R2403	NRSA6AJ-183W	MG RESISTOR	18kΩ 1/16W J		R4205	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R2406	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4301	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R2407	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R4303	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2601	NRSA6AJ-182W	MG RESISTOR	1.8kΩ 1/16W J		R4304	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2602	NRSA6AJ-182W	MG RESISTOR	1.8kΩ 1/16W J		R4306	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2607	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R4307	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R2608	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R4308	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R2609	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J		R4309	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2610	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J		R4310	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3002	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4315	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3004	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4317	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3005	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R4319	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3006	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R4321	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3007	NRSA6AJ-562W	MG RESISTOR	5.6kΩ 1/16W J		R4326	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R3008	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R4327	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3009	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4328	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3010	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4329	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3011	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J		R4330	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3013	NRSA6AJ-242W	MG RESISTOR	2.4kΩ 1/16W J		R4331	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3014	NRSA6AJ-392W	MG RESISTOR	3.9kΩ 1/16W J		R4332	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3015	NRSA6AJ-392W	MG RESISTOR	3.9kΩ 1/16W J		R4333	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3016	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D		R4334	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3017	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D		R4335	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3018	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D		R4336	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3019	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D		R4337	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3020	NRVA6AD-512W	CMF RESISTOR	5.1kΩ 1/16W D		R4338	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R3021	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4339	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3025	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R4341	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3027	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4342	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3029	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J		R4343	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3030	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J		R4344	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3031	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J		R4345	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R3032	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J		R4346	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R3034	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R4348	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3036	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4349	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3037	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J		R4350	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3057	NRSA6AJ-151W	MG RESISTOR	150Ω 1/16W J		R4351	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3066	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J		R4352	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3067	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J		R4353	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3068	NRSA6AJ-181W	MG RESISTOR	180Ω 1/16W J		R4354	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3069	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R4355	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3071	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4356	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3074	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4804	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R3081	NRSA6AJ-471W	MG RESISTOR	470Ω 1/16W J	F,G,H,J	R4805	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R3082	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	A,B,C,D,E	R4806	NRSA6AJ-683W	MG RESISTOR	68kΩ 1/16W J	
R3083	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J	R4807	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
R3701	NRSA6AD-271W	MG RESISTOR	270Ω 1/16W D		R4808	NRSA6AJ-243W	MG RESISTOR	24kΩ 1/16W J	
R3702	NRSA6AD-271W	MG RESISTOR	270Ω 1/16W D		R4809	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J	
R3703	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R4810	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R3704	NRSA6AD-301W	MG RESISTOR	300Ω 1/16W D		R4811	NRSA6AJ-824W	MG RESISTOR	820kΩ 1/16W J	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
R4812	NRSA6AJ-153W	MG RESISTOR	15kΩ 1/16W J	
R4814	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R4815	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R4816	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R4817	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
R4818	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J	
R4819	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R4820	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R4821	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R4822	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R4823	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4824	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R4827	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4828	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4833	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R4836	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4841	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4842	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4843	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4844	NRSA6AJ-151W	MG RESISTOR	150Ω 1/16W J	
R4854	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4856	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R4857	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R4858	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R4859	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4860	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4862	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R4863	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R4864	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4865	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4866	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4867	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4868	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4870	NRSA6AJ-271W	MG RESISTOR	270Ω 1/16W J	
R4871	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4874	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4875	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R5501	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R5503	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R5504	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R5505	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R5506	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R5507	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R5509	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R5511	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R5512	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R5513	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R5514	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6021	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6022	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6023	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6024	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6025	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6026	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6027	NRSA6AD-103W	MG RESISTOR	10kΩ 1/16W D	
R6028	NRSA6AD-751W	MG RESISTOR	750Ω 1/16W D	
R6029	NRSA6AD-103W	MG RESISTOR	10kΩ 1/16W D	
R6030	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R6031	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R6033	NRSA6AJ-562W	MG RESISTOR	5.6kΩ 1/16W J	
R6034	NRSA6AJ-153W	MG RESISTOR	15kΩ 1/16W J	
R6035	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6036	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6037	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D	
R6038	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6039	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6040	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R6042	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R6044	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	
R6102	NRVA6AD-223W	CMF RESISTOR	22kΩ 1/16W D	
R6103	NRVA6AD-103W	CMF RESISTOR	10kΩ 1/16W D	
R6104	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R6105	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6106	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R6107	NRSA6AD-183W	MG RESISTOR	18kΩ 1/16W D	
R6108	NRSA6AD-123W	MG RESISTOR	12kΩ 1/16W D	
R6109	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R6202	NRSA6AD-123W	MG RESISTOR	12kΩ 1/16W D	

△ Symbol No.	Part No.	Part Name	Description	Local
R6203	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D	
R6302	NRSA6AD-183W	MG RESISTOR	18kΩ 1/16W D	
R6303	NRSA6AD-472W	MG RESISTOR	4.7kΩ 1/16W D	
R6305	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6306	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J	
R6308	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R6309	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R6402	NRSA6AD-243W	MG RESISTOR	24kΩ 1/16W D	
R6403	NRSA6AD-302W	MG RESISTOR	3kΩ 1/16W D	
R6405	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J	
R6406	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R6407	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6502	NRSA6AD-473W	MG RESISTOR	47kΩ 1/16W D	
R6503	NRSA6AD-562W	MG RESISTOR	5.6kΩ 1/16W D	
R6505	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R6506	NRSA6AJ-273W	MG RESISTOR	27kΩ 1/16W J	
R6602	NRSA6AD-114W	MG RESISTOR	110kΩ 1/16W D	
R6603	NRSA6AD-392W	MG RESISTOR	3.9kΩ 1/16W D	
R6604	NRSA6AD-114W	MG RESISTOR	110kΩ 1/16W D	
R6605	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R6606	NRSA6AD-104W	MG RESISTOR	100kΩ 1/16W D	
R6607	NRSA6AD-473W	MG RESISTOR	47kΩ 1/16W D	
R6608	NRSA6AJ-273W	MG RESISTOR	27kΩ 1/16W J	
R6609	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J	
R6610	NRSA6AD-473W	MG RESISTOR	47kΩ 1/16W D	
R6611	NRSA6AD-683W	MG RESISTOR	68kΩ 1/16W D	
R6612	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6613	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
R6614	NRSA6AD-104W	MG RESISTOR	100kΩ 1/16W D	
R6615	NRSA6AD-104W	MG RESISTOR	100kΩ 1/16W D	
R6616	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R6617	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R6618	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6619	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R6701	NRZ0058-R20X	MG RESISTOR	0.2Ω 1/2W J	
R6702	NRSA6AD-114W	MG RESISTOR	110kΩ 1/16W D	
R6703	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D	
R6704	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	
R6706	NRSA6AD-823W	MG RESISTOR	82kΩ 1/16W D	
R6707	NRSA6AD-333W	MG RESISTOR	33kΩ 1/16W D	
R6801	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6803	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6804	NRVA6AD-563W	CMF RESISTOR	56kΩ 1/16W D	
△ R6805	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6813	NRVA6AD-273W	CMF RESISTOR	27kΩ 1/16W D	
R6815	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J	
R8059	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	A,B,C,D,E
R8701	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8702	NRS181J-220X	MG RESISTOR	22Ω 1/8W J	F,G,H,J
R8703	NRS181J-220X	MG RESISTOR	22Ω 1/8W J	F,G,H,J
R8704	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	F,G,H,J
R8705	NRSA6AJ-152W	MG RESISTOR	1.5kΩ 1/16W J	F,G,H,J
R8706	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	F,G,H,J
R8707	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8708	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8709	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	F,G,H,J
R8710	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8711	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8712	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8713	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8715	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8716	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8717	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8718	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8720	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8721	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8722	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	F,G,H,J
R8723	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	F,G,H,J
R8724	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
RA1001	NRZ0034-473W	NET RESISTOR	47kΩ 1/32W J	
RA1002	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J	
RA1004	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J	
RA1005	NRZ0034-103W	NET RESISTOR	10kΩ 1/32W J	
RA1006	NRZ0034-102W	NET RESISTOR	1kΩ 1/32W J	
RA1007	NRZ0034-102W	NET RESISTOR	1kΩ 1/32W J	
RA1008	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J	
RA3001	NRZ0034-560W	NET RESISTOR	56Ω 1/32W J	
RA3002	NRZ0034-560W	NET RESISTOR	56Ω 1/32W J	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
RA3003	NRZ0034-100W	NET RESISTOR	10Ω 1/32W J	
RA3004	NRZ0034-103W	NET RESISTOR	10kΩ 1/32W J	
RA3005	NRZ0040-0R0X	NET RESISTOR	0Ω 1/16W J	
L1001	NQL402M-100X	COIL	10uH M	F,G,H,J
L1002	NQL402M-100X	COIL	10uH M	
L2101	NQL315K-100X	COIL	10uH K	
L2401	NQL402M-100X	COIL	10uH M	
L2402	NQL402M-100X	COIL	10uH M	
L2604	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
L3001	NQR0129-002X	FERRITE BEADS		
L3002	NQR0129-002X	FERRITE BEADS		
L3004	NQR0006-001X	FERRITE BEADS		
L3005	NQR0006-001X	FERRITE BEADS		
L3007	NQL085J-2R2X	COIL	2.2uH J	
L3008	NQL085J-120X	COIL	12uH J	
L3012	NQR0129-002X	FERRITE BEADS		
L3014	NQL38DK-100X	P COIL	10uH K	
L3015	NQR0006-001X	FERRITE BEADS		
L3701	NQL38DK-100X	P COIL	10uH K	
L3801	NQR0129-002X	FERRITE BEADS		
L3802	NQR0129-002X	FERRITE BEADS		
L3803	NQR0006-001X	FERRITE BEADS		
L3804	NQL38DK-100X	P COIL	10uH K	
L4201	NQR0129-002X	FERRITE BEADS		
L4301	NQR0129-002X	FERRITE BEADS		
L4302	NQR0129-002X	FERRITE BEADS		
L4802	NQL302N-100X	COIL	10uH N	
L4851	NQR0129-002X	FERRITE BEADS		
L4852	NQL315K-100X	COIL	10uH K	
L4853	NQL315K-100X	COIL	10uH K	
L5501	NQL315K-100X	COIL	10uH K	
L5502	NQR0129-002X	FERRITE BEADS		
L5503	NQR0129-002X	FERRITE BEADS		
L5504	NQR0129-002X	FERRITE BEADS		
L5505	NQL315K-100X	COIL	10uH K	
L5506	NQL315K-100X	COIL	10uH K	
L6001	NQLZ011-4R7X	COIL	4.7uH N	
L6002	NQLZ011-4R7X	COIL	4.7uH N	
L6101	NQL52EM-390X	COIL	39uH M	
L6201	NQL52EM-390X	COIL	39uH M	
L6301	NQL52EM-390X	COIL	39uH M	
L6302	NQL144K-220X	P COIL	22uH K	
L6401	NQL52EM-470X	COIL	47uH M	
L6501	NQL52EM-470X	COIL	47uH M	
L6601	NQL52EM-221X	COIL	220uH M	
L6701	NQL73EM-100X	COIL	10uH M	
L6801	NQL034K-470X	P COIL	47uH K	
L8701	NQR0129-002X	FERRITE BEADS		F,G,H,J
L8702	NQR0129-002X	FERRITE BEADS		F,G,H,J
CN101	QGF0528F1-40X	CONNECTOR	FFC/FPC (1-40)	
CN102	QGF0505F1-22X	CONNECTOR	FFC/FPC (1-22)	
CN104	QGA1002C1-11X	CONNECTOR	W-B (1-11)	
CN105	QGB0509M1-30X	CONNECTOR	B-B (1-30)	
CN106	QGA1201C2-05X	CONNECTOR	W-B (1-5)	
CN107	QGF0503C1-20X	CONNECTOR	FFC/FPC (1-20)	
CN108	QGF0503C1-24V	CONNECTOR	FFC/FPC (1-24)	
CN109	QGF0503F1-16X	CONNECTOR	FFC/FPC (1-16)	
CN110	QGF0528F1-40X	CONNECTOR	FFC/FPC (1-40)	
CN111	QGF0528F1-40X	CONNECTOR	FFC/FPC (1-40)	
△ F6001	NMFZ007-2R0X-K	FUSE	2A 32V	
△ F6301	NMFZ007-1R25X-K	FUSE	1.25A 32V	
△ F6701	NMFZ007-1R25X-K	FUSE	1.25A 32V	
△ F6801	NMFZ007-R50X-K	FUSE	0.5A 50V	
J501	NNZ0041-001X	D CONNECTOR	IEEE1394(4pin)	
J502	QNZ0616-001	USB CONNECTOR		F,G,H,J
X1001	NAX0578-001X	CRYSTAL		
X1002	NAX0564-001X	CRYSTAL		
X3002	NAX0480-001X	CRYSTAL	24.576MHz	
X5501	NAX0587-001X	CXO		
X8701	NAX0398-001X	C OSCILLATOR		F,G,H,J
OT1	LY30030-069A	SPACER(A)		
OT2	LY44158-001A	SHEET(SHIELD)		
WR1	QAL0474-001	FPC	MAIN-PREMDA CN401	
WR2	QAL0474-001	FPC	MAIN-PREMDA CN408	

MONI-BW BOARD ASSEMBLY <02>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	YB10433E	MONI-BW BOARD ASSY		
IC7601	AN12550A	IC		
IC7602	BA4558F-X	IC		
Q7601	2SC4617/QR/-X	TRANSISTOR		
Q7601 or	2SC4738/YG/-X	TRANSISTOR		
Q7601 or	2SD2216J/QR/-X	TRANSISTOR		
Q7601 or	BC847BT-X	TRANSISTOR		
Q7602	2SA1774/QR/-X	TRANSISTOR		
Q7602 or	2SA1832/YG/-X	TRANSISTOR		
Q7602 or	BC857BT-X	TRANSISTOR		
Q7603	2SC4617/QR/-X	TRANSISTOR		
Q7603 or	2SC4738/YG/-X	TRANSISTOR		
Q7603 or	2SD2216J/QR/-X	TRANSISTOR		
Q7603 or	BC847BT-X	TRANSISTOR		
Q7604	2SA1774/QR/-X	TRANSISTOR		
Q7604 or	2SA1832/YG/-X	TRANSISTOR		
Q7604 or	BC857BT-X	TRANSISTOR		
Q7608	DTC144EE-X	DIGI TRANSISTOR		
Q7608 or	UN9213J-X	DIGI TRANSISTOR		
Q7608 or	RN1104-X	DIGI TRANSISTOR		
Q7608 or	BCR148T-X	DIGI TRANSISTOR		
Q7609	2SC4617/QR/-X	TRANSISTOR		
Q7609 or	2SC4738/YG/-X	TRANSISTOR		
Q7609 or	2SD2216J/QR/-X	TRANSISTOR		
Q7609 or	BC847BT-X	TRANSISTOR		
Q7610	DTA114EE-X	DIGI TRANSISTOR		
Q7610 or	BCR183T-X	DIGI TRANSISTOR		
Q7611	DTC144EE-X	DIGI TRANSISTOR		
Q7611 or	UN9213J-X	DIGI TRANSISTOR		
Q7611 or	RN1104-X	DIGI TRANSISTOR		
Q7611 or	BCR148T-X	DIGI TRANSISTOR		
Q7612	DTA144EE-X	DIGI TRANSISTOR		
Q7612 or	UN9113J-X	DIGI TRANSISTOR		
Q7612 or	RN2104-X	DIGI TRANSISTOR		
Q7612 or	BCR198T-X	DIGI TRANSISTOR		
Q7613	2SD2654/VW/-X	TRANSISTOR		
D7602	1SS355-X	SI DIODE		
C1	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C10	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7601	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7602	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7603	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7604	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7605	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7606	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7607	NCB41CK-106X	C CAPACITOR	10uF 16V K	
C7608	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7609	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7613	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7614	NCB31HK-152X	C CAPACITOR	1500pF 50V K	
C7615	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7616	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7617	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7618	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C7619	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C7620	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7621	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7622	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7623	NBE21AM-106X	TA E CAPACITOR	10uF 10V M	
C7624	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7626	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7627	NCF31CZ-104X	C CAPACITOR	0.1uF 16V Z	
C7628	NBP41EM-475X	TA E CAPACITOR	4.7uF 25V M	
C7629	NBP21CM-335X	TA E CAPACITOR	3.3uF 16V M	
C7630	NBP41EM-475X	TA E CAPACITOR	4.7uF 25V M	
C7631	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7632	NBP41EM-475X	TA E CAPACITOR	4.7uF 25V M	
C7633	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7634	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7635	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7637	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7646	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
C7647	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7651	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7661	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7662	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7663	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7664	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7665	NBP41CM-226X	TA E CAPACITOR	22uF 16V M	
C7666	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
R3	NRSA63J-103X	MG RESISTOR	10kΩ 1/16W J	
R4	NRSA63J-332X	MG RESISTOR	3.3kΩ 1/16W J	
R5	NRSA63J-682X	MG RESISTOR	6.8kΩ 1/16W J	
R6	NRSA63J-223X	MG RESISTOR	22kΩ 1/16W J	
R7	NRSA63J-103X	MG RESISTOR	10kΩ 1/16W J	
R8	NRSA63J-332X	MG RESISTOR	3.3kΩ 1/16W J	
R7601	NRVA63D-622X	CMF RESISTOR	6.2kΩ 1/16W D	
R7602	NRSA63J-153X	MG RESISTOR	15kΩ 1/16W J	
R7603	NRSA63J-683X	MG RESISTOR	68kΩ 1/16W J	
R7608	NRSA63J-153X	MG RESISTOR	15kΩ 1/16W J	
R7609	NRVA63D-223X	CMF RESISTOR	22kΩ 1/16W D	
R7610	NRVA63D-433X	CMF RESISTOR	43kΩ 1/16W D	
R7611	NRVA63D-821X	CMF RESISTOR	820Ω 1/16W D	
R7612	NRVA63D-223X	CMF RESISTOR	22kΩ 1/16W D	
R7613	NRVA63D-223X	CMF RESISTOR	22kΩ 1/16W D	
R7614	NRVA63D-223X	CMF RESISTOR	22kΩ 1/16W D	
R7615	NRSA63J-223X	MG RESISTOR	22kΩ 1/16W J	
R7616	NRSA63J-223X	MG RESISTOR	22kΩ 1/16W J	
R7617	NRSA02J-561X	MG RESISTOR	560Ω 1/10W J	
R7618	NRSA02J-561X	MG RESISTOR	560Ω 1/10W J	
R7620	NRSA63J-335X	MG RESISTOR	3.3MΩ 1/16W J	
R7621	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7630	NRSA63J-223X	MG RESISTOR	22kΩ 1/16W J	
R7634	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7636	NRSA63J-101X	MG RESISTOR	100Ω 1/16W J	
R7637	NRSA63J-101X	MG RESISTOR	100Ω 1/16W J	
R7638	NRSA63J-101X	MG RESISTOR	100Ω 1/16W J	
R7661	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7662	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7663	NRSA63J-103X	MG RESISTOR	10kΩ 1/16W J	
R7666	NRSA63J-153X	MG RESISTOR	15kΩ 1/16W J	
R7667	NRVA63D-273X	CMF RESISTOR	27kΩ 1/16W D	
R7668	NRVA63D-273X	CMF RESISTOR	27kΩ 1/16W D	
R7669	NRVA63D-392X	CMF RESISTOR	3.9kΩ 1/16W D	
R7672	NRSA63D-394X	MG RESISTOR	390kΩ 1/16W D	
R7673	NRVA63D-473X	CMF RESISTOR	47kΩ 1/16W D	
R7674	NRVA63D-473X	CMF RESISTOR	47kΩ 1/16W D	
R7675	NRSA63J-274X	MG RESISTOR	270kΩ 1/16W J	
L7601	NQL365K-100X	COIL	10uH K	
L7602	NQL365K-470X	COIL	47uH K	
L7603	NQL365K-470X	COIL	47uH K	
L7604	NQL365K-100X	COIL	10uH K	
L7605	NQL365K-100X	COIL	10uH K	
L7607	NQL365K-100X	COIL	10uH K	
CN761	QGF0508F1-40X	CONNECTOR	FFC/FPC (1-40)	
CN763	QGF0507F3-20X	CONNECTOR	FFC/FPC (1-20)	
CN765	QGF0506F2-32X	CONNECTOR	FFC/FPC (1-32)	
SW2	NSW0145-001X	TACT SWITCH STOP		
SW3	NSW0145-001X	TACT SWITCH REW		
SW4	NSW0145-001X	TACT SWITCH FF		
SW5	NSW0145-001X	TACT SWITCH PLAY/PAUSE		
SW7	NSW0145-001X	TACT SWITCH INDEX		
SW8	NSW0145-001X	TACT SWITCH SELECT		
SW7601	NSW0200-001X	LEVER SWITCH MONI SW		

BL-2.5 BOARD ASSEMBLY <03>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	YB20938A	BL-2.5 BOARD ASSY		
IC7604	DN8797MS-X	IC		
Q7501	2SD1664/QR/-W	TRANSISTOR		

△ Symbol No.	Part No.	Part Name	Description	Local
Q7502	2SD1664/QR/-W	TRANSISTOR		
Q7503	DTA144EE-X	DIGI TRANSISTOR		
Q7503 or	UN9113J-X	DIGI TRANSISTOR		
Q7503 or	RN2104-X	DIGI TRANSISTOR		
Q7503 or	BCR198T-X	DIGI TRANSISTOR		
Q7504	DTC144EE-X	DIGI TRANSISTOR		
Q7504 or	UN9213J-X	DIGI TRANSISTOR		
Q7504 or	RN1104-X	DIGI TRANSISTOR		
Q7504 or	BCR148T-X	DIGI TRANSISTOR		
C7501	NCZ1016-120X	C CAPACITOR	12pF 2kV J	
C7502	NCB21EK-273X	C CAPACITOR	0.027uF 25V K	
C7503	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7504	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
R7501	NRSA63J-102X	MG RESISTOR	1kΩ 1/16W J	
R7502	NRSA63J-102X	MG RESISTOR	1kΩ 1/16W J	
R7503	NRSA63J-102X	MG RESISTOR	1kΩ 1/16W J	
R7504	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7511	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7512	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7513	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
L7501	NQLZ010-680X	COIL	68uH M	
△ T7501	NQS0056-001X	SW TARN SF		
CN7601	QGF0507F3-16X	CONNECTOR	FFC/FPC (1-16)	
CN7602	QGF0507F3-16X	CONNECTOR	FFC/FPC (1-16)	
CN7603	QGF0508F1-24X	CONNECTOR	FFC/FPC (1-24)	
△ F7501	NMFZ007-R40X-K	FUSE	0.4A 50V	
WR1	QAL0464-001	FPC		

CCD BOARD ASSEMBLY <04>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	YB20942A-SS	CCD BOARD ASSY		
Q5001	2SC3931/CD/-X	TRANSISTOR		
C5001	NBP41EM-475X	TA E CAPACITOR	4.7uF 25V M	
C5002	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5003	NBE21AM-106X	TA E CAPACITOR	10uF 10V M	
C5004	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5005	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5006	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5007	NCB31EK-222X	C CAPACITOR	2200pF 25V K	
R5001	NRSA63J-472X	MG RESISTOR	4.7kΩ 1/16W J	
R5002	NRSA63J-104X	MG RESISTOR	100kΩ 1/16W J	
L5001	NQL315K-100X	COIL	10uH K	
L5002	NQL315K-100X	COIL	10uH K	
CN5001	QGF0517F2-20X	CONNECTOR	FFC/FPC (1-20)	

PREMDA BOARD ASSEMBLY <05>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	YB10405A-01	PREMDA BOARD ASSY		
IC1601	BD6637KS	IC		
IC1701	LM358DMR2-X	IC		
IC1702	LM393DMR2-X	IC		
IC3501	JCY0132	IC		
IC3502	SN74AHC1G04K-X IC			
Q1601	UMC3N-W	DIGI TRANSISTOR		
D1602	DAP222-X	DIODE ARRAY		
D1602 or	MA132WA-X	SI DIODE		

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

 Symbol No.	Part No.	Part Name	Description	Local
R502	NRSA63J-684X	MG RESISTOR	680k Ω 1/16W J	
R503	NRSA63J-182X	MG RESISTOR	1.8k Ω 1/16W J	
R504	NRSA63J-222X	MG RESISTOR	2.2k Ω 1/16W J	
R505	NRSA63J-103X	MG RESISTOR	10k Ω 1/16W J	
R506	NRSA63J-824X	MG RESISTOR	820k Ω 1/16W J	
R507	NRSA63J-104X	MG RESISTOR	100k Ω 1/16W J	
R508	NRSA63J-683X	MG RESISTOR	68k Ω 1/16W J	
R509	NRSA63J-822X	MG RESISTOR	8.2k Ω 1/16W J	
R510	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R511	NRSA63J-302X	MG RESISTOR	3k Ω 1/16W J	
R512	NRSA63J-470X	MG RESISTOR	47 Ω 1/16W J	
R513	NRSA63J-101X	MG RESISTOR	100 Ω 1/16W J	
R514	NRSA63J-101X	MG RESISTOR	100 Ω 1/16W J	
R515	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R516	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R517	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R518	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R519	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R520	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R521	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R522	NRSA63J-221X	MG RESISTOR	220 Ω 1/16W J	
R523	NRSA63J-331X	MG RESISTOR	330 Ω 1/16W J	
L501	NQR0251-004X	FERRITE BEADS		
L502	NQR0251-004X	FERRITE BEADS		
L503	NQR0251-004X	FERRITE BEADS		
CN501	QGF0503C1-22X	CONNECTOR	FFC/FPC (1-22)	
J501	QNS0078-001	3.5 JACK		
J502	QND0004-001	S JACK		
J503	PEMC1203	MINI JACK		
SW501	NSW0122-001X	DETECT SWITCH EJECT SW		

B/W-VF BOARD ASSEMBLY <07>

 Symbol No.	Part No.	Part Name	Description	Local
PW1	YB20940A	B/W-VF BOARD ASSY		
Q7001	PUMX1-W	PAIR TRANSISTOR		
Q7001 or	BC847S-X	PAIR TRANSISTOR		
D7001	E1S35AW0C501-X	LED		
C7001	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7002	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7003	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7004	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
R7001	NRSA63J-332X	MG RESISTOR	3.3k Ω 1/16W J	
R7002	NRSA63J-561X	MG RESISTOR	560 Ω 1/16W J	
R7003	NRSA63J-470X	MG RESISTOR	47 Ω 1/16W J	
R7004	NRSA63J-102X	MG RESISTOR	1k Ω 1/16W J	
CN7001	QGF0532F1-18X	CONNECTOR	FFC/FPC (1-18)	
CN7002	QGF0507F3-20X	CONNECTOR	FFC/FPC (1-20)	

SECTION 3 PARTS LIST

3.1 DVC MECHANISM ASSEMBLY




Fig.3-1-1

3.1.1 DVC MECHANISM ASSEMBLY PART LIST

- Since parts numbers described here are the numbers at the time of manual issue, they are subject to change without notice. Therefore, be sure to see a parts list in the service manual of each model as for parts numbers.
- To distinguish the mechanism assembly with the symbol number of 400-499 from the mechanism assembly with the symbol number of 900-999, see the following procedures.

(1) See the numbers on the backside of the MAIN DECK ASSY.

For example, "29D*****" is printed on the backside of the mechanism assembly with the symbol number of 900-999 (YMA0029D in this example). See the first three characters and numbers from the left.

(2) See the color of the SLIT WASHER on the REEL DISK (TU).

A red slit washer is used (the same color as a slit washer of CASSETTE GUIDE (SUP)) in the mechanism assembly with the symbol number of 400-499. A black slit washer is used in the mechanism assembly with the symbol number of 900-999.

However, the black slit washer may be changed into a red one for the purpose of parts unification.


(3) See the color of the CASSETTE GUIDE(SUP).

Light-brown CASSETTE GUIDE(SUP) is used in the mechanism assembly with the symbol number of 400-499.

Black CASSETTE GUIDE(SUP) is used in the mechanism assembly with the symbol number of 900-999.

(4) See the shape of the LED PRISM. LED PRISM consists of only resin in the mechanism assembly with the symbol number of 400-499.

Upper part of the LED PRISM is covered with black metal in the mechanism assembly with the symbol number of 900-999.



Part Name	Symbol No.	Part No.	Part No.	Part No.	Symbol No.	Part No.	Patr No.
MECHA(A) ASSY	400	YMA0029C	YMA0029M	YMA0029L	900	YMA0029H	YMA0029E
MECHA(A) ASSY	-	-	-	-	900A	YMA0029D	-
CASSETTE HOUSING ASSY	401	LY31543-002E*	LY31543-002H	←	901	LY32870-001G*	LY32870-001J
MINI SCREW,X3	402	YQ43893-8	←	←	902	←	←
UPPER BASE ASSY	403	LY31542-001J	←	←	903	LYH30420-001A	←
MINI SCREW	404	YQ43893*	QYSPSPU1425M	←	904	←	←
DRUM ASSY	405	**	**	**	905	**	**
DAMP.SCREW ASSY,X2	406	LY42820-001A	←	←	906	←	←
DAMP.SCREW ASSY	407	LY42820-002A	←	←	907	←	←
REEL DISK ASSY (SUP)	408	LY31538-001B*	LY31538-001F	←	908	←	←
REEL DISK ASSY (TU)	409	LY31538-002B*	LY31538-002H	LY31538-002G	909	LY31538-002H	←
SLIT WASHER,X2 or X1	410	YQ44246,(x2)	←,(x2)	←,(x2)	910	←*,(x1)	←,(x2)
REEL COVER ASSY	411	LY10217-001A*	LY10217-001F	←	911	LY10372-001D	←
MINI SCREW	412	LY42120-001A*	LY42120-002A	←	912	←	←
MINI SCREW,X2	413	LY41945-003A	←	←	913	←	←
SLIT WASHER	414	YQ44246	←	←	914	←	←
TENSION ARM ASSY	415	LY42025-001C	←	←	915	LY43725-001D	←
SLANT POLE ARM ASSY	416	LY31535-001F	←	←	916	LYH40269-001A	←
TU ARM ASSY	417	LY42031-001G*	LY42031-001K	←	917	LY43731-001F	←
SWING ARM ASSY	418	LY31531-001D	←	←	918	←	←
MINI SCREW	419	YQ43893	←	←	919	←	←
SLIDE DECK FINAL ASSY	420	LY20530-003B*	LY20530-003E	←	920	LYH30424-001A	←

Part Name	Symbol No.	Part No.	Part No.	Part No.	Symbol No.	Part No.	Patr No.
MINI SCREW,X2	421	YQ43893	←	←	921	←	←
MINI SCREW	422	LY43023-001A	←	←	922	←	←
PAD ARM ASSY	424	LY31533-001E	←	←	924	LYH30419-001A	←
SLIT WASHER	425	YQ44246	←	←	925	←	←
TU BRAKE ASSY	428	LY42016-001B	←	←	928	LYH40270-001A	←
SLIT WASHER	429	YQ44246	←	←	929	←	←
TENSION CONTROL LEVER ASSY	430	LY41959-001B	←	←	930	LY43684-001A	←
CENTER GEAR	431	LY31525-001B	←	←	931	LY32861-001A	←
PINCH ROLLER ARM FINAL ASSY	432	LY31516-001E	←	LY31516-001F	932	←	←
SLIT WASHER	433	YQ44246	←	←	933	←	←
TENSION CONTROL PLATE ASSY	434	LY41956-001C	←	←	934	LY43681-001A	←
BRAKE CONTROL LEVER ASSY	435	LY41962-001B*	LY41962-001C	←	935	LY43687-001A	←
MOTOR BRACKET ASSY	436	LY20525-002C	←	←	936	LYH30421-001A	←
LOADING MOTOR	436A	QAR0138-001	←	←	936A	←	←
TAPPING SCREW,x2	436B	LY41940-001A	←	←	936B	←	←
MINI SCREW,x3	437	YQ43893	←	←	937	←	←
GUIDE RAIL ASSY	438	LY20528-001R*	LY20528-001U	←	938	LYH30422-001A	←
MINI SCREW	439	YQ43893	←	←	939	←	←
SLIT WASHER,X2	440	YQ44246	←	←	940	←	←
SLIDE LEVER2 ASSY	441	LY31498-001C	←	LY31498-001D	941	LY32843-001A	←
LOADING PLATE ASSY	442	LY41965-001A	←	←	942	LY43690-001A	←
SLIT WASHER	443	YQ44246	←	←	943	←	←
EJECT LEVER	444	LY31522-001B	←	←	944	LY32858-001A	←
SLIT WASHER	445	YQ44246	←	←	945	←	←
BASE R ASSY	446	LY41929-001E*	LY41929-001F	←	946	LYH40271-001A	←
MINI SCREW	447	YQ43893	←	←	947	←	←
MINI SCREW	448	LY41945-001B	←	←	948	←	←
MODE GEAR	449	LY41930-001A	←	←	949	LY43665-001A	←
ROTARY ENCODER	450	QSW0876-003	←	←	950	←	←
MINI SCREW,X2	451	YQ43893	←	←	951	←	←
GEAR COVER ASSY	452	LY31524-001A	←	←	952	LY32860-001A	←
MINI SCREW,X2	453	YQ43893	←	←	953	←	←
MINI SCREW	454	YQ43893-4	←	←	954	←	←
MAIN CAM ASSY	455	LY41948-001C	←	←	955	LY43676-001A	←
SLIDE ARM ASSY	456	LY41941-001B	←	←	956	←	←
CONNECT GEAR 2	457	LY41951-001B	←	←	957	LY43678-001A	←
SUB CAM ASSY	458	LY41954-001B	←	LY41954-001E	958	←	←
MINI SCREW	459	LY42120-001A	←	←	959	←	←
CONTROL ARM ASSY	460	LY41952-001A	←	←	960	LY43692-001A	←
REEL GEAR 1	461	LY31523-001B	←	←	961	LY32859-001A	←
DRUM BASE ASSY	462	LY31508-002A*	LY31508-002B	LY33372-001A	962	LY31508-002B	←
SCREW,X3	463	QYSPSPU1425M	←	←	963	←	←
CAPSTAN MOTOR	464	QAR0142-001	←	←	964	←	←
MINI SCREW	465	YQ43893	←	←	965	←	←
MAIN DECK ASSY	466	LY10210-001D*	LY10210-001G	←	966	LY10367-001D*	LY10367-001E
SLIT WASHER	476	YQ44246	←	←	976	←	←
SLIT WASHER	477	-	-	-	977	YQ44246-6	-
WASHER	478	-	-	-	978	LY42047-005A	←
SPACER	479	-*	LY43987-001B	←	979	←	←

NOTE:


MARK ← is same as left.

MARK - is not used.

MARK * reference model was also changed.

MARK ** shows different parts number, depending on models.

3-4 (No.86700)



3.2.1 VHS-C MECHANISM ASSEMBLY PARTS LIST

- Since parts numbers described here are the numbers at the time of manual issue, they are subject to change without notice. Therefore, be sure to see a parts list in the service manual of each model as for parts numbers.

Part Name	Symbol No.	Part No.	Part No.	Part No.	Part No.	Part No.
MECHA(B) ASSY	400	YMA0033A-E	YMA0042A-E	YMA0034A-E	YMA0036A-E	YMA0040A-E
MAIN DECK ASSY	401	LY20612-001B	←	←	←	←
CASSETTE GUIDE (LEFT)	402	LY31817-001A	←	←	←	←
SW LEVER (LEFT)	403	LY31815-001A	←	←	←	←
TORSION SPRING	404	LY42581-001A	←	←	←	←
SCREW	405	LY42722-001A	←	←	←	←
CASSETTE GUIDE ASSY(RIGHT)	406	-	-	YQ44339A-7	←	←
SW.LEVER(RIGHT)	406A	-	-	YQ32162-1-3	←	←
TORSION SPRING	406B	-	-	YQ44340-1-4	←	←
SCREW	407	-	-	LY42819-001A	←	←
MOTOR BRACKET ASSY	408	LY31826-001A	←	←	←	←
WORM BRACKET	409	YQ20793	LY20951-001A	YQ20793	←	LY20951-001A
SCREW,X3	410	LY42722-001A	←	←	←	←
WHEEL GEAR	411	LY31925-001A	←	←	←	←
MIDDLE GEAR	412	LY42730-001A	←	←	←	←
CANCEL LEVER ASSY	413	LY42521-001A	←	←	←	←
SLIT WASHER,X2	414	LY42754-003A	←	←	←	←
CONTROL CAM	415	YQ20827-2-1	←	←	←	←
SLIT WASHER	416	PQM30017-25	←	←	←	←
LOADING GEAR(T)ASSY	417	LY42733-001A	←	←	←	←
SLIT WASHER	418	LY42754-003A	←	←	←	←
LOADING GEAR(S)ASSY	419	LY42732-001A	←	←	←	←
SLIT WASHER	420	LY42754-003A	←	←	←	←
COVER PLATE	421	LY42403-001A	←	←	←	←
LOADING RING ASSY	422	LY42452-001A	←	←	←	←
SCREW,X4	423	LY42728-001A	←	←	←	←
GUIDE RAIL	424	LY10239-001A	←	←	←	←
SCREW,X8 or X7	425	LY42728-001A,(X8)	←,(X7)	←,(X8)	←,(X8)	←,(X7)
POLE BASE(S)ASSY	426	LY30161-001B	←	←	←	←
POLE BASE(T)ASSY	427	LY30162-002A	←	←	←	←
DRIVE LEVER ASSY	428	LY42523-001A	←	←	←	←
SLANT ARM ASSY	429	LY42545-001B	LY44000-001B	LY42545-001B	←	LY44000-001B
TORSION SPRING(S)	429A	LY42547-001A	LY43992-001A	LY42547-001A	←	LY43992-001A
SLIT WASHER	430	LY42754-003A	←	←	←	←
ROLLER BASE ASSY	431	LY42739-003A	←	←	←	←
SCREW	432	LY42722-001A	←	←	←	←
LINK ARM ASSY	433	LY42494-001A	←	←	←	←
SLIT WASHER	434	PQM30017-25	←	←	←	←
PINCH ROLLER ARM ASSY	435	LY40018-002A	←	←	LY40018-005A	←
SLIT WASHER	436	PQM30017-25	←	←	←	←
TAKE UP GUIDE ARM ASSY	437	LY42541-001B	←	←	←	←
SLIT WASHER	438	LY42754-003A	←	←	←	←
TENSION ARM ASSY	439	LY42571-001A	←	←	←	←
TENSION SPRING	439A	LY42669-001A	←	←	←	←
SLIT WASHER	440	LY42754-003A	←	←	←	←
MOTOR BASE	441	YQ20797-1-5	←	←	←	←
SCREW,X2	442	LY42722-001A	←	←	←	←
SCREW	443	YQ44460	←	←	←	←
CAPSTAN MOTOR	444	QAR0212-001	QAR0212-002	QAR0212-001	QAR0212-002	←
TAPPING SCREW,X3	445	YQ44304	←	←	←	←
SLANT POLE BASE ASSY	446	LY42731-001A	←	←	←	←
TAPPING SCREW	447	YQ44304	←	←	←	←
TIMING BELT	448	YQ43710-2	←	←	←	←
CENTER PULLEY UNIT	449	LY42678-001A	←	←	←	LY42678-003A

Part Name	Symbol No.	Part No.	Part No.	Part No.	Part No.	Part No.
SCREW,X2	450	LY42722-002A	←	←	←	←
SUPPLY CLUTCH ASSY	451	LY42670-001A	←	←	←	←
SLIT WASHER	452	LY42754-003A	←	←	←	←
REEL DISC	453	YQ31861-1-7	←	←	←	←
WASHER	454	LY42755-001A	←	←	←	←
TAKE UP GEAR	455	LY31924-001A	←	←	←	←
BRAKE SUB GEAR	456	LY42738-001A	←	←	←	←
SLIT WASHER,X3	457	LY42754-003A	←	←	←	←
A/C HEAD UNIT	458	LY42544-001B	LY42544-002A	LY42544-001B	←	LY42544-002A
SCREW,X2	459	SPSN1750Z	←	←	←	←
EJECT LEVER ASSY	460	LY42517-001A	←	←	←	←
SLIT WASHER	461	LY42754-003A	←	←	←	←
LED GUIDE	462	YQ31833-1-1	←	←	←	←
SCREW	463	LY42722-001A	←	←	←	←
DRUM SPACER	464	LY42729-001A	←	←	←	←
SCREW,X2	465	LY42722-001A	←	←	←	←
ROTARY ENCODER	466	QSW0888-001	←	QSW0888-002	←	←
SCREW,X4	467	LY42722-002A	←	←	←	←
LINK LEVER	468	LY31814-001A	←	←	←	←
DRUM FINAL ASSY	469	**	**	**	**	**
CATCHER	469A	YDM1003-1-5	←	←	←	←
SCREW,X2	469B	QYSPSPU1735M	←	←	←	←
SCREW,X2	470	LY42722-001A	←	←	←	←
SCREW,X2	471	SPSH1740Z	←	←	←	←
BRUSH	472	LY43542-001A	←	←	←	←
SCREW	473	LY42722-003A	←	←	←	←
CASSETTE HOUSING FINAL ASSY	*155/481	LY31808-001C	LY31808-002C	LY31808-001C	LY31808-001D	LY31808-002C
SCREW,X4	*156/482	LY42722-003A	←	←	←	←
BRACKET(MECHA)	*161/484	LY32326-001A	←	←	←	←
SCREW,X2	*162/485	LY42722-003A	←	←	←	←
SIDE BRACKET L	*164/487	LY31807-001A	←	←	←	←
SCREW	*165/488	LY42722-003A	←	←	←	←

NOTE:

MARK ← is same as left.

MARK - is not used.

MARK * are shown in the parts list of FINAL ASSY of service manual of each model.

MARK ** shows different parts number, depending on models.

3.3 VHS MECHANISM ASSEMBLY




Fig.3-3-1

3.3.1 VHS MECHANISM ASSEMBLY PARTS LIST

- Since parts numbers described here are the numbers at the time of manual issue, they are subject to change without notice. Therefore, be sure to see a parts list in the service manual of each model as for parts numbers.

System		VHS		S-VHS	
**Job No.		V15D Series	V16D Series	V15S Series	V16S Series
Part Name	Symbol No.	Part No.	Part No.	Part No.	Part No.
MAIN DECK ASSY	1	LP21039-001N	LP21039-001S	LP21039-001R	LP21039-001S
GUIDE POLE CAP	3	LP40097-002D	←	←	←
FULL ERASE HEAD	4	QAH0082-001	←	←	←
LOAD.GEAR BASE	15	LP30958-001B	←	←	←
SCREW,X2	16	QYTPST2620Z	←	←	←
LORD.GEAR(SUPPLY) ASSY	18	LP40798-001A	←	←	←
LORD.GEAR(SUPPLY)	18A	LP21040-001A	←	←	←
LORD.ARM(SUPPLY) ASSY	18B	LP40799-001A	←	←	←
TORSION SPRING(SUPPLY)	19	LP40837-001A	←	←	←
FIXING PLATE	20	LP40903-001A	←	←	←
POLE BASE ASSY(SUPPLY)	21	LP40806-001D	←	←	←
LOAD GEAR	22	LP30959-002A	←	←	←
LORD. GEAR(TAKE UP) ASSY	23	LP40802-001B	LP40802-001C	LP40802-001B	LP40802-001C
LORD. GEAR(TAKE UP)	23A	LP21041-001B	LP21041-001C	LP21041-001B	LP21041-001C
LORD.ARM(TAKE UP) ASSY	23B	LP40803-001A	←	←	←
TORSION SPRING(TAKE UP)	24	LP40838-001A	←	←	←
POLE BASE ASSY(TAKE UP)	26	LP40808-001F	LP40808-001E	←	←
ARM BASE	30	-	←	LP31020-004A	←
SCREW	31	-	←	QYTDST2606Z	-
TU LEVER	36	LP21055-001E	←	←	←
TENSION SPRING	37	LP40943-001A	←	←	←
T-UP HEAD	38	LP40859-001D	←	←	←
LID GUIDE	39	LP30961-001C	←	←	←
SPACER	40	LP30002-0B7A	←	←	-
PINCH ROLLER ARM ASSY	42	LP40810-001A	←	←	←
TORSION SPRING	44	LP40840-001C	LP40840-001D	←	←
PRESS LEVER	46	LP30963-001B	←	←	←
SLIT WASHER	47	PQM30017-24	←	←	←
S-SWITCH	48	-	←	LP40930-002E	←
GIDE ARM ASSY	49	LP40813-001D	←	←	←
TORSION SPRING	50	LP40841-001A	←	←	←
SPACER	51	LP30002-090A	←	←	-
A/C HEAD	52	QAH0081-001	←	←	←
HEAD BASE	53	LP30965-001A	←	←	←
COMPRESSION SPRING	55	LP40842-001A	LP40842-001D	LP40842-001A	LP40842-001D
SCREWX1 A/C HEAD	*56	QYTDST2006M	←	←	←
A/C HEAD SCREW,X2	*57	LP41036-001A	←	←	←
SCREW,X2 A/C HEAD	*58	QYTDST2606Z	←	←	←
LOADING MOTOR	59	QAR0023-001	←	←	←
SCREW,X2	60	QYTPSP3003Z	←	←	←
MOTOR BRACKET	61	LP21056-002F	LP21056-002G	←	←
TAP SCREW	62	QYTPST2620Z	←	←	←
WORM BEARING	63	LP40814-001B	←	←	←
CONTROL CAM	64	LP21044-001D	←	←	←
SLIT WASHER	65	PQM30017-24	←	←	←
WORM GEAR	66	LP40815-001A	←	←	←
HELICAL GEAR	67	LP40816-001B	←	←	←
CONNECT GEAR	68	LP40817-001A	←	←	←

System		VHS		S-VHS	
**Job No.		V15D Series	V16D Series	V15S Series	V16S Series
Part Name	Symbol No.	Part No.	Part No.	Part No.	Part No.
CONTROL PLATE	69	LP10400-001H	←	←	LP10400-001J
TORTION SPRING	70	LP40843-001A	←	←	←
TENSION ARM ASSY	71	LP40818-001B	←	←	←
TENSION SPRING	72	LP40844-001C	LP40844-001E	LP40844-001D	LP40844-001E
TENSION ARM BASE	73	LP21045-001D	←	←	←
TENSION BAND ASSY	74	LP40821-001A	←	←	←
BAND HOLDER-1	75	LP30967-001B	←	←	←
BAND HOLDER-2	76	LP30968-001C	←	←	←
ADJUST PIN	77	LP40822-002B	←	←	←
TENSION ARM LEVER	78	LP31000-005E	←	←	←
MAIN BRAKE(TAKE UP)	79	LP21046-001C	←	←	←
BAND BRAKE ASSY	80	LP40824-001A	←	←	←
BRAKE LEVER	81	LP30969-002A	LP30969-002B	LP30969-002A	LP30969-002B
TENSION SPRING	82	LP30003-033B	←	←	←
TENSION SPRING	83	LP30003-035B	←	←	←
CAPSTAN BRAKE ASSY	84	LP40825-001B	←	←	←
CAPSTAN MOTOR	85	QAR0204-002	←	←	←
SCREW,X3 CAPSTAN MOTOR	86	QYTPSG2606M	QYTPSG2606Z	QYTPSG2606M	QYTPSG2606Z
BELTCAPSTAN MOTOR	87	LP30005-010A	←	←	←
IDLER ARM	88	LP30970-001A	←	←	←
IDLER GEAR 1,X2	89	LP40828-004A	←	←	←
IDLER GEAR 2,X2	90	LP40829-001B	LP40829-002A	LP40829-001B	LP40829-002A
WIRE HOLDER	91	LP31014-001A	←	←	←
CLUTCH UNIT	93	LP40934-001B	←	←	←
SLIT WASHER	94	PQM30017-47	←	←	←
DIRECT GEAR	95	LP30973-001A	←	←	←
COMPRESS. SPRING	96	LP40939-001A	←	←	←
CHANGE LEVER	102	LP30974-001B	←	←	←
REEL DISK,X2	105	LP21049-001A	←	←	←
SPACER,X2	107	LP30017-004A	←	←	←
SIDE FRAME(L)	110	LP10401-001F	LP10401-001H	LP10401-001F	LP10401-001H
SIDE FRAME(R)	111	LP10402-001F	LP10402-001K	LP10402-001G	LP10402-001K
SCREW,X2	112	QYTDST2606Z	←	←	←
TORSION SPRING	113	LP40917-001C	LP40917-001D	←	←
SIDE PLATE	114	LP30976-001D	LP30976-001E	←	←
LIMIT PLATE	115	LP30977-002D	←	←	←
LIMIT SPRING	116	LP40846-001C	←	←	←
DRIVE LEVER	117	LP31100-001B	←	←	←
DRIVE ARM(L)	118	LP30978-001B	←	←	←
DRIVE ARM(R)	119	LP30979-001H	LP30979-001N	LP30979-001H	LP30979-001N
TORSION SPRING	120	LP40847-001B	←	←	←
CONNECT PLATE	121	LP30980-001A	LP30980-001E	LP30980-001B	LP30980-001E
SIDE HOLDER(L)	122	LP10403-001C	←	←	←
SIDE HOLDER(R)	123	LP10404-001D	LP10404-001E	←	←
LOCK LEVER(L)	124	LP30983-001A	LP30983-001B	LP30983-001A	LP30983-001B
LOCK LEVER(R)	125	LP30984-001A	LP30984-001B	LP30984-001A	LP30984-001B
TENSION SPRING,X2	126	LP40924-001C	LP40924-001D	←	←
EARTH SPRING(1)	127	LP40856-001A	←	LP40856-001B	LP40972-001A
EARTH SPRING(2)	128	LP40857-001B	←	←	←
C.HOLDER ASSY	130	LP30981-001E	LP30981-001G	LP30981-001F	LP30981-001G
C.H STOPPER	131	LP31135-001A	-	LP31135-001A	-

System		VHS		S-VHS	
**Job No.		V15D Series	V16D Series	V15S Series	V16S Series
Part Name	Symbol No.	Part No.	Part No.	Part No.	Part No.
R.SAFETY LEVER	134	LP21051-002C	←	←	←
TOP FRAME	137	LP21052-001F	LP21052-001J	LP21052-001H	LP21052-001J
SPACER	138	LP30002-0A7A	-	LP30002-0A7A	-
DOOR OPENER	151	LP30985-001G	←	←	←
TAPE GUIDE	161	-	LP40993-001A	-	LP40993-001A
E-CARD WIRE DRUM.M	WR1	WJT0059-001C	WJT0059-001E	WJT0059-001D	WJT0059-001E
E-CARD WIRE AC HEAD CN2001	WR2	WJT0067-001B	←	←	←
E-FL/RB WIRE LOADING MOTOR	WR3	WJS0022-001A	←	←	←
MEMO	-	PMD0035B-C	PMD0040A-C	PMD0036B-C /PMD0039A-C	PMD0037A-C /PMD0041A-C

NOTE:

MARK ← is same as left.

MARK - is not used.

MARK * shows that Symbol No. and Parts No. may sometimes be different from those in each manual. See the table below for final Symbol No. and Parts No.

MARK ** is Job No.

To identify a model, see the Job No. of the model.

Job No. is shown just above the service manual number at the lower right of the service manual of each model.

PARTS LIST

SAFETY PRECAUTION

Parts identified by the $\triangle$ symbol are critical for safety. Replace only with specified part numbers.


BEWARE OF BOGUS PARTS

Parts that do not meet specifications may cause trouble in regard to safety and performance. We recommend that genuine JVC parts be used.


1. EXPLODED VIEW



1.1 PACKING AND ACCESSORY ASSEMBLY <M1>

The instruction manual to be provided with this product will differ according to the destination.




1.2 FINAL ASSEMBLY <M2>






<UPPER ASSEMBLY>



1.3 MECHANISM ASSEMBLY <M3>




Classification	Part No.	Symbol in drawing
Grease	KYODO-SH-JB	AA
Oil	YTU94027	BB
Grease (HANARL)	RX-410R	CC

NOTE1: The section marked in AA and BB, CC indicate lubrication and greasing areas.


NOTE2: Mark * is not contained in 900A.

1.4 ELECTRONIC VIEWFINDER ASSEMBLY <M4>



1.5 MONITOR ASSEMBLY (2.5 INCH) <M5>

500



MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

2. PARTS LIST

PACKING AND ACCESSORY ASSEMBLY <M1>

△ Symbol No.	Part No.	Part Name	Description	Local
1	LY33063-012A	PACKING CASE		A,B,C,D
1	LY33063-015A	PACKING CASE		E
1	LY33063-003A	PACKING CASE		F,G,H,J
2	LY33065-001B	CUSHION		A,B,C,D,E,F,G
2	LY33065-001C	CUSHION		H,J
3	LY30023-027A	POLY BAG		
4	YQM30061-3	POLY BAG		A,E,F
4	QPA02003506	POLY BAG	20cm x 35cm	B,C,D,G,H,J
△ 5	LYT1134-001A	INST BOOK	(ENGLISH)	E
△ 5	LYT1098-001A	INST BOOK	(ENGLISH)	A,F
△ 5	LYT1098-003A	INST BOOK	(FRENCH)	B,G
△ 5	LYT1098-004A	INST BOOK	(DUTCH)	B,G
△ 5	LYT1098-005A	INST BOOK	(SPANISH)	B,G
△ 5	LYT1098-006A	INST BOOK	(ITALIAN)	B,G
△ 5	LYT1098-002A	INST BOOK	(GERMAN)	B,C,G,H
△ 5	LYT1098-007A	INST BOOK	(DANISH)	C,H
△ 5	LYT1098-008A	INST BOOK	(FINNISH)	C,H
△ 5	LYT1098-009A	INST BOOK	(SWEDISH)	C,H
△ 5	LYT1098-010A	INST BOOK	(NORWEGIAN)	C,H
△ 5	LYT1098-011A	INST BOOK	(RUSSIAN)	D,J
△ 5	LYT1098-012A	INST BOOK	(CZECH)	D,J
△ 5	LYT1098-013A	INST BOOK	(POLISH)	D,J
△ 5	LYT1098-014A	INST BOOK	(HUNGARIAN)	D,J
6	LYT1135-001A	INST BOOK	(SOFT.ENGLISH)	E
6	LYT1086-001A	INST BOOK	(SOFT.ENGLISH)	F
6	LYT1086-003A	INST BOOK	(SOFT.FRENCH)	G
6	LYT1086-004A	INST BOOK	(SOFT.DUTCH)	G
6	LYT1086-005A	INST BOOK	(SOFT.SPANISH)	G
6	LYT1086-006A	INST BOOK	(SOFT.ITALIAN)	G
6	LYT1086-002A	INST BOOK	(SOFT.GERMAN)	G,H
6	LYT1086-007A	INST BOOK	(SOFT.DANISH)	H
6	LYT1086-008A	INST BOOK	(SOFT.FINNISH)	H
6	LYT1086-009A	INST BOOK	(SOFT.SWEDISH)	H
6	LYT1086-010A	INST BOOK	(SOFT.NORWEGIAN)	H
6	LYT1086-011A	INST BOOK	(SOFT.RUSSIAN)	J
7	BT-54008-4	WARRANTY CARD		A,E,F
7	BT-54013-5	WARRANTY CARD		B,C,D,G,H,J
8	YU30878	REGIST. CARD		E,F
9	LYT0194-001B	Q.CARD(JUK)		A,E,F
20	QPA01703005	POLY BAG	17cm x 30cm	
23	QAM0451-001	USB CABLE		F,G,H,J
24	QQR0491-002	FERRITE CORE	TDK (BLACK)	F,G,H,J
25	QAM0212-001	A/V CABLE		
26	QQR0918-002	CORE FILTER		
△ 27	LY20955-001C	AC ADAPTER	AP-V13E	
△ 27	or LY20956-001B	AC ADAPTER	AP-V11E	
28	QQR0917-002	CORE FILTER		
△ 29	QMPP110-190-JR	POWER CORD(EK)	1.9m BLACK	A,E,F
△ 29	QMPL120-190-JR	POWER CORD(EU)	1.9m BLACK	B,C,D,G,H,J
30	QPA02503505P	POLY BAG	25cm x 35cm	
△ 31	LY32566-001A	BATT.PACK ASSY	BN-V408U-B	
32	LY20186-004A	SHOULDER STRAP		
33	LY21020-001A	REMOCON	RM-V718U	
34	QQR0491-002	FERRITE CORE	TDK (BLACK)	
36	LY44002-001B	CAP(HOOD)ASSY		
37	LY32210-059A	CD ROM ASSY		E
37	LY32210-048A	CD ROM ASSY		F,G,H,J
40	QQR0491-002	FERRITE CORE	TDK (BLACK)	
41	QAM0302-001	ADAPTOR PLUG		

FINAL ASSEMBLY <M2>

△ Symbol No.	Part No.	Part Name	Description	Local
101	LY20941-007J	U.CASE(2.5)ASSY		A,B,C,D,E
101	LY20941-003J	U.CASE(2.5)ASSY		F,G,H,J
101A	LY40664-001A	SPACER	(x2)	
101E	LY33042-001A	C.LABEL(VF)		
101F	LY30030-0F2A	SPACER(A)		
102	LY30018-0D6A	SPECIAL SCREW	(x2)	
103	LY33044-001D	BKT(HINGE2.5)		

△ Symbol No.	Part No.	Part Name	Description	Local
104	LY30018-096A	SPECIAL SCREW	(x2)	
105	QAS0126-001	SPEAKER		
106	LY30018-017A	SPECIAL SCREW	(x2)	
108	LY30018-059A	SPECIAL SCREW	(x4)	
109	LY33049-002A	COVER(UPPER2.5)		
110	LY30018-056A	SPECIAL SCREW	(x2)	
111	LY30018-0E6A	SPECIAL SCREW	(x2)	
112	LY33050-002C	COVER(JIG)		
114	QUQ105-4007AA	FFC WIRE MONI CN761-MAIN CN101		
115	LY33033-001A	ORNAMENT(2.5 2)		A,B,C,D,E
115	LY33009-001A	ORNAMENT(2.5 1)		F,G,H,J
116	LY30018-0E6A	SPECIAL SCREW	(x2)	
117	LY30018-0A1A	SPECIAL SCREW		
118	LY30018-096A	SPECIAL SCREW	(x2)	
119	LY30018-096A	SPECIAL SCREW		
120	LY33025-001B	TOP COVER ASSY		
120A	LY40162-001A	BKT		
121	LY30018-096A	SPECIAL SCREW		
122	LY30018-096A	SPECIAL SCREW		
123	LY44187-006A	STICKER(2)		A,B,C,D,E
123	LY44187-004A	STICKER(2)		F,G,H,J
125	LY30018-0E6A	SPECIAL SCREW	(x2)	
126	LY30030-0E3B	SPACER(A)		
127	LY30030-0E5A	SPACER(A)		
135	LY20943-002E	F.COVER ASSY		
135A	LY33056-001B	HOOD		
135B	LY33057-001A	RING		
135C	LY33058-001A	HOOD(SCREW)		
135D	LY33059-001B	BKT(FRONT)		
135E	LY44186-002A	STICKER(1)		
135F	LY30018-0E6A	SPECIAL SCREW		
135G	LY30018-052A	SPECIAL SCREW	(x3)	
136	LY20944-001B	MIC		
137	LY30018-0G6A	SPECIAL SCREW		
△ 145	LY20938-001E	REAR UNIT		
146	LY30018-0G6A	SPECIAL SCREW	(x2)	
147	LY30018-0J1A	SPECIAL SCREW	(x2)	
148	LY30018-0H3A	SPECIAL SCREW		
155	LY20935-002E	LOWER CASE ASSY		
155A	LY33402-001A	COVER(LOWER)		
155B	LY30018-0E6A	SPECIAL SCREW	(x2)	
156	LY20939-001F	ARM ASSY		
156A	LY30002-046B	COMPRES. SPRING	(x2)	
156B	LY43973-001A	TENSION SPRING		
157	QUQ105-2203AA	FFC WIRE JACK CN501-MAIN CN102		
158	LY30018-096A	SPECIAL SCREW		
159	LY30018-059A	SPECIAL SCREW	(x2)	
160	LY30018-096A	SPECIAL SCREW	(x2)	
161	LY10453-001E	ZOOM UNIT		
162	LY30018-0E6A	SPECIAL SCREW		
163	LY33395-001A	BRACKET(ZOOM)		
164	LY30018-059A	SPECIAL SCREW		
165	LY20937-003B	C.COVER ASSY		
165A	LY33027-001B	KNOB(LOCK)		
165B	LY33028-001A	HOLDER(LOCK)		
165C	LY33397-001A	HOOK(G.B)		
165D	LY33039-001A	BKT(G.BELT)		
165E	LY20945-003A	GRIP BELT		
165F	LY44178-001A	SHEET(C.COV)		
165G	LY30018-0E6A	SPECIAL SCREW		
165H	QYSLSF2040D	TAP SCREW	2mm x 4mm(x2)	
165J	QYSLSF2040D	TAP SCREW	2mm x 4mm(x2)	
165K	QYSLSF2040D	TAP SCREW	2mm x 4mm	
165L	LY30018-0H1A	SPECIAL SCREW	(x2)	
166	LY30018-0K3A	SPECIAL SCREW	(x2)	
167	LY30018-096A	SPECIAL SCREW	(x2)	
168	LY30018-059A	SPECIAL SCREW	(x2)	
169	LY31019-001A	BASE		
170	LY30018-0E6A	SPECIAL SCREW	(x2)	
171	LY33396-001B	HOLDER(JACK)		
172	LY30018-0E6A	SPECIAL SCREW		
173	LY33037-001B	COVER(ZOOM)		
174	LY30018-084A	SPECIAL SCREW	(x3)	
175	LY33029-001B	COVER(ADJUST)		
176	LY33024-001C	COVER(JACK)		
178	LY30018-017A	SPECIAL SCREW		
191	LY33019-001B	BKT(MECHA)ASSY		

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
191A	LY42796-003A	BUSH	(x3)	
192	LY30019-028A	SPECIAL SCREW	(x3)	
193	LY30018-056A	SPECIAL SCREW	(x2)	
194	LY40699-002A	LABEL(PUSH)		
195	LY32001-002A	LABEL(HOUSING)		
196	LY33388-001C	SHIELD COVER(PR)		
197	QYSPSPT1414M	SCREW	1.4mm x 1.4mm(x2)	
198	LY30018-096A	SPECIAL SCREW	(x2)	
199	LY30019-038A	SPECIAL SCREW	(x2)	
200	LY30018-096A	SPECIAL SCREW	(x2)	
201	LY30018-017A	SPECIAL SCREW		
202	QUQ105-24X8AA	FPC WIRE OP BLOCK-MAIN CN108		
203	QAL0465-001	FPC CCD CN5001-MAIN CN107		
215	LY43965-001D	BKT(OP)ASSY		
215A	LY30030-095A	SPACER(A)		
215B	LY30030-096A	SPACER(A)		
215C	LY43966-001A	RUBBER(OP)	(x2)	
215D	LY30030-0E5A	SPACER(A)		
216	LY30018-0G9A	SPECIAL SCREW	(x2)	
217	LY30030-057A	SPACER(A)		
218	LY30030-050A	SPACER(A)		
219	LY30030-060A	SPACER(A)		
251	LY33085-001F	OP BLOCK ASSY		
251A	LY30724-001B	FOCUS MOTOR		
251B	LY30723-001B	ZOOM MOTOR		
251C	PTY33085-001	SCREW	(x7)	
251D	PTY31727-116	SCREW	(x2)	
251E	PTY33085-007	IRIS MOTOR UNIT		
252	LY44120-001A	OP LPF		
253	LY44005-001A	SHEET		
254	LY33288-001A	SPACER		
255	LYH30446-002A	CCD BASE ASSY		
256	LY30018-0E7A	SPECIAL SCREW	(x2)	
257	LY30030-093A	SPACER(A)		
258	LY30030-094A	SPACER(A)		
259	LY30029-0Q7A	SPACER(A)		

MECHANISM ASSEMBLY <M3>

△ Symbol No.	Part No.	Part Name	Description	Local
900	YMA0029H	MECHA(A)ASSY		
900A	YMA0029D	MECHA(A)ASSY		
901	LY32870-001G	CASSETTEHOUSING ASSY		
902	YQ43893-8	MINI SCREW	(x3)	
903	LYH30420-001A	UPPER BASE ASSY		
904	QYSPSPU1425M	SCREW		
905	YDV2102B	DRUM ASSY		
906	LY42820-001A	DAMP.SCREW ASSY	(x2)	
907	LY42820-002A	DAMP.SCREW ASSY		
908	LY31538-001F	REEL DISK ASSY		
909	LY31538-002H	REEL DISK ASSY		
910	YQ44246	SLIT WASHER		
911	LY10372-001D	REEL COVER ASSY		
912	LY42120-002A	MINI SCREW		
913	LY41945-003A	MINI SCREW	(x2)	
914	YQ44246	SLIT WASHER		
915	LY43725-001D	TENSION ARM ASSY		
916	LYH40269-001A	SLANT POLE ARM ASSY		
917	LY43731-001F	TU ARM ASSY		
918	LY31531-001D	SWING ARM ASSY		
919	YQ43893	MINI SCREW		
920	LYH30424-001A	SLIDE DECK FINAL ASSY		
921	YQ43893	MINI SCREW	(x2)	
922	LY43023-001A	MINI SCREW		
924	LYH30419-001A	PAD ARM ASSY		
925	YQ44246	SLIT WASHER		
928	LYH40270-001A	TU BRAKE ASSY		
929	YQ44246	SLIT WASHER		
930	LY43684-001A	TENSION CONTROL LEVER ASSY		
931	LY32861-001A	CENTER GEAR		
932	LY31516-001F	PINCH ROLLER ARM FINAL ASSY		
933	YQ44246	SLIT WASHER		
934	LY43681-001A	TENSION CONTROL PLATE ASSY		
935	LY43687-001A	BRAKE CONTROL LEVER ASSY		
936	LYH30421-001A	MOTOR BRACKET ASSY		

△ Symbol No.	Part No.	Part Name	Description	Local
936A	QAR0138-001	LOADING MOTOR		
936B	LY41940-001A	TAPPING SCREW	(x2)	
937	YQ43893	MINI SCREW	(x3)	
938	LYH30422-001A	GUIDE RAIL ASSY		
939	YQ43893	MINI SCREW		
940	YQ44246	SLIT WASHER	(x2)	
941	LY32843-001A	SLIDE LEVER2 ASSY		
942	LY43690-001A	LOADING PLATE ASSY		
943	YQ44246	SLIT WASHER		
944	LY32858-001A	EJECT LEVER		
945	YQ44246	SLIT WASHER		
946	LYH40271-001A	BASE R ASSY		
947	YQ43893	MINI SCREW		
948	LY41945-001B	MINI SCREW		
949	LY43665-001A	MODE GEAR		
950	QSW0876-003	ROTARY ENCODER		
951	YQ43893	MINI SCREW	(x2)	
952	LY32860-001A	GEAR COVER ASSY		
953	YQ43893	MINI SCREW	(x2)	
954	YQ43893-4	MINI SCREW		
955	LY43676-001A	MAIN CAM ASSY		
956	LY41941-001B	SLIDE ARM ASSY		
957	LY43678-001A	CONNECT GEAR 2		
958	LY41954-001C	SUB CAM ASSY		
959	LY42120-001A	MINI SCREW		
960	LY43692-001A	CONTROL ARM ASSY		
961	LY32859-001A	REEL GEAR 1		
962	LY31508-002B	DRUM BASE ASSY		
963	QYSPSPU1425M	SCREW	1.4mm x 2.5mm(x3)	
964	QAR0142-001	CAPSTAN MOTOR		
965	YQ43893	MINI SCREW		
966	LY10367-001D	MAIN DECK ASSY		
976	YQ44246	SLIT WASHER		
977	YQ44246-6	SLIT WASHER		
978	LY42047-005A	WASHER		
979	LY43987-001B	SPACER		

ELECTRONIC VIEWFINDER ASSEMBLY<M4>

△ Symbol No.	Part No.	Part Name	Description	Local
300	LY21043-001E	VF ASSY		
301	LY32995-001B	EYE CUP		
302	LY43961-001B	SHEET(LENS)		
303	LY32472-001A	LENS ASSY		
304	LY43868-001A	SPRING(LENS)		
305	LY32993-001C	GUIDE LENS(VF)		
306	LY33006-001C	LEVER(LENS)		
307	LY33442-001B	LCD UNIT ASSY		
308	LY20931-001B	U.CASE(VF)R		
309	LY20930-001B	U.CASE(VF)F		
310	LY33083-001A	PROTECTOR(VF)	(x2)	
311	QAL0466-002	FPC		
312	NSW0200-001X	LEVER SWITCH VF SW		
313	LY30030-059B	SPACER(A)		
314	LY30018-031A	SPECIAL SCREW	(x2)	
315	LY32996-001B	COVER(VF)		
316	LY30018-022A	SPECIAL SCREW	(x6)	
317	LY20929-001C	B.CASE(VF)		
318	LY33076-001E	VF HINGE ASSY		
318A	LY43962-001C	TOR.SPRING		
318B	LY30019-048A	SPECIAL SCREW		
319	LY30018-084A	SPECIAL SCREW	(x7)	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

MONITOR ASSEMBLY (2.5 INCH) <M5>

△ Symbol No.	Part No.	Part Name	Description	Local
500	LY21042-004B	MONITOR ASSY		
501	LY20932-003E	M.COVER(2.5)ASSY		
501A	LY33007-001C	KNOB(LOCK)M		
501B	LY33008-001A	HOLDER(LOCK)M		
501C	LY30002-047A	COMPRES. SPRING		
501D	LY30018-0C8A	SPECIAL SCREW	(x2)	
501E	LY30030-0E5A	SPACER(A)		
502	LY10407-001C	MONI.CASE(2.5)		
503	QYSPSPT1730R	SCREW	1.7mm x 3mm(x2)	
504	LY30018-0K9A	SPECIAL SCREW	(x2)	
506	LY33011-001C	LCD FRAME(2.5)		
507	QLD0262-001	LCD MODULE		
508	LY30029-0R5A	SPACER(A)	(x3)	
510	LY33010-001A	SHIELD CASE(2.5)		
512	QYSPSPT1720R	SCREW	1.7mm x 2mm	
513	LY33012-001A	DIFF.SHEET(2.5)		
514	LY43938-001A	LIGHT SCREEN		
515	LY33013-003B	MONI.HINGE ASSY		
515A	LY33015-002A	HINGE COVER(U)		
515B	LY32969-002A	HINGE COVER(L)		
515C	LY30018-0K1A	SPECIAL SCREW	(x2)	
516	LY43936-001A	HOLDER(LAMP)	(x2)	
517	LY43396-001A	SHEET(REFLECT)		
518	QLL0142-001	LAMP		

MAIN BOARD ASSEMBLY <01>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	YB10404J-02	MAIN BOARD ASSY		A,B,C,D,E
PW1	YB10404K-02	MAIN BOARD ASSY		F,G,H,J
IC1001	MN103S33NJD	IC(MICRO C ROM)		
IC1001 or	MN103SF33NY4JD	IC(MICRO C ROM)		
IC1002	MB90097PFV149-X	IC(MICRO C ROM)		
IC1003	SN74AHC1G00K-X	IC		
IC1003 or	SN74AHC1G00DC-X	IC		
IC1004	S-89220ACNC-W	IC		
IC1005	X25330S8I-2.5-X	IC		
IC1005 or	AT25320N-10SI-X	IC		
IC1005 or	M95320-WMN6-X	IC		
IC1005 or	25LC320-I/SN-X	IC		
IC1005 or	CAT25C32SI-X	IC		
IC1006	RS5C314-X	IC		
IC1007	IC-PST3423U-X	IC		
IC1007 or	S-80823CNNB-X	IC		
IC2101	AK5355VT-X	IC		F,G,H,J
IC2201	AK4564VQ	IC		
IC3001	JCY0152	IC		
IC3002	BU2501FV-X	IC		
IC3005	JCY0136-X	IC		
IC3701	BA7665FS-X	IC		
IC3851	JCP8055FP	IC		
IC4201	HD49340NP-X	IC		
IC4202	MM1613AN-X	IC		
IC4301	JCY0200	IC		
IC4302	R1160N151B-X	IC		
IC4802	BA10358FVM-W	IC		
IC4803	BA10358FVM-W	IC		
IC4804	UPC358G2/5/-W	IC		
IC4851	UPD16879GS-X	IC		
IC5501	JCY0185	IC		
IC6001	FA3698F	IC		
IC6801	R1224N102G-X	IC		
IC8701	PIX-MC10	IC		F,G,H,J
IC8702	MT48LC1M16TG-6S	IC		F,G,H,J
Q1001	DTA114EE-X	DIGI TRANSISTOR		
Q1001 or	PDTA114EE-X	DIGI TRANSISTOR		
Q1001 or	RN2102-X	DIGI TRANSISTOR		
Q1001 or	BCR183T-X	DIGI TRANSISTOR		
Q1002	UMC3N-W	DIGI TRANSISTOR		
Q1003	UMC3N-W	DIGI TRANSISTOR		
Q1004	UMC3N-W	DIGI TRANSISTOR		
Q1005	DTC143XE-X	DIGI TRANSISTOR		
Q1006	UMC3N-W	DIGI TRANSISTOR		
Q1007	2SC4617/QR/-X	TRANSISTOR		
Q1007 or	BC847BT-X	TRANSISTOR		
Q1008	DTC124EE-X	DIGI TRANSISTOR		
Q1008 or	PDTC124EE-X	DIGI TRANSISTOR		
Q1008 or	BCR141T-X	DIGI TRANSISTOR		
Q1009	2SJ347-X	MOS FET		
Q2001	UMX1N-W	PAIR TRANSISTOR		
Q2001 or	BC847S-X	PAIR TRANSISTOR		
Q2002	UMX1N-W	PAIR TRANSISTOR		
Q2002 or	BC847S-X	PAIR TRANSISTOR		
Q2003	UMX1N-W	PAIR TRANSISTOR		
Q2003 or	BC847S-X	PAIR TRANSISTOR		
Q2004	UMX1N-W	PAIR TRANSISTOR		
Q2004 or	BC847S-X	PAIR TRANSISTOR		
Q2005	UMX1N-W	PAIR TRANSISTOR		
Q2005 or	BC847S-X	PAIR TRANSISTOR		
Q2006	UMX1N-W	PAIR TRANSISTOR		
Q2006 or	BC847S-X	PAIR TRANSISTOR		
Q2202	UMX1N-W	PAIR TRANSISTOR		
Q2202 or	BC847S-X	PAIR TRANSISTOR		
Q2401	2SC4617/QR/-X	TRANSISTOR		
Q2401 or	BC847BT-X	TRANSISTOR		
Q2403	2SC4617/QR/-X	TRANSISTOR		
Q2403 or	BC847BT-X	TRANSISTOR		
Q3001	2SC4617/RS/-X	TRANSISTOR		
Q3001 or	BC847BT-X	TRANSISTOR		
Q3002	2SC4617/RS/-X	TRANSISTOR		
Q3002 or	BC847BT-X	TRANSISTOR		
Q3701	UMT1N-W	PAIR TRANSISTOR		

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
Q3701	or XP4401-W	TRANSISTOR		
Q3701	or BC856S-X	PAIR TRANSISTOR		
Q3702	UMZ1N-W	PAIR TRANSISTOR		
Q3702	or XP4601-W	TRANSISTOR		
Q3704	2SA1774/RS/-X	TRANSISTOR		
Q3704	or BC857BT-X	TRANSISTOR		
Q3705	UMT1N-W	PAIR TRANSISTOR		
Q3705	or XP4401-W	TRANSISTOR		
Q3705	or BC856S-X	PAIR TRANSISTOR		
Q4801	2SC4655/BC/-X	TRANSISTOR		
Q4806	2SC4617/QR/-X	TRANSISTOR		
Q4806	or BC847BT-X	TRANSISTOR		
Q4851	2SC4617/RS/-X	TRANSISTOR		
Q4851	or BC847BT-X	TRANSISTOR		
Q6101	SSM5G01TU-X	MOS FET		
Q6102	2SA1577/QR/-X	TRANSISTOR		
Q6102	or BC807-25W-X	TRANSISTOR		
Q6201	SSM5G01TU-X	MOS FET		
Q6301	SSM5G01TU-X	MOS FET		
Q6302	2SA1577/QR/-X	TRANSISTOR		
Q6302	or BC807-25W-X	TRANSISTOR		
Q6303	2SC4617/QR/-X	TRANSISTOR		
Q6303	or BC847BT-X	TRANSISTOR		
Q6401	SSM5G01TU-X	MOS FET		
Q6501	SSM5G01TU-X	MOS FET		
Q6601	CPH3314-X	MOS FET		
Q6602	UMX1N-W	PAIR TRANSISTOR		
Q6602	or HN1C01FU/G/-X	PAIR TRANSISTOR		
Q6602	or BC847S-X	PAIR TRANSISTOR		
Q6603	2SA1577/QR/-X	TRANSISTOR		
Q6603	or BC807-25W-X	TRANSISTOR		
Q6604	DTC144EE-X	DIGI TRANSISTOR		
Q6604	or BCR148T-X	DIGI TRANSISTOR		
Q6605	UMT1N-W	PAIR TRANSISTOR		
Q6605	or HN1A01FU/G/-X	PAIR TRANSISTOR		
Q6605	or BC856S-X	PAIR TRANSISTOR		
Q6606	2SC4617/QR/-X	TRANSISTOR		
Q6606	or BC847BT-X	TRANSISTOR		
Q6701	CPH3314-X	MOS FET		
Q6801	FML9-W	TRANSISTOR		
D1001	DA221-X	DIODE ARRAY		
D3001	EC2C01C-X	VARI CAP DIODE		
D3002	EC2C01C-X	VARI CAP DIODE		
D3003	EC2C01C-X	VARI CAP DIODE		
D3004	MA2Z720-X	SB DIODE		
D5501	1SS355-X	SI DIODE		
D6601	RB481K-X	SB DIODE		
D6602	RB480Y-W	SB DIODE		
D6701	RB160M-30-X	SB DIODE		
D6702	RB160M-30-X	SB DIODE		
△ D6801	RB715F-X	SB DIODE		
D8702	EMZ6.8N-X	Z DIODE		F,G,H,J
D8703	EMZ6.8N-X	Z DIODE		F,G,H,J
C1001	NDCA1HJ-8R0W	C CAPACITOR	8pF 50V J	
C1002	NDCA1HJ-100W	C CAPACITOR	10pF 50V J	
C1004	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1005	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1007	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1008	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1009	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1010	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1011	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1012	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1013	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1014	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1015	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1019	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1020	NCBA1EK-682W	C CAPACITOR	6800pF 25V K	
C1021	NCBA1EK-682W	C CAPACITOR	6800pF 25V K	
C1022	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1024	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1025	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1029	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1030	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C1032	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1035	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	

△ Symbol No.	Part No.	Part Name	Description	Local
C1036	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1037	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1038	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1039	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1040	NDCA1HJ-100W	C CAPACITOR	10pF 50V J	
C1041	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1042	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1043	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1044	NDCA1HJ-470W	C CAPACITOR	47pF 50V J	
C1045	NDCA1HJ-470W	C CAPACITOR	47pF 50V J	
C1046	NCF31AZ-105X	C CAPACITOR	1uF 10V Z	
C1047	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1048	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1049	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1050	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1051	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C1052	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C1053	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C1054	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C1055	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1064	NBE20JM-226X	TA E CAPACITOR	22uF 6.3V M	
C2105	NCBA1HK-222W	C CAPACITOR	2200pF 50V K	F,G,H,J
C2106	NCBA1HK-222W	C CAPACITOR	2200pF 50V K	F,G,H,J
C2107	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	F,G,H,J
C2108	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C2109	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C2110	NBE20JM-475X	TA E CAPACITOR	4.7uF 6.3V M	F,G,H,J
C2201	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2202	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2203	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2204	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2205	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2209	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2210	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2211	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2212	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2213	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2214	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2215	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2216	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2217	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2218	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2223	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2224	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2401	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2402	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2403	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2404	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2405	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2406	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2603	NCBA1CK-153W	C CAPACITOR	0.015uF 16V K	
C2604	NCBA1CK-153W	C CAPACITOR	0.015uF 16V K	
C2605	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C2606	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C2607	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C2608	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C2611	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2612	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2613	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2614	NDCA1HJ-101W	C CAPACITOR	100pF 50V J	
C2615	NDCA1HJ-101W	C CAPACITOR	100pF 50V J	
C3001	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3003	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3005	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3006	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3007	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C3008	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3009	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3011	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3012	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3013	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3015	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3016	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3017	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3020	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3021	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3022	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3023	NDCA1HJ-330W	C CAPACITOR	33pF 50V J	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local	△ Symbol No.	Part No.	Part Name	Description	Local
C3024	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		C4307	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3025	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4308	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3026	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C4309	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3027	NCBA1EK-472W	C CAPACITOR	4700pF 25V K		C4310	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3028	NDCA1EJ-271W	C CAPACITOR	270pF 25V J		C4311	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3029	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4312	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3030	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4313	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3031	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4314	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3032	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		C4315	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3033	NDCA1HJ-220W	C CAPACITOR	22pF 50V J		C4316	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3036	NDCA1HJ-8R0W	C CAPACITOR	8pF 50V J		C4317	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3037	NDCA1HJ-8R0W	C CAPACITOR	8pF 50V J		C4803	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3038	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4804	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3039	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4806	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3042	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4808	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3043	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4809	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3044	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4810	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3045	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4811	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3046	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4812	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3047	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4813	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3048	NCB31CK-473X	C CAPACITOR	0.047uF 16V K		C4814	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3049	NCBA1HK-222W	C CAPACITOR	2200pF 50V K		C4815	NCB31HK-152X	C CAPACITOR	1500pF 50V K	
C3050	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4819	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C3055	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4851	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3059	NBE20GM-226X	TA E CAPACITOR	22uF 4V M		C4852	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3060	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4853	NBE21AM-335X	TA E CAPACITOR	3.3uF 10V M	
C3064	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		C4854	NBE21AM-106X	TA E CAPACITOR	10uF 10V M	
C3066	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C4855	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C3067	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		C4858	NDCA1HJ-330W	C CAPACITOR	33pF 50V J	
C3069	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4859	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C3701	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C4860	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C3702	NDCA1HJ-560W	C CAPACITOR	56pF 50V J		C4861	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3703	NDCA1HJ-270W	C CAPACITOR	27pF 50V J		C4862	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3704	NDCA1HJ-680W	C CAPACITOR	68pF 50V J		C4864	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3705	NDCA1HJ-270W	C CAPACITOR	27pF 50V J		C4865	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3706	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C5501	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3707	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5503	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3708	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C5504	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3709	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5506	NBE40GM-476X	TA E CAPACITOR	47uF 4V M	
C3712	NEA70GM-337X	E CAPACITOR	330uF 4V M		C5507	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3713	NEA70GM-337X	E CAPACITOR	330uF 4V M		C5508	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3715	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5509	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3801	NCB21AK-105X	C CAPACITOR	1uF 10V K		C5510	NBP21VM-105X	TA E CAPACITOR	1uF 35V M	
C3802	NCB21AK-105X	C CAPACITOR	1uF 10V K		C5511	NBZ0003-475X	TA E CAPACITOR	4.7uF 20V M	
C3803	NBE20GM-476X	TA E CAPACITOR	47uF 4V M		C5512	NBE21AM-106X	TA E CAPACITOR	10uF 10V M	
C3804	NBE20GM-476X	TA E CAPACITOR	47uF 4V M		C5513	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C3851	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5514	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3852	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5515	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3853	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5516	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3854	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5517	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C3855	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C5518	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3856	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5519	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3857	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6002	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C3858	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6003	NEA71CM-106X	E CAPACITOR	10uF 16V M	
C3859	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C6004	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C3860	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6021	NCB21CK-104X	C CAPACITOR	0.1uF 16V K	
C3861	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C6022	NCB21CK-104X	C CAPACITOR	0.1uF 16V K	
C4201	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C6023	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4202	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6024	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4203	NCB21AK-105X	C CAPACITOR	1uF 10V K		C6025	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4204	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6026	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4205	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6027	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C4206	NCB21CK-105X	C CAPACITOR	1uF 16V K		C6029	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4207	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6030	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4208	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C6031	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4209	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6032	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4210	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6033	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C4211	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6034	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4212	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6035	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4213	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6036	NDCA1HJ-101W	C CAPACITOR	100pF 50V J	
C4214	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6037	NCB21CK-473X	C CAPACITOR	0.047uF 16V K	
C4216	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6038	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C4301	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6039	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4302	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6040	NCB31CK-473X	C CAPACITOR	0.047uF 16V K	
C4303	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6041	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C4304	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6042	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C4305	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6043	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C4306	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6044	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
C6045	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6101	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6103	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C6104	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C6105	NCBA1HK-561W	C CAPACITOR	560pF 50V K	
C6106	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6201	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6203	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C6204	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C6301	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6303	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C6304	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C6401	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6403	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6405	NCB31CK-683X	C CAPACITOR	0.068uF 16V K	
C6501	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6503	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6505	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6601	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6602	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6603	NCB11EK-105X	C CAPACITOR	1uF 25V K	
C6605	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6606	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6607	NCB11EK-105X	C CAPACITOR	1uF 25V K	
C6608	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C6609	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6701	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6703	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6801	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6802	NBE40JM-476X	TA E CAPACITOR	47uF 6.3V M	
C6804	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6807	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C6809	NDCA1HJ-151W	C CAPACITOR	150pF 50V J	
C8701	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	F,G,H,J
C8702	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	F,G,H,J
C8703	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8704	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8705	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8706	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8707	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8708	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8709	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8710	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8711	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8712	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8719	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
R1001	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R1002	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1003	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1006	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1007	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1008	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1009	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1010	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1011	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1012	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1013	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1014	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1015	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1016	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1017	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1018	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1019	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1020	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1021	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1022	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1023	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1024	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1025	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1027	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1030	NRSA6AJ-753W	MG RESISTOR	75kΩ 1/16W J	
R1031	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
R1032	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1033	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1034	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1035	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1037	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J	

△ Symbol No.	Part No.	Part Name	Description	Local
R1038	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1039	NRSA6AJ-152W	MG RESISTOR	1.5kΩ 1/16W J	
R1040	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1041	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1042	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1043	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1044	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1045	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R1046	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1047	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1048	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1049	NRSA6AJ-623W	MG RESISTOR	62kΩ 1/16W J	
R1050	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
R1051	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R1052	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1053	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R1054	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1055	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
R1056	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
R1057	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1058	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1059	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1060	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1061	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J	
R1062	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	
R1063	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R1064	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1065	NRSA6AJ-153W	MG RESISTOR	15kΩ 1/16W J	
R1066	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1067	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
R1068	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1069	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1070	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J	
R1071	NRSA6AJ-272W	MG RESISTOR	2.7kΩ 1/16W J	
R1072	NRSA6AJ-183W	MG RESISTOR	18kΩ 1/16W J	
R1073	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1074	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R1075	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R1076	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R1077	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1078	NRSA6AJ-393W	MG RESISTOR	39kΩ 1/16W J	
R1079	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J	
R1080	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J	
R1081	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1082	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J	
R1083	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1084	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1085	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1086	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1087	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1088	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1089	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1091	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1092	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1093	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1094	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1095	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1096	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1097	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1099	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R2001	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2002	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2003	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2004	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2005	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2006	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2007	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2008	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2009	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2010	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2011	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2012	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2101	NRSA6AJ-471W	MG RESISTOR	470Ω 1/16W J	F,G,H,J
R2102	NRSA6AJ-471W	MG RESISTOR	470Ω 1/16W J	F,G,H,J
R2105	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R2107	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R2108	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R2109	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local	△ Symbol No.	Part No.	Part Name	Description	Local
R2110	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J	R3705	NRSA6AD-301W	MG RESISTOR	300Ω 1/16W D	
R2201	NRSA6AJ-684W	MG RESISTOR	680kΩ 1/16W J		R3706	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R2202	NRSA6AJ-564W	MG RESISTOR	560kΩ 1/16W J		R3707	NRSA6AD-680W	MG RESISTOR	68Ω 1/16W D	
R2203	NRSA6AJ-393W	MG RESISTOR	39kΩ 1/16W J		R3708	NRSA6AD-680W	MG RESISTOR	68Ω 1/16W D	
R2204	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J		R3709	NRSA6AD-680W	MG RESISTOR	68Ω 1/16W D	
R2206	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J		R3710	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R2207	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J		R3711	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R2208	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J		R3712	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R2209	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J		R3713	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R2210	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3714	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
R2211	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3715	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R2212	NRSA6AJ-2R7W	MG RESISTOR	2.7Ω 1/16W J		R3722	NRSA6AD-131W	MG RESISTOR	130Ω 1/16W D	
R2213	NRSA6AJ-2R7W	MG RESISTOR	2.7Ω 1/16W J		R3724	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R2217	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R3725	NRSA6AD-131W	MG RESISTOR	130Ω 1/16W D	
R2218	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R3726	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R2219	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3727	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R2220	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3728	NRSA6AD-131W	MG RESISTOR	130Ω 1/16W D	
R2221	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3730	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R2222	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R3807	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R2223	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R3851	NRSA6AJ-101W	MG RESISTOR	100Ω 1/16W J	
R2224	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R3852	NRSA6AD-821W	MG RESISTOR	820Ω 1/16W D	
R2225	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3853	NRSA6AD-273W	MG RESISTOR	27kΩ 1/16W D	
R2226	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3854	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D	
R2229	NRSA6AJ-564W	MG RESISTOR	560kΩ 1/16W J		R3855	NRSA6AD-821W	MG RESISTOR	820Ω 1/16W D	
R2230	NRSA6AJ-564W	MG RESISTOR	560kΩ 1/16W J		R4201	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R2231	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R4202	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2401	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R4203	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2402	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R4204	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R2403	NRSA6AJ-183W	MG RESISTOR	18kΩ 1/16W J		R4205	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R2406	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4301	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R2407	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R4303	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2601	NRSA6AJ-182W	MG RESISTOR	1.8kΩ 1/16W J		R4304	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2602	NRSA6AJ-182W	MG RESISTOR	1.8kΩ 1/16W J		R4306	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2607	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R4307	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R2608	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R4308	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R2609	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J		R4309	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2610	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J		R4310	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3002	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4315	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3004	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4317	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3005	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R4319	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3006	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R4321	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3007	NRSA6AJ-562W	MG RESISTOR	5.6kΩ 1/16W J		R4326	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R3008	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R4327	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3009	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4328	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3010	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4329	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3011	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J		R4330	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3013	NRSA6AJ-242W	MG RESISTOR	2.4kΩ 1/16W J		R4331	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3014	NRSA6AJ-392W	MG RESISTOR	3.9kΩ 1/16W J		R4332	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3015	NRSA6AJ-392W	MG RESISTOR	3.9kΩ 1/16W J		R4333	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3016	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D		R4334	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3017	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D		R4335	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3018	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D		R4336	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3019	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D		R4337	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3020	NRVA6AD-512W	CMF RESISTOR	5.1kΩ 1/16W D		R4338	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R3021	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4339	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3025	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R4341	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3027	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4342	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3029	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J		R4343	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3030	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J		R4344	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3031	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J		R4345	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R3032	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J		R4346	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R3034	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R4348	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3036	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4349	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3037	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J		R4350	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3057	NRSA6AJ-151W	MG RESISTOR	150Ω 1/16W J		R4351	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3066	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J		R4352	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3067	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J		R4353	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3068	NRSA6AJ-181W	MG RESISTOR	180Ω 1/16W J		R4354	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3069	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R4355	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3071	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4356	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3074	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4804	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R3081	NRSA6AJ-471W	MG RESISTOR	470Ω 1/16W J	F,G,H,J	R4805	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R3082	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	A,B,C,D,E	R4806	NRSA6AJ-683W	MG RESISTOR	68kΩ 1/16W J	
R3083	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J	R4807	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
R3701	NRSA6AD-271W	MG RESISTOR	270Ω 1/16W D		R4808	NRSA6AJ-243W	MG RESISTOR	24kΩ 1/16W J	
R3702	NRSA6AD-271W	MG RESISTOR	270Ω 1/16W D		R4809	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J	
R3703	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R4810	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R3704	NRSA6AD-301W	MG RESISTOR	300Ω 1/16W D		R4811	NRSA6AJ-824W	MG RESISTOR	820kΩ 1/16W J	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
R4812	NRSA6AJ-153W	MG RESISTOR	15kΩ 1/16W J	
R4814	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R4815	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R4816	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R4817	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
R4818	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J	
R4819	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R4820	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R4821	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R4822	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R4823	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4824	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R4827	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4828	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4833	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R4836	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4841	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4842	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4843	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4844	NRSA6AJ-151W	MG RESISTOR	150Ω 1/16W J	
R4854	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4856	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R4857	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R4858	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R4859	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4860	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4862	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R4863	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R4864	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4865	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4866	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4867	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4868	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4870	NRSA6AJ-271W	MG RESISTOR	270Ω 1/16W J	
R4871	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4874	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4875	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R5501	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R5503	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R5504	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R5505	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R5506	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R5507	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R5509	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R5511	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R5512	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R5513	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R5514	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6021	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6022	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6023	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6024	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6025	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6026	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6027	NRSA6AD-103W	MG RESISTOR	10kΩ 1/16W D	
R6028	NRSA6AD-751W	MG RESISTOR	750Ω 1/16W D	
R6029	NRSA6AD-103W	MG RESISTOR	10kΩ 1/16W D	
R6030	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R6031	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R6033	NRSA6AJ-562W	MG RESISTOR	5.6kΩ 1/16W J	
R6034	NRSA6AJ-153W	MG RESISTOR	15kΩ 1/16W J	
R6035	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6036	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6037	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D	
R6038	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6039	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6040	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R6042	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R6044	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	
R6102	NRVA6AD-223W	CMF RESISTOR	22kΩ 1/16W D	
R6103	NRVA6AD-103W	CMF RESISTOR	10kΩ 1/16W D	
R6104	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R6105	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6106	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R6107	NRSA6AD-183W	MG RESISTOR	18kΩ 1/16W D	
R6108	NRSA6AD-123W	MG RESISTOR	12kΩ 1/16W D	
R6109	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R6202	NRSA6AD-123W	MG RESISTOR	12kΩ 1/16W D	

△ Symbol No.	Part No.	Part Name	Description	Local
R6203	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D	
R6302	NRSA6AD-183W	MG RESISTOR	18kΩ 1/16W D	
R6303	NRSA6AD-472W	MG RESISTOR	4.7kΩ 1/16W D	
R6305	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6306	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J	
R6308	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R6309	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R6402	NRSA6AD-243W	MG RESISTOR	24kΩ 1/16W D	
R6403	NRSA6AD-302W	MG RESISTOR	3kΩ 1/16W D	
R6405	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J	
R6406	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R6407	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6502	NRSA6AD-473W	MG RESISTOR	47kΩ 1/16W D	
R6503	NRSA6AD-562W	MG RESISTOR	5.6kΩ 1/16W D	
R6505	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R6506	NRSA6AJ-273W	MG RESISTOR	27kΩ 1/16W J	
R6602	NRSA6AD-114W	MG RESISTOR	110kΩ 1/16W D	
R6603	NRSA6AD-392W	MG RESISTOR	3.9kΩ 1/16W D	
R6604	NRSA6AD-114W	MG RESISTOR	110kΩ 1/16W D	
R6605	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R6606	NRSA6AD-104W	MG RESISTOR	100kΩ 1/16W D	
R6607	NRSA6AD-473W	MG RESISTOR	47kΩ 1/16W D	
R6608	NRSA6AJ-273W	MG RESISTOR	27kΩ 1/16W J	
R6609	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J	
R6610	NRSA6AD-473W	MG RESISTOR	47kΩ 1/16W D	
R6611	NRSA6AD-683W	MG RESISTOR	68kΩ 1/16W D	
R6612	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6613	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
R6614	NRSA6AD-104W	MG RESISTOR	100kΩ 1/16W D	
R6615	NRSA6AD-104W	MG RESISTOR	100kΩ 1/16W D	
R6616	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R6617	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R6618	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6619	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R6701	NRZ0058-R20X	MG RESISTOR	0.2Ω 1/2W J	
R6702	NRSA6AD-114W	MG RESISTOR	110kΩ 1/16W D	
R6703	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D	
R6704	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	
R6706	NRSA6AD-823W	MG RESISTOR	82kΩ 1/16W D	
R6707	NRSA6AD-333W	MG RESISTOR	33kΩ 1/16W D	
R6801	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6803	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6804	NRVA6AD-563W	CMF RESISTOR	56kΩ 1/16W D	
△ R6805	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6813	NRVA6AD-273W	CMF RESISTOR	27kΩ 1/16W D	
R6815	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J	
R8059	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	A,B,C,D,E
R8701	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8702	NRS181J-220X	MG RESISTOR	22Ω 1/8W J	F,G,H,J
R8703	NRS181J-220X	MG RESISTOR	22Ω 1/8W J	F,G,H,J
R8704	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	F,G,H,J
R8705	NRSA6AJ-152W	MG RESISTOR	1.5kΩ 1/16W J	F,G,H,J
R8706	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	F,G,H,J
R8707	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8708	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8709	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	F,G,H,J
R8710	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8711	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8712	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8713	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8715	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8716	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8717	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8718	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8720	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8721	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8722	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	F,G,H,J
R8723	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	F,G,H,J
R8724	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
RA1001	NRZ0034-473W	NET RESISTOR	47kΩ 1/32W J	
RA1002	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J	
RA1004	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J	
RA1005	NRZ0034-103W	NET RESISTOR	10kΩ 1/32W J	
RA1006	NRZ0034-102W	NET RESISTOR	1kΩ 1/32W J	
RA1007	NRZ0034-102W	NET RESISTOR	1kΩ 1/32W J	
RA1008	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J	
RA3001	NRZ0034-560W	NET RESISTOR	56Ω 1/32W J	
RA3002	NRZ0034-560W	NET RESISTOR	56Ω 1/32W J	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
RA3003	NRZ0034-100W	NET RESISTOR	10Ω 1/32W J	
RA3004	NRZ0034-103W	NET RESISTOR	10kΩ 1/32W J	
RA3005	NRZ0040-0R0X	NET RESISTOR	0Ω 1/16W J	
L1001	NQL402M-100X	COIL	10uH M	
L1002	NQL402M-100X	COIL	10uH M	
L2101	NQL315K-100X	COIL	10uH K	F,G,H,J
L2401	NQL402M-100X	COIL	10uH M	
L2402	NQL402M-100X	COIL	10uH M	
L2604	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
L3001	NQR0129-002X	FERRITE BEADS		
L3002	NQR0129-002X	FERRITE BEADS		
L3004	NQR0006-001X	FERRITE BEADS		
L3005	NQR0006-001X	FERRITE BEADS		
L3007	NQL085J-2R2X	COIL	2.2uH J	
L3008	NQL085J-120X	COIL	12uH J	
L3012	NQR0129-002X	FERRITE BEADS		
L3014	NQL38DK-100X	P COIL	10uH K	
L3015	NQR0006-001X	FERRITE BEADS		
L3701	NQL38DK-100X	P COIL	10uH K	
L3801	NQR0129-002X	FERRITE BEADS		
L3802	NQR0129-002X	FERRITE BEADS		
L3803	NQR0006-001X	FERRITE BEADS		
L3804	NQL38DK-100X	P COIL	10uH K	
L4201	NQR0129-002X	FERRITE BEADS		
L4301	NQR0129-002X	FERRITE BEADS		
L4302	NQR0129-002X	FERRITE BEADS		
L4802	NQL302N-100X	COIL	10uH N	
L4851	NQR0129-002X	FERRITE BEADS		
L4852	NQL315K-100X	COIL	10uH K	
L4853	NQL315K-100X	COIL	10uH K	
L5501	NQL315K-100X	COIL	10uH K	
L5502	NQR0129-002X	FERRITE BEADS		
L5503	NQR0129-002X	FERRITE BEADS		
L5504	NQR0129-002X	FERRITE BEADS		
L5505	NQL315K-100X	COIL	10uH K	
L5506	NQL315K-100X	COIL	10uH K	
L6001	NQLZ011-4R7X	COIL	4.7uH N	
L6002	NQLZ011-4R7X	COIL	4.7uH N	
L6101	NQL52EM-390X	COIL	39uH M	
L6201	NQL52EM-390X	COIL	39uH M	
L6301	NQL52EM-390X	COIL	39uH M	
L6302	NQL144K-220X	P COIL	22uH K	
L6401	NQL52EM-470X	COIL	47uH M	
L6501	NQL52EM-470X	COIL	47uH M	
L6601	NQL52EM-221X	COIL	220uH M	
L6701	NQL73EM-100X	COIL	10uH M	
L6801	NQL034K-470X	P COIL	47uH K	
L8701	NQR0129-002X	FERRITE BEADS		F,G,H,J
L8702	NQR0129-002X	FERRITE BEADS		F,G,H,J
CN101	QGF0528F1-40X	CONNECTOR	FFC/FPC (1-40)	
CN102	QGF0505F1-22X	CONNECTOR	FFC/FPC (1-22)	
CN104	QGA1002C1-11X	CONNECTOR	W-B (1-11)	
CN105	QGB0509M1-30X	CONNECTOR	B-B (1-30)	
CN106	QGA1201C2-05X	CONNECTOR	W-B (1-5)	
CN107	QGF0503C1-20X	CONNECTOR	FFC/FPC (1-20)	
CN108	QGF0503C1-24V	CONNECTOR	FFC/FPC (1-24)	
CN109	QGF0503F1-16X	CONNECTOR	FFC/FPC (1-16)	
CN110	QGF0528F1-40X	CONNECTOR	FFC/FPC (1-40)	
CN111	QGF0528F1-40X	CONNECTOR	FFC/FPC (1-40)	
△ F6001	NMFZ007-2R0X-K	FUSE	2A 32V	
△ F6301	NMFZ007-1R25X-K	FUSE	1.25A 32V	
△ F6701	NMFZ007-1R25X-K	FUSE	1.25A 32V	
△ F6801	NMFZ007-R50X-K	FUSE	0.5A 50V	
J501	NNZ0041-001X	D CONNECTOR	IEEE1394(4pin)	
J502	QNZ0616-001	USB CONNECTOR		F,G,H,J
X1001	NAX0578-001X	CRYSTAL		
X1002	NAX0564-001X	CRYSTAL		
X3002	NAX0480-001X	CRYSTAL	24.576MHz	
X5501	NAX0587-001X	CXO		
X8701	NAX0398-001X	C OSCILLATOR		F,G,H,J
OT1	LY30030-069A	SPACER(A)		
OT2	LY44158-001A	SHEET(SHIELD)		
WR1	QAL0474-001	FPC	MAIN-PREMDA CN401	
WR2	QAL0474-001	FPC	MAIN-PREMDA CN408	

MONI-BW BOARD ASSEMBLY <02>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	YB10433E	MONI-BW BOARD ASSY		
IC7601	AN12550A	IC		
IC7602	BA4558F-X	IC		
Q7601	2SC4617/QR/-X	TRANSISTOR		
Q7601 or	2SC4738/YG/-X	TRANSISTOR		
Q7601 or	2SD2216J/QR/-X	TRANSISTOR		
Q7601 or	BC847BT-X	TRANSISTOR		
Q7602	2SA1774/QR/-X	TRANSISTOR		
Q7602 or	2SA1832/YG/-X	TRANSISTOR		
Q7602 or	BC857BT-X	TRANSISTOR		
Q7603	2SC4617/QR/-X	TRANSISTOR		
Q7603 or	2SC4738/YG/-X	TRANSISTOR		
Q7603 or	2SD2216J/QR/-X	TRANSISTOR		
Q7603 or	BC847BT-X	TRANSISTOR		
Q7604	2SA1774/QR/-X	TRANSISTOR		
Q7604 or	2SA1832/YG/-X	TRANSISTOR		
Q7604 or	BC857BT-X	TRANSISTOR		
Q7608	DTC144EE-X	DIGI TRANSISTOR		
Q7608 or	UN9213J-X	DIGI TRANSISTOR		
Q7608 or	RN1104-X	DIGI TRANSISTOR		
Q7608 or	BCR148T-X	DIGI TRANSISTOR		
Q7609	2SC4617/QR/-X	TRANSISTOR		
Q7609 or	2SC4738/YG/-X	TRANSISTOR		
Q7609 or	2SD2216J/QR/-X	TRANSISTOR		
Q7609 or	BC847BT-X	TRANSISTOR		
Q7610	DTA114EE-X	DIGI TRANSISTOR		
Q7610 or	BCR183T-X	DIGI TRANSISTOR		
Q7611	DTC144EE-X	DIGI TRANSISTOR		
Q7611 or	UN9213J-X	DIGI TRANSISTOR		
Q7611 or	RN1104-X	DIGI TRANSISTOR		
Q7611 or	BCR148T-X	DIGI TRANSISTOR		
Q7612	DTA144EE-X	DIGI TRANSISTOR		
Q7612 or	UN9113J-X	DIGI TRANSISTOR		
Q7612 or	RN2104-X	DIGI TRANSISTOR		
Q7612 or	BCR198T-X	DIGI TRANSISTOR		
Q7613	2SD2654/VW/-X	TRANSISTOR		
D7602	1SS355-X	SI DIODE		
C1	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C10	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7601	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7602	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7603	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7604	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7605	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7606	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7607	NCB41CK-106X	C CAPACITOR	10uF 16V K	
C7608	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7609	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7613	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7614	NCB31HK-152X	C CAPACITOR	1500pF 50V K	
C7615	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7616	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7617	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7618	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C7619	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C7620	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7621	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7622	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7623	NBE21AM-106X	TA E CAPACITOR	10uF 10V M	
C7624	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7626	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7627	NCF31CZ-104X	C CAPACITOR	0.1uF 16V Z	
C7628	NBP41EM-475X	TA E CAPACITOR	4.7uF 25V M	
C7629	NBP21CM-335X	TA E CAPACITOR	3.3uF 16V M	
C7630	NBP41EM-475X	TA E CAPACITOR	4.7uF 25V M	
C7631	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7632	NBP41EM-475X	TA E CAPACITOR	4.7uF 25V M	
C7633	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7634	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7635	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7637	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7646	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
C7647	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7651	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7661	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7662	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7663	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7664	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7665	NBP41CM-226X	TA E CAPACITOR	22uF 16V M	
C7666	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
R3	NRSA63J-103X	MG RESISTOR	10kΩ 1/16W J	
R4	NRSA63J-332X	MG RESISTOR	3.3kΩ 1/16W J	
R5	NRSA63J-682X	MG RESISTOR	6.8kΩ 1/16W J	
R6	NRSA63J-223X	MG RESISTOR	22kΩ 1/16W J	
R7	NRSA63J-103X	MG RESISTOR	10kΩ 1/16W J	
R8	NRSA63J-332X	MG RESISTOR	3.3kΩ 1/16W J	
R7601	NRVA63D-622X	CMF RESISTOR	6.2kΩ 1/16W D	
R7602	NRSA63J-153X	MG RESISTOR	15kΩ 1/16W J	
R7603	NRSA63J-683X	MG RESISTOR	68kΩ 1/16W J	
R7608	NRSA63J-153X	MG RESISTOR	15kΩ 1/16W J	
R7609	NRVA63D-223X	CMF RESISTOR	22kΩ 1/16W D	
R7610	NRVA63D-433X	CMF RESISTOR	43kΩ 1/16W D	
R7611	NRVA63D-821X	CMF RESISTOR	820Ω 1/16W D	
R7612	NRVA63D-223X	CMF RESISTOR	22kΩ 1/16W D	
R7613	NRVA63D-223X	CMF RESISTOR	22kΩ 1/16W D	
R7614	NRVA63D-223X	CMF RESISTOR	22kΩ 1/16W D	
R7615	NRSA63J-223X	MG RESISTOR	22kΩ 1/16W J	
R7616	NRSA63J-223X	MG RESISTOR	22kΩ 1/16W J	
R7617	NRSA02J-561X	MG RESISTOR	560Ω 1/10W J	
R7618	NRSA02J-561X	MG RESISTOR	560Ω 1/10W J	
R7620	NRSA63J-335X	MG RESISTOR	3.3MΩ 1/16W J	
R7621	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7630	NRSA63J-223X	MG RESISTOR	22kΩ 1/16W J	
R7634	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7636	NRSA63J-101X	MG RESISTOR	100Ω 1/16W J	
R7637	NRSA63J-101X	MG RESISTOR	100Ω 1/16W J	
R7638	NRSA63J-101X	MG RESISTOR	100Ω 1/16W J	
R7661	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7662	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7663	NRSA63J-103X	MG RESISTOR	10kΩ 1/16W J	
R7666	NRSA63J-153X	MG RESISTOR	15kΩ 1/16W J	
R7667	NRVA63D-273X	CMF RESISTOR	27kΩ 1/16W D	
R7668	NRVA63D-273X	CMF RESISTOR	27kΩ 1/16W D	
R7669	NRVA63D-392X	CMF RESISTOR	3.9kΩ 1/16W D	
R7672	NRSA63D-394X	MG RESISTOR	390kΩ 1/16W D	
R7673	NRVA63D-473X	CMF RESISTOR	47kΩ 1/16W D	
R7674	NRVA63D-473X	CMF RESISTOR	47kΩ 1/16W D	
R7675	NRSA63J-274X	MG RESISTOR	270kΩ 1/16W J	
L7601	NQL365K-100X	COIL	10uH K	
L7602	NQL365K-470X	COIL	47uH K	
L7603	NQL365K-470X	COIL	47uH K	
L7604	NQL365K-100X	COIL	10uH K	
L7605	NQL365K-100X	COIL	10uH K	
L7607	NQL365K-100X	COIL	10uH K	
CN761	QGF0508F1-40X	CONNECTOR	FFC/FPC (1-40)	
CN763	QGF0507F3-20X	CONNECTOR	FFC/FPC (1-20)	
CN765	QGF0506F2-32X	CONNECTOR	FFC/FPC (1-32)	
SW2	NSW0145-001X	TACT SWITCH STOP		
SW3	NSW0145-001X	TACT SWITCH REW		
SW4	NSW0145-001X	TACT SWITCH FF		
SW5	NSW0145-001X	TACT SWITCH PLAY/PAUSE		
SW7	NSW0145-001X	TACT SWITCH INDEX		
SW8	NSW0145-001X	TACT SWITCH SELECT		
SW7601	NSW0200-001X	LEVER SWITCH MONI SW		

BL-2.5 BOARD ASSEMBLY <03>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	YB20938A	BL-2.5 BOARD ASSY		
IC7604	DN8797MS-X	IC		
Q7501	2SD1664/QR/-W	TRANSISTOR		

△ Symbol No.	Part No.	Part Name	Description	Local
Q7502	2SD1664/QR/-W	TRANSISTOR		
Q7503	DTA144EE-X	DIGI TRANSISTOR		
Q7503 or	UN9113J-X	DIGI TRANSISTOR		
Q7503 or	RN2104-X	DIGI TRANSISTOR		
Q7503 or	BCR198T-X	DIGI TRANSISTOR		
Q7504	DTC144EE-X	DIGI TRANSISTOR		
Q7504 or	UN9213J-X	DIGI TRANSISTOR		
Q7504 or	RN1104-X	DIGI TRANSISTOR		
Q7504 or	BCR148T-X	DIGI TRANSISTOR		
C7501	NCZ1016-120X	C CAPACITOR	12pF 2kV J	
C7502	NCB21EK-273X	C CAPACITOR	0.027uF 25V K	
C7503	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7504	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
R7501	NRSA63J-102X	MG RESISTOR	1kΩ 1/16W J	
R7502	NRSA63J-102X	MG RESISTOR	1kΩ 1/16W J	
R7503	NRSA63J-102X	MG RESISTOR	1kΩ 1/16W J	
R7504	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7511	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7512	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7513	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
L7501	NQLZ010-680X	COIL	68uH M	
△ T7501	NQS0056-001X	SW TARN SF		
CN7601	QGF0507F3-16X	CONNECTOR	FFC/FPC (1-16)	
CN7602	QGF0507F3-16X	CONNECTOR	FFC/FPC (1-16)	
CN7603	QGF0508F1-24X	CONNECTOR	FFC/FPC (1-24)	
△ F7501	NMFZ007-R40X-K	FUSE	0.4A 50V	
WR1	QAL0464-001	FPC		

CCD BOARD ASSEMBLY <04>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	YB20942A-SS	CCD BOARD ASSY		
Q5001	2SC3931/CD/-X	TRANSISTOR		
C5001	NBP41EM-475X	TA E CAPACITOR	4.7uF 25V M	
C5002	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5003	NBE21AM-106X	TA E CAPACITOR	10uF 10V M	
C5004	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5005	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5006	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5007	NCB31EK-222X	C CAPACITOR	2200pF 25V K	
R5001	NRSA63J-472X	MG RESISTOR	4.7kΩ 1/16W J	
R5002	NRSA63J-104X	MG RESISTOR	100kΩ 1/16W J	
L5001	NQL315K-100X	COIL	10uH K	
L5002	NQL315K-100X	COIL	10uH K	
CN5001	QGF0517F2-20X	CONNECTOR	FFC/FPC (1-20)	

PREMDA BOARD ASSEMBLY <05>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	YB10405A-01	PREMDA BOARD ASSY		
IC1601	BD6637KS	IC		
IC1701	LM358DMR2-X	IC		
IC1702	LM393DMR2-X	IC		
IC3501	JCY0132	IC		
IC3502	SN74AHC1G04K-X IC			
Q1601	UMC3N-W	DIGI TRANSISTOR		
D1602	DAP222-X	DIODE ARRAY		
D1602 or	MA132WA-X	SI DIODE		

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

 Symbol No.	Part No.	Part Name	Description	Local
R502	NRSA63J-684X	MG RESISTOR	680k Ω 1/16W J	
R503	NRSA63J-182X	MG RESISTOR	1.8k Ω 1/16W J	
R504	NRSA63J-222X	MG RESISTOR	2.2k Ω 1/16W J	
R505	NRSA63J-103X	MG RESISTOR	10k Ω 1/16W J	
R506	NRSA63J-824X	MG RESISTOR	820k Ω 1/16W J	
R507	NRSA63J-104X	MG RESISTOR	100k Ω 1/16W J	
R508	NRSA63J-683X	MG RESISTOR	68k Ω 1/16W J	
R509	NRSA63J-822X	MG RESISTOR	8.2k Ω 1/16W J	
R510	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R511	NRSA63J-302X	MG RESISTOR	3k Ω 1/16W J	
R512	NRSA63J-470X	MG RESISTOR	47 Ω 1/16W J	
R513	NRSA63J-101X	MG RESISTOR	100 Ω 1/16W J	
R514	NRSA63J-101X	MG RESISTOR	100 Ω 1/16W J	
R515	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R516	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R517	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R518	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R519	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R520	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R521	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R522	NRSA63J-221X	MG RESISTOR	220 Ω 1/16W J	
R523	NRSA63J-331X	MG RESISTOR	330 Ω 1/16W J	
L501	NQR0251-004X	FERRITE BEADS		
L502	NQR0251-004X	FERRITE BEADS		
L503	NQR0251-004X	FERRITE BEADS		
CN501	QGF0503C1-22X	CONNECTOR	FFC/FPC (1-22)	
J501	QNS0078-001	3.5 JACK		
J502	QND0004-001	S JACK		
J503	PEMC1203	MINI JACK		
SW501	NSW0122-001X	DETECT SWITCH EJECT SW		

B/W-VF BOARD ASSEMBLY <07>

 Symbol No.	Part No.	Part Name	Description	Local
PW1	YB20940A	B/W-VF BOARD ASSY		
Q7001	PUMX1-W	PAIR TRANSISTOR		
Q7001 or	BC847S-X	PAIR TRANSISTOR		
D7001	E1S35AW0C501-X	LED		
C7001	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7002	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7003	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7004	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
R7001	NRSA63J-332X	MG RESISTOR	3.3k Ω 1/16W J	
R7002	NRSA63J-561X	MG RESISTOR	560 Ω 1/16W J	
R7003	NRSA63J-470X	MG RESISTOR	47 Ω 1/16W J	
R7004	NRSA63J-102X	MG RESISTOR	1k Ω 1/16W J	
CN7001	QGF0532F1-18X	CONNECTOR	FFC/FPC (1-18)	
CN7002	QGF0507F3-20X	CONNECTOR	FFC/FPC (1-20)	


JVC

SCHEMATIC DIAGRAMS

DIGITAL VIDEO CAMERA

GR-D20EK, GR-D20EX, GR-D20EY, GR-D20EZ, GR-D21EK,
GR-D40EK, GR-D40EX, GR-D40EY, GR-D40EZ

CD-ROM No.SML200305



Mini **DV** PAL

For disassembling and assembling of MECHANISM ASSEMBLY, refer to the SERVICE MANUAL No.86700 (MECHANISM ASSEMBLY).

SPECIFICATION

Camcorder		Connectors	
General		S-Video Output	Y : 1 V (p-p), 75 Ω , analogue C : 0.29 V (p-p), 75 Ω , analogue
Power supply	: DC 11.0 V $\overline{\text{---}}$ (Using AC Adapter) DC 7.2 V $\overline{\text{---}}$ (Using battery pack)	Input*	Y : 0.8 V (p-p) -1.2 V (p-p), 75 Ω , analogue C : 0.2 V (p-p) -0.4 V (p-p), 75 Ω , analogue
Power consumption		AV Video output	: 1 V (p-p), 75 Ω , analogue
LCD monitor off, viewfinder on	: Approx. 3.4 W	Video input*	: 0.8 V (p-p) -1.2 V (p-p), 75 Ω , analogue
LCD monitor on, viewfinder off	: Approx. 4.7 W	Audio output	: 300 mV (rms), 1 k Ω , analogue, stereo
Dimensions (W x H x D)	: 69 mm x 94 mm x 143 mm (with the LCD monitor closed and the viewfinder pushed back in)	Audio input*	: 300 mV (rms), 50 k Ω , analogue, stereo
Weight	: Approx. 525 g	DV Output	: 4-pin, IEEE 1394 compliant
Operating temperature	: 0°C to 40°C	Input*	: 4-pin, IEEE 1394 compliant
Operating humidity	: 35% to 80%	USB**	: 5-pin
Storage temperature	: -20°C to 50°C	EDIT	: $\varnothing$ 3.5 mm, 2-pole
Pickup	: 1/6" CCD	* GR-D50/D30 only	
Lens	: F 1.6, f = 2.7 mm to 43.2 mm, 16:1 power zoom lens	** GR-D50/D40 only	
Filter diameter	: $\varnothing$ 37 mm		
LCD monitor	: 2.5" diagonally measured, LCD panel/TFT active matrix system		
Viewfinder	: Electronic viewfinder with 0.24" black/white LCD		
Speaker	: Monaural		
Digital Video Camera		AC Adapter	
Format	: DV format (SD mode)	Power requirement Output	AC 110 V to 240 V $\sim$, 50 Hz/60 Hz
Signal format	: PAL standard		: DC 11 V $\overline{\text{---}}$, 1 A
Recording/Playback format	: Video: Digital component recording Audio: PCM digital recording, 32 kHz 4-channel (12-bit), 48 kHz 2-channel (16-bit)		
Cassette	: Mini DV cassette		
Tape speed	: SP : 18.8 mm/s LP : 12.5 mm/s		
Maximum recording time (using 80 min. cassette)	: SP : 80 min. LP : 120 min.		

Specifications shown are for SP mode unless otherwise indicated. E & O.E. Design and specifications subject to change without notice.

GR-D20EK, GR-D20EX, GR-D20EY, GR-D20EZ, GR-D21EK, GR-D40EK, GR-D40EX, GR-D40EY, GR-D40EZ M3D122, M3D124

COPYRIGHT © 2003 VICTOR COMPANY OF JAPAN, LTD.

No.86730SCH
2003/04

CHARTS AND DIAGRAMS

NOTES OF SCHEMATIC DIAGRAM

Safety precautions

The Components identified by the symbol  are critical for safety. For continued safety, replace safety critical components only with manufacturer's recommended parts.

1. Units of components on the schematic diagram

Unless otherwise specified.

- 1) All resistance values are in ohm. 1/6 W, 1/8 W (refer to parts list).
Chip resistors are 1/16 W.
K: K Ω (1000 Ω), M: M Ω (1000K Ω)
- 2) All capacitance values are in μ F, (P: PF).
- 3) All inductance values are in μ H, (m: mH).
- 4) All diodes are 1SS133, MA165 or 1N4148M (refer to parts list).

Note: The Parts Number, value and rated voltage etc. in the Schematic Diagram are for references only. When replacing the parts, refer to the Parts List.

2. Indications of control voltage


AUX : Active at high.

$\overline{\text{AUX}}$ or AUX(L) : Active at low.


3. Interpreting Connector indications




Removable connector



Wire soldered directly on board



Non-removable Board connector



Board to Board




Connected pattern on board
The arrows indicate signal path

Note: For the destination of each signal and further line connections that are cut off from the diagram, refer to "BOARD INTERCONNECTIONS"

4. Voltage measurement

- 1) Regulator (DC/DC CONV) circuits
REC : Colour bar signal.
PB : Alignment tape (Colour bar).
— : Unmeasurable or unnecessary to measure.
- 4) Indication on schematic diagram
Voltage Indications for REC and PB mode on the schematic diagram are as shown below.



Note: If the voltages are not indicated on the schematic diagram, refer to the voltage charts.

5. Signal path Symbols

The arrows indicate the signal path as follows.

NOTE : The arrow is DVC unique object.

-  Playback signal path
-  Playback and recording signal path
-  Recording signal path (including E-E signal path)
-  Capstan servo path
-  Drum servo path

(Example)

-  R-Y Playback R-Y signal path
-  Y Recording Y signal path

6. Indication of the parts for adjustments

The parts for the adjustments are surrounded with the circle as shown below.



7. Indication of the parts not mounted on the circuit board

"OPEN" is indicated by the parts not mounted on the circuit board.




CIRCUIT BOARD NOTES

1. Foil and Component sides

- 1) Foil side (B side) :
Parts on the foil side seen from foil face (pattern face) are indicated.
- 2) Component side (A side) :
Parts on the component side seen from component face (parts face) indicated.

2. Parts location guides


Parts location are indicated by guide scale on the circuit board.




Note: For general information in service manual, please refer to the Service Manual of GENERAL INFORMATION Edition 4 No. 82054D (January 1994).

BOARD INTERCONNECTIONS

NOTE)*: The number of patch cords are indicated by inter connected.




■ MAIN IF SCHEMATIC DIAGRAM




CPU SCHEMATIC DIAGRAM

01 MAIN(CPU)



NOTE: The parts with marked (※) is not used.



DV_MAIN SCHEMATIC DIAGRAM


5

4


3

2


1



VIDEO I/O SCHEMATIC DIAGRAM



■ CAMERA DSP SCHEMATIC DIAGRAM




	R4302	R4303
NTSC	0 Ω	*
PAL	*	0 Ω

NOTE: The parts with marked (※) is not used.

1



■ TG SCHEMATIC DIAGRAM





3

2

1

A

B

C

2-21 D

2-22

E

F

G

■ AV STRM SCHEMATIC DIAGRAM

5


4

3

2

1

0 1 MAIN(AV STRM)



NOTE: The parts with marked (※) is not used.

A

B

C

D

2-23


2-24

E

F

G


■ MONI-BW SCHEMATIC DIAGRAM



NOTE: The parts with marked (※) is not used.


y10337001a_rev0.1

BL-2.5 SCHEMATIC DIAGRAM



CCD SCHEMATIC DIAGRAM


NOTES : • IC5001 is incorporated in the CCD base assembly.
When IC 5001 needs replacement, replace the CCD base assembly in whole because it cannot be replaced alone.




	Q5002	R5005
DSC MODEL	2SC4081/QR/-X	4.7K
NON DSC MODEL	※	※

NOTE: The parts with marked (※) is not used.


JACK SCHEMATIC DIAGRAM




PREMDA IF SCHEMATIC DIAGRAM



■ MDA SCHEMATIC DIAGRAM




■ PRE/REC SCHEMATIC DIAGRAM




NOTE: The parts with marked (※) is not used.

■ B/W-VF SCHEMATIC DIAGRAM



■ ZOOM UNIT SCHEMATIC DIAGRAM


NOTES : ● The schematic diagram is only for reference. Avoid replacing individual parts.
Replace the entire unit only.



■ MAIN CIRCUIT BOARD

<01> MAIN
YB 10404-01-01


FOIL SIDE(B)



■ MAIN CIRCUIT BOARD

<01> MAIN
YB 10404-01-01

COMPONENT SIDE(A)




COMPONENT PARTS LOCATION GUIDE <MAIN> YB 10404-01-01

REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION		
CAPACITOR																							
C1001	A C 4B	C3011	A C 2A	C4214	A C 3B	C6604	B C 1A	IC1006	A C 4A	Q3704	B C 5B	R1084	B C 5B	R3068	A C 2A	R4355	A C 3C	R6309	A C 2A				
C1002	A C 4B	C3012	A C 2A	C4216	A C 3B	C6605	B C 1B	IC1007	A C 4A	Q3705	B C 5B	R1085	A C 4A	R3069	A C 2A	R4356	A C 3C	R6402	B C 1A				
C1003	A C 4A	C3013	A C 3B	C4301	A C 2B	C6606	B C 1B	IC2101	A C 5B	Q3731	B C 5A	R1086	B C 4A	R3071	A C 2A	R4804	B C 5C	R6403	B C 1A				
C1004	A C 4A	C3016	A C 2A	C4302	A C 3C	C6607	B C 1B	IC2201	A C 5A	Q3732	B C 5A	R1087	B C 4A	R3072	A C 2A	R4805	B C 5C	R6405	B C 1A				
C1005	A C 5A	C3017	A C 3B	C4303	A C 3C	C6608	B C 1B	IC3001	A C 3A	Q3733	B C 5A	R1088	B C 5A	R3073	A C 2A	R4806	B C 6C	R6406	B C 1A				
C1006	A C 4A	C3020	A C 2A	C4304	A C 2B	C6609	B C 2B	IC3002	A C 2B	Q3734	B C 5A	R1089	B C 5A	R3074	A C 2A	R4807	B C 6C	R6407	B C 1A				
C1007	A C 3A	C3021	A C 2A	C4305	A C 2C	C6701	B C 2C	IC3005	A C 2B	Q3735	B C 5A	R1091	B C 4A	R3075	A C 2B	R4808	B C 5C	R6502	B C 1A				
C1008	A C 3A	C3022	A C 2B	C4306	A C 3B	C6703	B C 2C	IC3701	B C 5A	Q4801	B C 5C	R1092	A C 4B	R3081	A C 3B	R4809	B C 5C	R6503	B C 1A				
C1009	A C 4B	C3023	A C 2B	C4307	A C 3B	C6704	B C 1A	IC3731	B C 5A	Q4802	B C 5C	R1093	B C 4B	R3082	A C 3B	R4810	B C 5C	R6505	B C 1A				
C1010	A C 4B	C3024	A C 2B	C4308	A C 3C	C6801	B C 1C	IC3801	A C 5B	Q4803	B C 5B	R1094	A C 4B	R3083	A C 3B	R4811	B C 5C	R6506	B C 1A				
C1011	B C 5B	C3025	A C 2B	C4309	A C 3C	C6802	B C 1B	IC3802	B C 5B	Q4804	B C 5C	R1095	A C 5A	R3701	B C 6B	R4812	B C 5C	R6602	B C 1A				
C1012	B C 5B	C3026	A C 3A	C4310	A C 2C	C6803	B C 2C	IC3851	B C 5B	Q4805	B C 5C	R1096	A C 4A	R3702	B C 5B	R4813	B C 5C	R6603	B C 1A				
C1013	B C 5B	C3027	A C 2B	C4311	A C 2C	C6804	B C 1B	IC4201	A C 3B	Q4806	B C 5C	R1097	A C 4A	R3703	B C 5A	R4814	B C 5C	R6604	B C 1A				
C1014	B C 5B	C3028	A C 3A	C4312	A C 2B	C6805	B C 2B	IC4202	A C 3C	Q4851	A C 5C	R1099	A C 3A	R3704	B C 5B	R4815	B C 5C	R6605	B C 1A				
C1015	B C 5B	C3029	A C 2A	C4313	A C 2B	C6806	B C 1C	IC4301	A C 3C	Q6101	B C 1B	R2001	A C 4B	R3705	B C 5B	R4816	B C 5C	R6606	B C 1B				
C1016	B C 5B	C3030	A C 3A	C4314	A C 2B	C6807	B C 1B	IC4302	A C 2B	Q6102	A C 2A	R2002	A C 4B	R3706	B C 5A	R4817	B C 5C	R6607	B C 1B				
C1017	B C 4A	C3031	A C 2A	C4315	A C 2B	C6809	B C 1C	IC4303	A C 2C	Q6201	A C 1B	R2003	A C 4B	R3707	B C 5A	R4818	B C 5C	R6608	B C 1B				
C1018	A C 4A	C3032	A C 3B	C4316	A C 3C	R8001	B C 3B	IC4802	B C 6C	Q6301	A C 1A	R2004	A C 4B	R3708	B C 6A	R4819	B C 5C	R6609	B C 1B				
C1019	A C 4A	C3033	A C 3B	C4317	A C 2C	R8002	B C 4B	IC4803	B C 5C	Q6302	A C 2A	R2005	A C 4B	R3709	B C 6A	R4820	B C 5C	R6610	B C 1B				
C1019	B C 5A	C3033	A C 3B	C4318	A C 3B	R8003	B C 3C	IC4804	B C 5C	Q6303	A C 2A	R2006	A C 4B	R3710	B C 5A	R4821	B C 5C	R6611	B C 1B				
C1020	B C 4A	C3036	A C 3B	C4803	B C 6B	R8004	B C 3C	IC4807	B C 5C	Q6401	A C 1A	R2007	A C 4B	R3711	B C 5A	R4822	B C 5C	R6612	B C 1B				
C1021	B C 4A	C3037	A C 3B	C4804	B C 5B	R8005	B C 3B	IC4851	A C 5B	Q6501	A C 1A	R2008	A C 4B	R3712	B C 5A	R4823	B C 5C	R6613	B C 1B				
C1022	A C 4B	C3038	A C 3A	C4806	B C 5C	R8006	B C 3B	IC5501	A C 4B	Q6601	B C 1B	R2009	A C 3B	R3713	B C 5A	R4824	B C 5C	R6614	B C 1B				
C1024	A C 3A	C3039	A C 3A	C4807	B C 5C	R8007	B C 3A	IC6001	B C 1A	Q6602	B C 1B	R2010	A C 3B	R3714	B C 5A	R4825	B C 5B	R6615	B C 1B				
C1025	A C 4B	C3040	A C 3B	C4808	B C 5C	R8008	B C 3B	IC6801	B C 1C	Q6603	B C 1B	R2011	A C 4B	R3715	B C 5A	R4826	B C 5C	R6616	B C 1A				
C1029	A C 4A	C3042	A C 3A	C4809	B C 6C	R8010	B C 4B	IC6802	B C 2C	Q6604	B C 1B	R2012	A C 3B	R3722	B C 5B	R4827	B C 5C	R6617	B C 2B				
C1030	A C 4A	C3043	A C 3B	C4810	B C 5C	R8011	B C 3B	IC8001	B C 4B	Q6605	B C 1B	R2013	A C 4B	R3724	B C 5B	R4828	B C 5C	R6618	B C 2B				
C1032	A C 4A	C3044	A C 2A	C4811	B C 5C	R8012	B C 3B	IC8002	B C 4B	Q6606	B C 2B	R2014	A C 4B	R3725	B C 5B	R4829	B C 5C	R6619	A C 1B				
C1035	A C 4A	C3045	A C 3A	C4812	B C 5C	R8013	B C 3B	IC8003	B C 4C	Q6701	B C 2C	R2015	A C 4B	R3726	B C 5B	R4830	B C 5B	R6701	B C 2C				
C1036	B C 5B	C3046	A C 3A	C4813	B C 5C	R8014	B C 3B	IC8004	B C 3C	Q6801	B C 1B	R2016	A C 3B	R3727	B C 5B	R4831	B C 5C	R6702	B C 1A				
C1037	A C 4A	C3047	A C 3B	C4814	B C 5C	R8015	B C 4B	IC8006	B C 4B	Q6802	B C 2C	R2017	A C 3B	R3728	B C 5B	R4833	B C 5C	R6703	B C 1A				
C1038	A C 4A	C3048	A C 2A	C4815	B C 4C	R8016	B C 3B	IC8007	B C 3C	Q6803	B C 2C	R2018	A C 3B	R3730	B C 5A	R4836	B C 5C	R6704	B C 1A				
C1039	B C 4A	C3049	A C 3A	C4819	B C 5C	R8017	B C 4B	IC8301	B C 3C	Q6804	B C 1C	R2101	A C 5A	R3731	B C 5A	R4837	B C 5C	R6705	B C 1A				
C1040	A C 4A	C3050	A C 3A	C4820	B C 5C	R8018	B C 4B	IC8302	B C 3C	Q6805	B C 1C	R2102	A C 5A	R3732	B C 5A	R4839	B C 5C	R6706	B C 1A				
C1041	B C 4A	C3055	A C 3A	C4822	B C 5C	R8019	B C 3B	IC8701	B C 2B	R8001	C C 3B	R2105	A C 5B	R3733	B C 5A	R4840	B C 5C	R6707	B C 1A				
C1042	B C 5A	C3056	A C 2B	C4823	B C 5C	R8020	B C 4B			Q8002	B C 4B	R2106	A C 5B	R3734	B C 5A	R4841	B C 5B	R6801	B C 1C				
C1043	A C 4A	C3059	A C 2B	C4851	A C 4C	R8021	B C 4B	COIL															
C1044	A C 4A	C3060	A C 2B	C4852	A C 5C	R8022	B C 4B	L1001	B C 4A	RESISTOR													
C1045	A C 4A	C3064	A C 3B	C4853	A C 6C	R8023	B C 4B	L1002	B C 5A	R1001	A C 4B	R2109	A C 4B	R3737	B C 5A	R4844	B C 5C	R6804	B C 2B				
C1046	B C 5B	C3066	A C 2B	C4854	A C 5C	R8024	B C 4B	L2101	A C 5B	R1002	A C 4B	R2110	A C 4B	R3738	B C 5A	R4845	B C 5C	R6805	B C 1B				
C1047	B C 5B	C3067	A C 2A	C4855	A C 5C	R8025	B C 4B	L2401	A C 5A	R1003	A C 4B	R2111	A C 4B	R3739	B C 5A	R4846	B C 5B	R6806	B C 2C				
C1048	B C 5B	C3068	A C 2A	C4858	A C 5B	R8026	B C 3B	L2402	A C 5A	R1004	A C 4B	R2112	A C 4B	R3740	B C 5A	R4847	B C 5C	R6807	B C 2C				
C1049	B C 5B	C3069	A C 2A	C4859	A C 5B	R8027	B C 3C	L2604	A C 5A	R1005	B C 4A	R2113	A C 4B	R3741	B C 6A	R4849	B C 5C	R6808	B C 2B				
C1050	B C 5B	C3070	A C 2A	C4860	A C 5B	R8028	B C 3C	L3001	A C 2A	R1006	A C 3A	R2114	A C 4B	R3742	B C 6A	R4850	B C 5C	R6809	B C 2C				
C1051	B C 4A	C3701	B C 6B	C4861	A C 5B	R8029	B C 3C	L3002	A C 2B	R1007	A C 4B	R2201	A C 5A	R3743	B C 6A	R4852	A C 5B	R6810	B C 2C				
C1052	B C 5A	C3702	B C 5B	C4862	A C 5B	R8030	B C 3B	L3004	A C 2A	R1008	B C 5A	R2202	A C 5A	R3744	B C 5A	R4854	A C 5B	R6811	B C 1C				
C1053	B C 4A	C3703	B C 5B	C4863	A C 5B	R8301	B C 2C	L3005	A C 2B	R1009	B C 5A	R2203	A C 5A	R3745	B C 5A	R4855	A C 5B	R6812	B C 1C				
C1054	B C 4A	C3704	B C 5B	C4864	A C 5C	R8305	B C 2B	L3007	A C 2B	R1010	A C 4B	R2204	A C 5A	R3746	B C 5A	R4856	A C 5B	R6813	B C 2B				
C1055	B C 5A	C3705	B C 5B	C4865	A C 5C	R8306	B C 2B	L3008	A C 3B	R1011	B C 4A	R2206	A C 5A	R3747	B C 5A	R4857	A C 5C	R6815	B C 1C				
C1056	A C 4B	C3706	B C 5A	C4866	A C 5B	R8307	B C 2B	L3012	A C 2A	R1012	A C 3A	R2207	A C 5A	R3748	B C 5A	R4858	A C 5C	R8001	B C 4B				
C1057	A C 4A	C3707	B C 5A	C5501	A C 4C	R8308	B C 2C	L3014	A C 2B	R1013	A C 3A	R2208	A C 5A	R3801	A C 5B	R4859	A C 5C	R8002	B C 4B				
C1058	A C 4A	C3708	B C 5A	C5503	A C 4C	R8309	B C 2C	L3015	A C 2B	R1014	B C 5B	R2209	A C 5A	R38023									

■ PREMDA CIRCUIT BOARD


<05> PREMDA
YB 10405-01-01



■ PREMDA CIRCUIT BOARD


<05> PREMDA
YB 10405-01-01

COMPONENT SIDE(A)




■ MONI-BW CIRCUIT BOARD

COMPONENT SIDE(A)



<02> MONI-BW
YB 10433

FOIL SIDE(B)




<02> MONI-BW
YB 10433

COMPONENT PARTS LOCATION GUIDE <MONI-BW> YB10433

REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION
CAPACITOR															
C1	A C 3C	C7627	A C 1C	C7667	B C 1B	L7601	B C 1B	R5	A C 2C	R7613	B C 3C	R7667	A C 2C	ZP1-3	B C 1A
C10	B C 1A	C7628	B C 3C	C7668	A C 1C	L7602	B C 1B	R6	A C 1C	R7614	B C 3C	R7668	A C 2C	ZP1-4	B C 1A
C11	B C 1A	C7629	B C 3B	C7669	A C 2C	L7603	B C 1C	R7	A C 2B	R7615	B C 3C	R7669	A C 2C	ZP1-6	B C 1B
C7601	B C 2B	C7631	B C 4C	CONNECTOR	CN761	L7604	B C 4C	R8	A C 1B	R7616	B C 3C	R7670	B C 2B	ZP1-7	B C 1A
C7602	B C 2B	C7632	B C 2C			L7605	B C 1A	R18	B C 1A	R7617	B C 4C	R7672	A C 2C	ZP1-8	B C 1A
C7603	A C 2B	C7633	B C 2C			L7606	B C 1B	R19	B C 1A	R7618	B C 4B	R7673	A C 2C	ZP1-9	B C 1B
C7604	B C 2B	C7634	B C 2C			L7607	B C 2C	R20	B C 1A	R7619	B C 3B	R7674	A C 2C	ZP2-2	B C 1A
C7605	B C 2B	C7635	B C 2C	TRANSISTOR	Q10	R21	B C 1A	R7620	B C 4B	R7675	A C 1C	ZP2-3	B C 1A		
C7606	B C 2B	C7636	B C 3B			R22	B C 1A	R7621	B C 3B	R7676	A C 2C	ZP2-4	B C 1A		
C7607	B C 2B	C7637	B C 3B			R23	B C 1A	R7622	B C 4B	OTHER	SW2	ZP2-5	B C 1A		
C7608	B C 2B	C7641	A C 3B			R24	B C 1A	R7623	B C 4B			ZP2-6	B C 1B		
C7609	B C 2B	C7643	B C 1B	R25	B C 1A	R7624	B C 3B	ZP2-7	B C 1A						
C7613	B C 1B	C7644	B C 1B	R26	B C 1A	R7625	B C 3B	ZP2-8	B C 1A						
C7614	B C 1B	C7645	B C 3C	R28	B C 1A	R7626	B C 3B	ZP2-9	B C 1A						
C7615	B C 1B	C7646	B C 1B	R29	A C 1A	R7627	B C 3B	ZP3-7	B C 1C						
C7616	B C 2B	C7647	B C 1B	R30	A C 1A	R7628	B C 3B	ZP3-8	B C 1C						
C7617	B C 2B	C7648	B C 1B	R31	A C 1A	R7629	B C 3B	ZP3-9	B C 1B						
C7618	B C 1B	C7649	B C 1B	R32	A C 2C	R7630	B C 3B	ZP3-10	B C 1B						
C7619	B C 1B	C7654	B C 1C	R33	B C 2B	R7631	A C 3B	ZP3-11	B C 1C						
C7620	B C 2B	C7655	B C 1C	R34	A C 2C	R7632	A C 3B	ZP3-12	B C 1B						
C7621	B C 2B	C7661	B C 2B	R35	B C 1B	R7633	A C 3B	ZP3-13	B C 1B						
C7622	B C 2B	C7662	B C 2B	R36	B C 1B	R7634	A C 3B	ZP3-14	B C 1B						
C7623	B C 2C	C7663	B C 2B	R37	B C 3B	R7635	B C 3B	ZP3-15	B C 1B						
C7624	B C 1C	C7664	B C 2B	R38	B C 2C	R7636	B C 3B	ZP3-16	B C 1B						
C7625	B C 2C	C7665	B C 2C	R39	B C 2C	R7637	B C 3B	ZP3-17	B C 1B						
C7626	B C 2C	C7666	A C 2C	R40	A C 1C	R7638	B C 3B	ZP3-18	B C 1B						
				R41	A C 1C	R7639	B C 3B	ZP3-19	B C 1B						
				R42	A C 1C	R7640	B C 3B	ZP3-20	B C 1B						
				R43	A C 1C	R7641	B C 3B	ZP3-21	B C 1A						
				R44	A C 1C	R7642	B C 3B	ZP3-22	B C 1A						
				R45	A C 1C	R7643	B C 3B	ZP3-23	B C 1A						
				R46	A C 1C	R7644	B C 3B	ZP3-24	B C 1A						
				R47	A C 1C	R7645	B C 3B	ZP3-25	B C 1A						
				R48	A C 1C	R7646	B C 3B	ZP3-26	B C 1A						
				R49	A C 1C	R7647	B C 3B	ZP3-27	B C 1A						
				R50	A C 1C	R7648	B C 3B	ZP3-28	B C 1A						
				R51	A C 1C	R7649	B C 3B	ZP3-29	B C 1A						
				R52	A C 1C	R7650	B C 3B	ZP3-30	B C 1A						
				R53	A C 1C	R7651	B C 3B	ZP3-31	B C 1A						
				R54	A C 1C	R7652	B C 3B	ZP3-32	B C 1A						
				R55	A C 1C	R7653	B C 3B	ZP3-33	B C 1A						
				R56	A C 1C	R7654	B C 3B	ZP3-34	B C 1A						
				R57	A C 1C	R7655	B C 3B	ZP3-35	B C 1A						
				R58	A C 1C	R7656	B C 3B	ZP3-36	B C 1A						
				R59	A C 1C	R7657	B C 3B	ZP3-37	B C 1A						
				R60	A C 1C	R7658	B C 3B	ZP3-38	B C 1A						
				R61	A C 1C	R7659	B C 3B	ZP3-39	B C 1A						
				R62	A C 1C	R7660	B C 3B	ZP3-40	B C 1A						
				R63	A C 1C	R7661	B C 3B	ZP3-41	B C 1A						
				R64	A C 1C	R7662	B C 3B	ZP3-42	B C 1A						
				R65	A C 1C	R7663	B C 3B	ZP3-43	B C 1A						
				R66	A C 1C	R7664	B C 3B	ZP3-44	B C 1A						
				R67	A C 1C	R7665	B C 3B	ZP3-45	B C 1A						
				R68	A C 1C	R7666	B C 3B	ZP3-46	B C 1A						
				R69	A C 1C	R7667	B C 3B	ZP3-47	B C 1A						
				R70	A C 1C	R7668	B C 3B	ZP3-48	B C 1A						
				R71	A C 1C	R7669	B C 3B	ZP3-49	B C 1A						
				R72	A C 1C	R7670	B C 3B	ZP3-50	B C 1A						
				R73	A C 1C	R7671	B C 3B	ZP3-51	B C 1A						
				R74	A C 1C	R7672	B C 3B	ZP3-52	B C 1A						
				R75	A C 1C	R7673	B C 3B	ZP3-53	B C 1A						
				R76	A C 1C	R7674	B C 3B	ZP3-54	B C 1A						
				R77	A C 1C	R7675	B C 3B	ZP3-55	B C 1A						
				R78	A C 1C	R7676	B C 3B	ZP3-56	B C 1A						
				R79	A C 1C	R7677	B C 3B	ZP3-57	B C 1A						
				R80	A C 1C	R7678	B C 3B	ZP3-58	B C 1A						
				R81	A C 1C	R7679	B C 3B	ZP3-59	B C 1A						
				R82	A C 1C	R7680	B C 3B	ZP3-60	B C 1A						
				R83	A C 1C	R7681	B C 3B	ZP3-61	B C 1A						
				R84	A C 1C	R7682	B C 3B	ZP3-62	B C 1A						
				R85	A C 1C	R7683	B C 3B	ZP3-63	B C 1A						
				R86	A C 1C	R7684	B C 3B	ZP3-64	B C 1A						
				R87	A C 1C	R7685	B C 3B	ZP3-65	B C 1A						
				R88	A C 1C	R7686	B C 3B	ZP3-66	B C 1A						
				R89	A C 1C	R7687	B C 3B	ZP3-67	B C 1A						
				R90	A C 1C	R7688	B C 3B	ZP3-68	B C 1A						
				R91	A C 1C	R7689	B C 3B	ZP3-69	B C 1A						
				R92	A C 1C	R7690	B C 3B	ZP3-70	B C 1A						
				R93	A C 1C	R7691	B C 3B	ZP3-71	B C 1A						
				R94	A C 1C	R7692	B C 3B	ZP3-72	B C 1A						
				R95	A C 1C	R7693	B C 3B	ZP3-73	B C 1A						
				R96	A C 1C	R7694	B C 3B	ZP3-74	B C 1A						
				R97	A C 1C	R7695	B C 3B	ZP3-75	B C 1A						
				R98	A C 1C	R7696	B C 3B	ZP3-76	B C 1A						
				R99	A C 1C	R7697	B C 3B	ZP3-77	B C 1A						
				R100	A C 1C	R7698	B C 3B	ZP3-78	B C 1A						
				R101	A C 1C	R7699	B C 3B	ZP3-79	B C 1A						
				R102	A C 1C	R7700	B C 3B	ZP3-80	B C 1A						
				R103	A C 1C	R7701	B C 3B	ZP3-81	B C 1A						
				R104	A C 1C	R7702	B C 3B	ZP3-82	B C 1A						
				R105	A C 1C	R7703	B C 3B	ZP3-83	B C 1A						
				R106	A C 1C	R7704	B C 3B	ZP3-84	B C 1A						
				R107	A C 1C	R7705	B C 3B	ZP3-85	B C 1A						
				R108	A C 1C	R7706	B C 3B	ZP3-86	B C 1A						
				R109	A C 1C	R7707	B C 3B	ZP3-87	B C 1A						
				R110	A C 1C	R7708	B C 3B	ZP3-88	B C 1A						
				R111	A C 1C	R7709	B C 3B	ZP3-89	B C 1A						
				R112	A C 1C	R7710	B C 3B	ZP3-90	B C 1A						
				R113	A C 1C	R7711	B C 3B	ZP3-91	B C 1A						
				R114	A C 1C	R7712	B C 3B	ZP3-92	B C 1A						
				R115	A C 1C	R7713	B C 3B	ZP3-93	B C 1A						
				R116	A C 1C	R7714	B C 3B	ZP3-94	B C 1A						
				R117	A C 1C	R7715	B C 3B	ZP3-95	B C 1A						
				R118	A C 1C	R7716	B C 3B	ZP3-96	B C 1A						
				R119	A C 1C	R7717	B C 3B	ZP3-97	B C 1A						
				R120	A C 1C	R7718	B C 3B	ZP3-98	B C 1A						
				R121	A C 1C	R7719	B C 3B	ZP3-99	B C 1A						
				R122	A C 1C	R7720	B C 3B	ZP3-100	B C 1A						


■ BL-2.5 CIRCUIT BOARD

COMPONENT SIDE(A)



<03> BL-2.5
YB 20938


FOIL SIDE(B)



<03> BL-2.5
YB 20938


■ JACK CIRCUIT BOARD

COMPONENT SIDE(A)



<06> JACK
YB 20943-01-01


FOIL SIDE(B)



<06> JACK
YB 20943-01-01


■ CCD CIRCUIT BOARD

COMPONENT SIDE(A)



<04> CCD
YB 20942


FOIL SIDE(B)



<04> CCD
YB 20942


■ B/W-VF CIRCUIT BOARD

COMPONENT SIDE(A)




<07> B/W-VF
YB 20940

FOIL SIDE(B)



<07> B/W-VF
YB 20940

■ POWER SYSTEM BLOCK DIAGRAM



VIDEO BLOCK DIAGRAM (1/2)


5

4

3

2

1



*1 WITH ANALOG INPUT MODEL
*2 WITHOUT ANALOG INPUT MODEL
*3 WITH EDIT MODEL
*4 WITH DSC MODEL

5



■ VOLTAGE CHARTS

<MAIN IF>			<CPU>			<DV MAIN>			<VIDEO I/O>			<CDS/DSP>			<OP DRIVE>			<TG>			<REG>			<MDA>			<PRE/REC>			<MONI BW>			<BL 2.5>		<CCD>	
MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	REC	PLAY	MODE PIN NO.	EE	MODE PIN NO.	EE	MODE PIN NO.	EE	
Q2001			IC1001	-	-	Q1009			IC3001	-	-	IC3701			IC4201			IC4802			Q4806			IC6001			Q6303			IC3501			IC7601		Q7612	
1	0	0	IC1002			D	3	3	IC3002			1	0	0	1	1.2	0	1	3.1	3.1	E	1.2	0	1	3.1	3.1	E	0	0	1	0	0	1	2.7	E	4.8
2	0.5	0.5				S	0	0	1	0	0	2	2.3	2.3	2	1.2	0	2	2.6	2.6	C	4.8	4.8	2	3	3	C	0.5	0.5	2	0.5	0.5	2	7.2	C	1.1
3	3.0	3.0				G	3	3	2	0.5	0.5	3	0	0	3	0.5	0	3	2.6	2.6	B	2	0	3	3	3	B	0	0	3	0	0	3	2.4	B	4.8
4	0	0							3	0.4	0.4	4	0	0	4	0.2	0	4	0	0	Q4851			4	3	3			4	0	1.5	4	2.5			
5	0	0							4	1.7	1.7	5	0	0	5	0	3	5	2.6	2.6	E	0	0	5	3	3	5	1.5	1.5	5	2.5	2.5	5	2.4		
6	0	0							5	0.7	0.7	6	0	0	6	0	0	6	2.6	2.6	C	3.5	3.7	6	0	0	6	1.5	1.5	6	2.4	1.6	6	2.5		
Q2002									6	2.4	2.4	7	1.9	1.9	7	0	0	7	2.6	2.6				7	1.2	1.2	7	1.5	1.5	7	1.4	0	7	2.4		
1	0	0							7	1.2	1.2	8	0	0	8	0	0	8	4.8	4.8				8	11.1	11.1	8	1.5	1.5	8	0	0	8	2.5		
2	0	0							8	3.1	3.1	9	2.3	2.3	9	1.2	0	9	0	0	E	0	0	9	1	1	9	1.6	1.6	9	1.3	3.1	9	2.4		
3	0	2.9							9	3.1	3.1	10	0	0	10	3	3	10	0	0	C	3.5	3.7	10	1.2	1.2	10	1.5	1.5	10	1.3	1.5	10	0		
4	0	0							10	3.1	3.1	11	2.1	2.1	11	0	0	11	0	0				11	2.2	2.2	11	2.8	2.8	11	3.1	3.1	11	0		
5	0.5	0							11	3.1	3.1	12	2.1	2.1	12	1.5	1.5	12	0.6	0.6				12	0	0	12	1.2	1.2	12	0	0	12	5.4		
6	0.5	0							12	2.1	2.1	13	4.8	4.8	13	3	3	13	0	0				13	0	0	13	1.6	1.6	13	4.8	4.8	13	0.2		
Q2003									13	1.1	1.1	14	1.9	1.9	14	2.5	0	14	0	0				14	0	0	14	1.5	1.5	14	0	0	14	0.2		
1	0	0							14	0	0	15	1.9	1.9	15	3	0	15	2.6	2.6				15	0	0	15	1.5	1.5	15	0	0	15	0.2		
2	0.5	0.5							15	0	0	16	4.8	4.8	16	2.4	0	16	2.6	2.8				16	0	0	16	1.5	1.5	16	0	0	16	12		
3	3.0	2.3							16	3	3	17	3	3	17	2.5	0	17	4.8	4.8				17	0.1	0.1	17	1.6	1.6	17	0	0	17	0		
4	0	0							17	3	3	18	0	0	18	0	0	18	0	0				18	0	0	18	0	0	18	3.8	1.7	18	0		
5	0	0							18	1.4	1.4	19	3	3	19	3	3	19	1.3	0.3				19	0.7	0.7	19	0.7	0.7	19	3.6	1.7	19	2.5		
6	0	0							19	1.3	1.3	20	0	0	20	1.9	0	20	1.9	0				20	1	1	20	0.4	0.4	20	3.6	1.7	20	0.1		
Q2004									20	2.8	2.8	21	1.9	0	21	1.9	0	21	0	0				21	0	0	21	1.3	1.3	21	3.8	1.7	21	6.1		
1	0	0							IC1003			22	2	0	22	2	0	22	2.2	2.2				22	2.2	2.2	22	1.3	1.3	22	0	0	22	1.7		
2	0.5	0							1	0	0.4	23	1.9	0	23	1.9	0	23	1.5	3				23	1	1	23	5.1	5.1	23	14.5	14.5	23	0		
3	2.9	0							2	0	0.4	24	1.2	0	24	1.2	0	24	1.5	3				24	0.6	0.6	24	4.3	4.3	24	2.6	2.6	24	0		
4	0	0							3	0	0	25	3	3	25	3	3	25	2	0				25	1	1	25	4.8	4.8	25	3.6	1.6	25	0		
5	0	0.5							4	0.8	1.7	26	0	0	26	0	0	26	4.8	4.8				26	0.6	0.6	26	15.1	15.1	26	3.8	1.6	26	1.5		
6	0	0.5							5	0	0	27	0	0	27	0	0	27	0	0				27	1	1	27	0.7	0.7	27	0	0	27	0		
Q2005									6	0	0	28	1.4	0	28	1.4	0	28	1.5	3				28	0.8	0.8	28	15.1	15.1	28	2.3	2.3	28	1.5		
1	0	0							7	0	0	29	2	0	29	2	0	29	1.5	3				29	1	1	29	12	12	29	3.6	1.7	29	0		
2	0.5	0.5							8	0	3.1	30	0.9	0	30	0.9	0	30	4.8	4.8				30	0.6	0.6	30	14.5	14.5	30	3.6	1.7	30	1.4		
3	2.9	2.9							Q3001			31	3	3	31	3	3	31	0	0				31	0.3	0.3	31	0.3	0.3	31	2.2	2.2	31	3.1		
4	0	0							E	1.8	1.8	32	0	0	32	0	0	32	1.5	3				32	0.6	0.6	32	0.3	0.3	32	0	0	32	3.1		
5	0	0							C	2.9	2.9	33	3	3	33	3	3	33	1.5	3				33	0.6	0.6	33	15.1	15.1	33	1.2	1.2	33			



VICTOR COMPANY OF JAPAN, LIMITED

AV & MULTIMEDIA COMPANY CAMCORDER CATEGORY 12, 3-chome, Moriya-cho, kanagawa-ku, Yokohama, kanagawa-prefecture, 221-8528, Japan

(No.86733)




Printed in Japan
200304WPC

JVC


SERVICE MANUAL

MECHANISM ASSEMBLY


DVC MECHANISM VHS-C MECHANISM VHS MECHANISM



<DVC MECHANISM>



<VHS-C MECHANISM>



<VHS MECHANISM>

TABLE OF CONTENTS

1	JIGS AND TOOLS	1-1
2	SPECIFIC SERVICE INSTRUCTIONS	2-1
3	PARTS LIST	3-1

SECTION 1

JIGS AND TOOLS

1.1 TOOLS REQUIRED FOR ADJUSTMENTS

1. Torque driver YTU94088	2. Bit YTU94088-003
3. Tweezers P-895	4. Chip IC replacement jig PTS40844-2
5. Slit washer installation jig YTU94121A	6. Cleaning cloth KSMM-01

Fig.1-1-1

1. Torque driver

Be sure to use to fastening the mechanism and exterior parts because those parts must strictly be controlled for tightening torque.

Torque setting value of torque driver is limited. At the values over the maximum torque setting value, fasten a screw manually not to damage the screw thread.

2. Bit

This bit is slightly longer than those set in conventional torque drivers.

3. Tweezers

To be used for removing and installing parts and wires.

4. Chip IC replacement jig

To be used for replacement of part.

5. Slit washer installation jig

To be used to install slit washers.

6. Cleaning cloth

Recommended cleaning cloth to wipe down the video heads, mechanism (tape transport system), optical lens surface.

SECTION 2

SPECIFIC SERVICE INSTRUCTIONS

2.1 DVC MECHANISM

2.1.1 Precautions

- (1) When fastening parts, pay careful attention to the tightening torque of each screw. Unless otherwise specified, tighten a screw with the torque of 0.055 N•m (0.56 kgf•cm).
- (2) Be sure to disconnect the set from the power supply before fastening and soldering parts.
- (3) When disconnecting/connecting wires, be careful not to get them and their connectors damaged.
- (4) When replacing parts, be very careful neither to damage other parts nor to fit wrong parts by mistake.

2.1.2 Notes on procedure for disassembly/assembly

The disassembling procedure table (Fig. 2-1-10 on page 2-4, a part of the table is shown below for reference) shows the procedure to disassemble/reassemble mechanism parts.

Carefully read the following explanation before starting actual disassembling/reassembling work. The item numbers (circled numbers) in the following explanation correspond to those appearing under respective columns of the table.

Example

NO.	PART NAME	FIG.	POINT	NOTE	REMARKS
[1]	CASSETTE HOUSING ASSY	T	Fig.2-4-3	3(S1),(L1a)-(L1e)	NOTE 1 a,b,c,d
[2]	UPPER BASE ASSY	T	Fig.2-4-4	(S2),(L2a),(L2b)	NOTE 2
[3]	DRUM ASSY	T		(S3a),2(S3b)	NOTE 3 a,b
[4]	REEL DISK ASSY(SUP)	T	Fig.2-4-5	(W4)	NOTE 4 a
[5]	REEL DISK ASSY(TU)	T		(W5a),(W5b),(W5c)	NOTE 5 a,b
[6]	REEL COVER ASSY	T		(W6),(S6a),2(S6b)	NOTE 6

↑
*1

↑
*2

↑
*3

↑
*4

↑
*5

↑
*6

↑
*7

*1 Numbers appearing in this column indicate the order to remove parts. When reassembling, follow these numbers in the reverse order. Circled numbers in this column correspond to those appearing in drawings of this section.

*2 This column shows part names corresponding to numbers in the left column.

*3 The symbol (T or B) appearing in this column shows the side which the objective part is mounted on.

T =the upper side, B =the lower side

*4 Symbols appearing in this column indicate drawing numbers.

*5 This column indicates parts and points such as screws, washers, springs, and others to be removed/fitted for disassembling/reassembling the mechanism. Besides such the parts, this column occasionally indicates working points.

P = Spring

W = Washer

S = Screw

* = Lock (L), soldering (SD), shield, connector (CN), etc.

*6 Numbers in this column represent the numbers of notes in the text.

(For parts that need phase adjustment after reassembling, refer to "MECHANISM ADJUSTMENTS".)

*7 This column indicates required after-disassembling/-reassembling work such as phase adjustment or mechanism adjustment.

Example

- Remove (W1)=Washer W1.
- Remove the solder at (SD1)=Point SD1.
- Disconnect A = Connector A.

2.1.3 DISASSEMBLY AND ASSEMBLY OF MECHANISM ASSEMBLY

2.1.3.1 General statement

The mechanism should generally be disassembled/assembled in the C.IN mode (ASSEMBLY mode). (Refer to Fig. 2-1-1,2-1-2.) However, when the mechanism is removed from the main body, it is set in the STOP mode. Therefore, after the mechanism is removed from the main body, supply 3 V DC to the electrode on the top of the loading motor to enter the mechanism mode into the C IN mode compulsory.

<Mechanism assembly/Cassette housing assembly>




Fig.2-1-1

<Back side of the mechanism assembly>




Fig.2-1-2

2.1.3.2 Explanation of mechanism mode

The mechanism mode of this model is classified into five modes as shown in Fig. 2-1-9. Each mechanism mode can be distinguished from others by the relative position of "△", "○", "○", "□" marks on the sub cam gear to the inner or outer protrusion on the main deck.

Refer to Fig. 2-1-3 to 2-1-8 below.




Fig.2-1-3




Fig.2-1-4




Fig.2-1-5




Fig.2-1-6




Fig.2-1-7




Fig.2-1-8

2.1.3.3 Mechanism timing chart




Fig.2-1-9

2.1.4 DISASSEMBLY PROCEDURE TABLE

MARK: # After assembly, perform adjustments.

NO.	PART NAME		FIG.	POINT	NOTE	REMARKS
[1]	CASSETTE HOUSING ASSY	T	Fig.2-1-14	3(S1),(L1a)-(L1e)	NOTE 1 a,b,c,d	ADJUSTMENT
[2]	UPPER BASE ASSY	T	Fig.2-1-15	(S2),(L2a),(L2b)	NOTE 2	
[3]	DRUM ASSY	T		(S3a),2(S3b)	NOTE 3 a,b	ADJUSTMENT
[4]	REEL DISK ASSY(SUP)	T	Fig.2-1-16	(W4)	NOTE 4	
[5]	REEL DISK ASSY(TU)	T		(W5a),(W5b)	NOTE 5 a,b	
[6]	REEL COVER ASSY	T		(W6),2(S6a),(S6b)	NOTE 6	
[7]	TENSION ARM ASSY	T	Fig.2-1-17	(L7)	NOTE 7	ADJUSTMENT / #
[8]	SLANT POLE ARM ASSY	T		(P8)	NOTE 8	ADJUSTMENT
[9]	TU ARM ASSY	T		(L9)	NOTE 9	ADJUSTMENT
[10]	SWING ARM ASSY	T		(S10)	NOTE 10	ADJUSTMENT
[11]	SLIDE DECK ASSY	T	Fig.2-1-18	2(S11a),(S11b),2(L11a), 2(L11b),(L11c)	NOTE 11a,b	ADJUSTMENT / #
[12]	PAD ARM ASSY	T	Fig.2-1-19	(P12),(L12),(W12)	NOTE 12	ADJUSTMENT / #
[13]	-	-		-	-	
[14]	TU BRAKE ASSY	T		(P14),(L14),(W14)	NOTE 14	ADJUSTMENT
[15]	TENSION CTL LEVER ASSY	T	Fig.2-1-20	(W15)	NOTE 15	ADJUSTMENT
[16]	CENTER GEAR	T		-	NOTE 16	
[17]	PINCH ROLLER ARM F. ASSY	T		(W17)	NOTE 17	ADJUSTMENT
[18]	TENSION CTL PLATE ASSY	T		-	NOTE 18	ADJUSTMENT
[19]	BRAKE CTL LEVER ASSY	T		-	NOTE 19	ADJUSTMENT
[20]	MOTOR BRACKET ASSY	T	Fig.2-1-21	3(S20),(L20a),2(L20b)	NOTE 20	ADJUSTMENT
[21]	GUIDE RAIL ASSY	T		2(W21),(S21),2(L21a),(L21b)	NOTE 21	ADJUSTMENT
[22]	SLIDE LEVER 2 ASSY	T		-	NOTE 22	ADJUSTMENT / #
[23]	LOADING PLATE ASSY	T		(W23)	NOTE 23	ADJUSTMENT
[24]	MODE GEAR	T		-	NOTE 24	
[25]	EJECT LEVER	T		(W25)	NOTE 25	ADJUSTMENT
[26]	BASE R ASSY	T	Fig.2-1-22	(S26a),(S26b),2(L26)	NOTE 26	ADJUSTMENT
[27]	ROTARY ENCODER	T		2(S27)	NOTE 27	PHASE ADJUSTMENT
[28]	GEAR COVER ASSY	T		(S28a),2(S28b)	-	
[29]	MAIN CAM ASSY	T		-	NOTE 29	PHASE ADJUSTMENT
[30]	SLIDE ARM ASSY	T	Fig.2-1-23	-	NOTE 30	ADJUSTMENT
[31]	CONNECT GEAR 2	T		-	NOTE 31	
[32]	SUB CAM ASSY	T		(S32)	NOTE 32	PHASE ADJUSTMENT
[33]	CONTROL ARM ASSY	T		-	NOTE 33	ADJUSTMENT
[34]	REEL GEAR 1	T		-	NOTE 34	
[35] / [36]	DRUM BASE ASSY/ CAPSTAN MOTOR	T	Fig.2-1-24	3(S35)	NOTE 35a,b	ADJUSTMENT
[36]	CAPSTAN MOTOR	T		(S36)	NOTE 36	ADJUSTMENT
[37]	MAIN DECK ASSY	T		-	-	

Fig.2-1-10




Fig.2-1-11

< TOP VIEW >




Fig.2-1-12

< BOTTOM VIEW >




Fig.2-1-13

2.1.5 DISASSEMBLY/ASSEMBLY

2.1.5.1 [1] CASSETTE HOUSING ASSY

NOTE 1a:

Be careful not to damage any of the parts during work.

NOTE 1b:

Special care is required in mounting.

NOTE 1c:

When mounting, the CASSETTE HOUSING ASSY should be attached in the Eject status. Pay heed to the positions of the LOCK LEVER and EJECT LEVER during mounting.

NOTE 1d:

When mounting, be sure to locate the FPC in the gap.





Fig.2-1-14

2.1.5.2 [2] UPPER BASE ASSY

[3] DRUM ASSY

NOTE 2:

When mounting, be sure to insert the FPC reinforcing sheet.

NOTE 3a:

Be mindful of scratches or damage during work.

NOTE 3b:

Be careful not to attach screws incorrectly.





Fig.2-1-15

2.1.5.3 [4] REEL DISK ASSY(SUP)
 [5] REEL DISK ASSY(TU)
 [6] REEL COVER ASSY

NOTE 4:

Be careful not to attach the REEL DISK wrongly. The Supply side can be identified by the white color at the center.

NOTE 5a:

Be careful not to attach the REEL DISK wrongly. The Take-up side can be identified by the black color at the center.

NOTE 5b

The washer is inserted under the REEL DISK.

Be careful not to lose the washer.

Two washers are inserted under the REEL DISK in some products manufactured earlier, but one washer is inserted in the products manufactured recently and in the future.

See the parts list, and use the parts written in the parts list.


NOTE 6:

Perform the following steps for mounting.

- (1) Align the hole with the pin.
- (2) Attach the [17] PINCH ROLLER ARM FINAL ASSY by aligning the positions.
- (3) Attach the SLIDE DECK ASSY (POINT[A]) by aligning the positions.
- (4) Check that the parts below them are located in the correct positions.
- (5) Tighten the 2 screws.
- (6) Tighten the screw.
- (7) Attach the 1 SLIT WASHER parts.

NOTE 4, 5

REEL DISK ASSY



NOTE 6





Fig.2-1-16

2.1.5.4 [7] TENSION ARM ASSY
 [8] SLANT POLE ARM ASSY
 [9] TU ARM ASSY
 [10] SWING ARM ASSY

NOTE 7:

When detaching, remove the spring of the [12] PAD ARM ASSY in advance.

Pay attention to the attachment position.

NOTE 8:

When mounting the SLANT POLE ARM ASSY, hook the spring onto the lug as in diagram A, and fit the combination onto the SLIDE DECK ASSY. After fitting, hook the spring onto the lug of the SLIDE DECK ASSY as in diagram B.

Be careful not to lose the spring.

NOTE 9:

Pay attention to the attachment position.

NOTE 10:

When detaching, remove the screw then remove the SWING ARM ASSY by pulling it up and turning it.





Fig.2-1-17

2.1.5.5 [11] SLIDE DECK ASSY

NOTE 11a:

Each of the parts on the SLIDE DECK ASSY can be replaced separately.

When detaching the assembly, if there is no need to replace any of its parts, remove the SLIDE DECK ASSY as it is.

NOTE 11b:

When mounting, pay attention to the positions of the [22] SLIDE LEVER 2 ASSY studs and the [19] BRAKE CTL LEVER ASSY.

When mounting, position the CONTROL PLATE on the left side.

Pay attention to the position of the SLIDE GUIDE PLATE during mounting.

NOTE 11b





Fig.2-1-18

2.1.5.6 [12] PAD ARM ASSY

[13] -

[14] TU BRAKE ASSY

NOTE 12:

The spring may have already been disengaged when the [8] SLANT POLE ARM ASSY was removed.

NOTES 14:

When mounting, pay attention to the correct positioning. Mount the CONTROL PLATE by moving it fully toward the left side.

NOTE 12,14





Fig.2-1-19

- 2.1.5.7 [15] TENSION CTL LEVER ASSY
 [16] CENTER GEAR
 [17] PINCH ROLLER ARM FINAL ASSY
 [18] TENSION CTL PLATE ASSY
 [19] BRAKE CTL LEVER ASSY

NOTES 15/16:

When mounting, pay attention to the correct positioning.

NOTE 17:

Take care against grease attachment during work.

NOTES 18/19:

When mounting, pay attention to the correct positioning.





Fig.2-1-20

- 2.1.5.8 [20] MOTOR BRACKET ASSY
 [21] GUIDE RAIL ASSY
 [22] SLIDE LEVER 2 ASSY
 [23] LOADING PLATE ASSY
 [24] MODE GEAR
 [25] EJECT LEVER

NOTE 20:

When mounting, pay attention to the positioning of the sliding parts.

NOTE 21:

When mounting, take care that no part is allowed to float or rattle.

NOTES 22/23/24/25:

When mounting, pay attention to the correct positioning.





Fig.2-1-21

2.1.5.9 [26] BASE R ASSY
[27] ROTARY ENCODER
[28] GEAR COVER ASSY
[29] MAIN CAM ASSY

NOTE 26:

When mounting, fold the sliding part to the inner side.

NOTE 27:

When mounting, pay attention to the correct positioning and the FPC layout.

NOTE 29:

When mounting, pay attention to the correct positioning.





Fig.2-1-22

2.1.5.10 [30] SLIDE ARM ASSY
[31] CONNECT GEAR 2
[32] SUB CAM ASSY
[33] CONTROL ARM ASSY
[34] REEL GEAR 1

NOTE 30:

When mounting, pay attention to the correct positioning.

NOTE 31:

When mounting, pay attention to the position of the front and back.

NOTES 32/33/34:

When mounting, pay attention to the correct positioning.





Fig.2-1-23

**2.1.5.11 [35] DRUM BASE ASSY
[36] CAPSTAN MOTOR
[37] MAIN DECK ASSY**

NOTES 35a/36:

Since [36]CAPSTAN MOTOR is attached to [35]DRUM BASE ASSY, remove [36]CAPSTAN MOTOR together with [35]DRUM BASE ASSY when removing [36]CAPSTAN MOTOR.

[36]CAPSTAN MOTOR should not be separated from [35]DRUM BASE ASSY except when replacing them.


NOTE 35b:

It is very important to attach [35]DRUM BASE ASSY to the proper position.

Especially, improper engagement of [36]CAPSTAN MOTOR with [34]REEL GEAR 1 causes operational deflection or abnormal sound. Therefore, confirm the attachment position before disassembly procedure.


See the following figure as for the proper attachment position.

NOTE 35b



When [35]DRUM BASE ASSY is properly attached, the screw hole tends to be located at the center of the oval.

When the screw hole is located far from the center of the oval, operational deflection or abnormal sound may occur.



Before removing [35]DRUM BASE ASSY, confirm the position of [35]DRUM BASE ASSY by seeing the length (A), as shown in the left figure.

When reattaching [35]DRUM BASE ASSY, confirm the position to reattach [35]DRUM BASE ASSY by seeing the length (A). Be sure to reattach [35]DRUM BASE ASSY to the same position as it has been before the removing procedure.




Fig.2-1-24

2.1.6 CHECKUP AND ADJUSTMENT OF MECHANISM PHASE

[24]MODE GEAR

Align the MODE GEAR with the Main Deck Assembly hole.

Note:

The MODE GEAR may be displaced during the mechanism operation, however it can be checked from the rear and realigned during manual assembly.

[27]ROTARY ENCODER

Mount the ROTARY ENCODER by aligning its mark (Δ) and the mark (∇) of the Main Deck Assembly.

Note:

Be careful when handling the FPC during mounting.

[34]REEL GEAR 1

Align the REEL GEAR 1 with the Main Deck Assembly hole.

Note:

The REEL GEAR 1 may be displaced during mechanism operation, however this can be checked from the rear and realigned during manual assembly.

[29]MAIN CAM ASSY/[30]SLIDE ARM ASSY

When mounting the SLIDE ARM ASSY align it with the Main Deck Assembly and MAIN CAM ASSY holes.

Note:

During the mounting procedure, make sure that the [32] SUB CAM ASSY is in the correct mounting position.

[32]SUB CAM ASSY/[33] CONTROL ARM ASSY

Mount the SUB CAM ASSY hole to align with the CONTROL ARM ASSY and Main Deck Assembly holes and then tighten them all together with a screw.

Note:

When mounting it, make sure that the [29]MAIN CAM ASSY is in the correct mounting position.




Fig.2-1-25

2.1.7 MECHANISM ADJUSTMENTS

2.1.7.1 Adjustment of the slide guide plate

Use Fig. 2-1-26 as the reference unless otherwise specified.

- (1) Set the PLAY mode. See Fig. 2-1-8.
- (2) Loosen the screws (A, B).
- (3) With the Main Deck and Slide Deck Assemblies pushed into the unit, tighten the screws (A, B) while applying pressure to the stud (shaft) on the Slide Guide plate.
The pressure applied should be enough to enable utilization of the rebounding force of the springs.
The tightening torque should be 0.069 N•m (0.7 kgf•cm).
- (4) Check the operation.
Repeat unloading and loading several times and make sure that these operations can be performed smoothly without producing rattles.




Fig.2-1-26

2.1.7.2 Adjustment of the Tension Arm and Pad Arm Assemblies

Use Fig. 2-1-27 as the reference unless otherwise specified.

- (1) Set the PLAY mode.
See Fig. 2-1-8.
- (2) Loosen the screw **A**.
- (3) With the take-up side at the bottom, align the extreme end of the Tension Arm Assembly with the crossed grooves on the screw **B** that retains the Loading Motor Assembly and then tighten the screw **A**.
The tightening torque should be 0.069 N•m (0.7 kgf•cm).
- (4) Check the operation.
Repeat unloading and loading several times and make sure that the Tension Arm Assembly is located within the normal range.




Fig.2-1-27




Fig.2-1-28

2.1.7.3 Adjustment of the Slide Lever 2

Use Fig. 2-1-28 as the reference unless otherwise specified.

- (1) Set the C IN mode.
See Fig. 2-1-4.
- (2) Loosen the screw **A**.
- (3) Set the Main Deck and Slide Deck Assemblies apart so that they do not rattle, then tighten the screw **A** by screwing it fully toward the Drum Assembly.
The tightening torque should be 0.069 N•m (0.7 kgf•cm).
- (4) Check the operation.
Repeat unloading and loading several times and make sure that these operations can be performed smoothly without producing rattles.

2.1.8 SERVICE NOTE

Use the following chart to manage mechanism parts that are removed for disassembling the mechanism.









Fig.2-1-14	[1] CASSETTE HOUSING ASSY 		Fig.2-1-15		[2] UPPER BASE ASSY 	
Fig.2-1-15	[3] DRUM ASSY 	Fig.2-1-16	[4] REEL DISK ASSY(SUP)  [5] REEL DISK ASSY(TU) 	[6] REEL COVER ASSY 		
Fig.2-1-17	[7] TENSION ARM ASSY 	[8] SLANT POLE ARM ASSY 		[9] TU ARM ASSY 	[10] SWING ARM ASSY 	
Fig.2-1-18	[11] SLIDE DECK ASSY 		Fig.2-1-19	[12] PAD ARM ASSY 	[13] —	[14] TU BRAKE ASSY 

Fig.2-1-29







Fig.2-1-20	[15] TENSION CTL LEVER ASSY	[16] CENTER GEAR	[17] PINCH ROLLER ARM F ASSY	[18] TENSION CTL PLATE ASSY	[19] BRAKE CTL LEVER ASSY
					
Fig.2-1-21	[20] MOTOR BRACKET ASSY	[21] GUIDE RAIL ASSY	[22] SLIDE LEVER 2 ASSY	[23] LOADING PLATE ASSY	
			[24] MODE GEAR	[25] EJECT LEVER	
Fig.2-1-22	[26] BASE R ASSY	[27] ROTARY ENCODER	[28] GEAR COVER ASSY	[29] MAIN CAM ASSY	
					
Fig.2-1-23	[30] SLIDE ARM ASSY	[31] CONNECT GEAR 2	[32] SUB CAM ASSY	[33] CONTROL ARM ASSY	[34] REEL GEAR 1
					
Fig.2-1-24	[35] DRUM BASE ASSY	[36] CAPSTAN MOTOR	[37] MAIN DECK ASSY		
					

Fig.2-1-30

2.1.9 SERVICE NOTE
 Use the following chart to manage screws.

Symbol No.	[1]	[2]	[3]	[6]	[10]	[11]	[20]	[21]	[22]
Removing order of screw	1 2 3	4	5 6 7	8 9 10	11	12 13 14	15 16 17	18	19 20
Place to stick screw									
Reference drawing (Fig. No.2-1-**)	14		15	16	17	18	21		22
Screw tightening torque	I	II							
									III

Symbol No.	[27]	[28]	[32]	[35]	[36]
Removing order of screw	21 22 23 24 25	26	27 28 29	30	
Place to stick screw					
Reference drawing (Fig. No.2-1-**)	22	23	24		
Screw tightening torque	II		IV		V

<NOTE>

•Pay careful attention to tightening torque for each screw.

I : 0.069N・m(0.7kgf・cm)

II : 0.055N・m(0.56kgf・cm)

III : 0.0198N・m(0.2kgf・cm)

IV : 0.078N・m(0.8kgf・cm)

V : 0.039N・m(0.4kgf・cm)

Fig.2-1-31

2.1.10 REMARKS

2.1.10.1 Cleaning

- (1) For cleaning of the upper drum (particularly video heads), use fine-woven cotton cloth with alcohol soaks through. Do not move the cloth but turn the upper drum counterclockwise.

NOTE:

Make sure not to move the cloth in the vertical direction to the video head, since it may cause damage of the video heads.

- (2) For cleaning of parts of the tape transport system except the upper drum, use fine-woven cotton cloth or cotton swab soaked alcohol.
- (3) After cleaning, confirm that the cleaned parts are completely dry before loading the deck with cassette tape.

2.1.10.2 Applying oil and grease

- (1) Periodical oiling and greasing are not required but should be done to new parts when replacing. If oil and grease on the other parts of the other party are old and dirty, wipe them clean and apply new oil or grease.
- (2) For parts and points to apply oil and grease, refer to the exploded view of the 3.1 DVC MECHANISM ASSEMBLY. Fig.2-1-32 specifies oil and grease to be used.
- (3) When oiling, clean the objective parts with alcohol first and apply one or two drop(s) of oil. Too much oiling causes rotary parts to slip because of oil leakage.

Classification	Part No.	Symbol in drawing
Grease	KYODO-SH-JB	AA
Oil	YTU94027	BB
Grease (HANARL)	RX-410R	CC

specifies oil and grease to be used

Fig.2-1-32

2.2 VHS-C MECHANISM

2.2.1 Precautions

- (1) When fastening parts, pay careful attention to the tightening torque of each screw. Unless otherwise specified, tighten a screw with the torque of 0.216 N•m (2.2 kgf•cm). Torque setting value of torque driver is limited. At the values over the maximum torque setting value, fasten a screw manually not to damage the screw thread.
- (2) Be sure to disconnect the set from the power supply before fastening and soldering parts.
- (3) When disconnecting/connecting wires, be careful not to get them and their connectors damaged.
- (4) When replacing parts, be very careful neither to damage other parts nor to fit wrong parts by mistake.

Example

STEP/LOC. No.	PART NAME		FIG.	REMOVAL	INSTALLATION
				POINT	ADJUSTMENT CONDITION NOTE
[1]	ROLLER BASE ASSEMBLY	T	M1	(S1)	—
[2]	TENSION ARM ASSEMBLY	T	M1	(P1), (W1a)	—
[3]	REEL DISC (SUP)	T	M1	(W1a), (W1b)	—

↑
*1

↑
*2

↑
*3

↑
*4

↑
*5

↑
*6

2.2.2 How to read the disassembly and assembly

*1 Order of steps in Procedure

When reassembling, perform the step(s) in the reverse order. These numbers are also used as the identification (location) No. of parts Figures.

*2 Part to Name be removed or installed.

*3 Location of part.

T = The Upper side
B = The Lower side

*4 Fig. No. showing Procedure or Part Location.

M = Mechanism

*5 Identification of part to be removed, unhooked, unlocked, released, unplugged, unclamped or unsoldered.

P = Spring

W = Washer

S = Screw

* = Unhook, unlock, release, unplug or unsolder.

Example

- Remove (W1)=Washer W1.
- Remove the solder at (SD1)=Point SD1.
- Disconnect A = Connector A.

*6 Adjustment information for installation.


(+) = Refer to Exploded Views for Lubrication information.

2.2.3 DISASSEMBLY/ASSEMBLY PROCEDURE TABLE

This procedure starts with the condition that the cabinet parts and deck parts. Also, all the following procedures for adjustment and parts replacement should be performed in STOP mode. When reassembling, perform the step(s) in the reverse order.

STEP/LOC. No.	PART NAME		FIG.	REMOVAL	INSTALLATION
				POINT	ADJUSTMENT CONDITION NOTE
[1]	ROLLER BASE ASSY	T	M1	(1)	—
[2]	TENSION ARM ASSY	T	M1	(P1), (W1a)	—
[3]	REEL DISC	T	M1	(W1a), (W1b)	—
[4]	SLANT ARM ASSY	T	M1	(W1a)	—
[5]	CANCEL LEVER ASSY	T	M2	(W2)	—
[6]	EJECT LEVER ASSY	T	M2	(W2)	—
[7]	CASSETTE GUIDE (LEFT)	T	M2	(2)	—
[8]	SUPPLY CLUTCH ASSY	T	M2	(W2)	—
[9]	WHEEL GEAR	T	M2	(W2)	See, Adjustment procedure for Section 2.2.5
[10]	ROTARY ENCODER	B	M3	4(S3a)	The function of this part varies according to the ASSY (VHS/SVHS) which this part is incorporated in. (Refer to fig. 2-2-6)
[11]	TIMING BELT	B	M3	—	—
[12]	CENTER PULLEY UNIT	T/B	M3	2(S3a)	—
[13]	CASSETTE GUIDE (R) ASSY	T	M3	(S3b), (P3)	(Only use SVHS model)
[14]	TAKE UP GEAR	T	M3	(W3a)	—
[15]	BRAKE SUB GEAR	T	M3	(W3a)	—
[16]	PINCH ROLLER ARM ASSY	T	M3	(W3b)	—
[17]	TAKE UP GUIDE ARM ASSY	T	M3	(W3a)	—
[18]	LINK ARM ASSY	T	M4	(W4)	—
[19]	LED GUIDE	T	M4	(S4a)	—
[20]	A/C HEAD UNIT	T	M4	2(S4b)	—
[21]	SLANT POLE BASE ASSY	T	M5	(S5a)	—
[22]	CAPSTAN MOTOR	T	M5	3(S5a)	—
[23]	MOTOR BASE	T	M5	2(S5b), (S5c)	—
[24]	BRUSH	B	M6	(S6a)	—
[25]	DRUM FINAL ASSY	T/B	M6	2(S6b), 2(S6c) *CATCHER	—
[26]	GUIDE RAIL	T	M6	7(S6d), 8(S6d)	(Refer to part list.)
[27]	POLE BASE (S)ASSY	T	M6	—	—
[28]	POLE BASE (T)ASSY	T	M6	—	—
[29]	COVER PLATE	T	M7	—	—
[30]	DRIVE LEVER ASSY	T	M7	—	—
[31]	MOTOR BRACKET ASSY	T	M7	3(S7)	—
[32]	CONTROL CAM	T	M8	(W8a)	See, Adjustment procedure for Section 2.2.5
[33]	LINK LEVER	T	M8	—	See, Adjustment procedure for Section 2.2.5
[34]	MIDDLE GEAR	T	M8	—	—
[35]	LOADING GEAR(T) ASSY	T	M8	(W8b)	See, Adjustment procedure for Section 2.2.5
[36]	LOADING GEAR(S) ASSY	T	M8	(W8b)	—
[37]	LOADING RING ASSY	T	M8	4(S8)	See, Adjustment procedure for Section 2.2.5

Fig.2-2-1



<TOP VIEW>




Fig.2-2-3

<BOTTOM VIEW>




Fig.2-2-4




Fig.M1




Fig.M3





Fig.M2



* 0.118 N·m (1.2 kgf·cm)

Fig.M4




Fig.M5




Fig.M7




Fig.M6




Fig.M8

2.2.4 CHECKUP AND ADJUSTMENT OF MECHANISM PHASE

NOTE:

Pay careful attention to the installing order and phase of mechanism parts of the loading system.




Fig.2-2-5 Top of main deck




Fig.2-2-6 Rotary encoder

2.2.5 SERVICE NOTE

Use the following chart to manage screws.

Symbol No.	[1]	[7]	[10]				[12]	[13]	[19]	[20]	[21]	[22]	[23]											
Removing order of screw	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19					
Place to stick screw																								
Reference drawing (Fig. No.)	M1	M2	M3								M4				M5									
Screw tightening torque	I										II										I			

Symbol No.	[24]	[25]				[26]				[31]				[37]							
Removing order of screw	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	
Place to stick screw																					
Reference drawing (Fig. No.)						M6								M7				M8			
Screw tightening torque	III	I																			

Fig.2-2-7

<NOTE>

・Pay careful attention to tightening torque for each screw.
 Torque setting value of torque driver is limited. At the values over the maximum torque setting value, fasten a screw manually not to damage the screw thread.

I : 0.216N・m(2.2kgf・cm) II : 0.118N・m(1.2kgf・cm) III : 0.112N・m(1.1kgf・cm)

2.2.6 REMARKS

2.2.6.1 Cleaning

- (1) For cleaning of the upper drum (particularly video heads), use fine-woven cotton cloth with alcohol soaks through. Do not move the cloth but turn the upper drum counterclockwise.

NOTE:

Make sure not to move the cloth in the vertical direction to the video head, since it may cause damage of the video heads.

- (2) For cleaning of parts of the tape transport system except the upper drum, use fine-woven cotton cloth or cotton swab soaked alcohol.
- (3) After cleaning, confirm that the cleaned parts are completely dry before loading the deck with cassette tape.

2.2.6.2 Applying oil and grease

- (1) Periodical oiling and greasing are not required but should be done to new parts when replacing. If oil and grease on the other parts of the other party are old and dirty, wipe them clean and apply new oil or grease.
- (2) For parts and points to apply oil and grease, refer to the exploded view of the 3.2 VHS-C MECHANISM ASSEMBLY. Fig.2-2-8 specifies oil and grease to be used.
- (3) When oiling, clean the objective parts with alcohol first and apply one or two drop(s) of oil. Too much oiling causes rotary parts to slip because of oil leakage.

Classification	Part No.	Symbol in drawing
Grease	KYODO-SH-JB	AA
Oil	YTU94027	BB

specifies oil and grease to be used

Fig.2-2-8

2.3 VHS MECHANISM

2.3.1 Notes

This model's mechanism relates closely to the rotary encoder and system control circuit (the rotary encoder is meshed with the control cam).

The system control circuit detects the mechanism condition using the rotary encoder's phase (internal switch phase). Therefore, the parts such as the rotary encoder, control plate, loading gear and control cam need to be installed correctly in order for the mechanism to operate properly. (For the mechanism phase adjustment, refer to the installation of each part.)

- Before using a soldering iron, be sure to disconnect the power plug from the AC outlet.
- Do not touch any of the adjustment points until a defect position is specified.
- When plugging or unplugging the connector, be sure not to damage the wire.
- Be sure the springs are hooked all the way around and in the correct direction.
- When performing repairs, take care not to damage a catch, etc.




Fig.2-3-1

2.3.2 Mechanism operation check

When the mechanism is operated without a cassette loaded, operate the mechanism in the mechanism service mode.

2.3.3 Setting the mechanism assembling mode

The mechanism-assembling mode is provided with this mechanism. When disassembling and assembling, it is required to engage this mode.

Set the mode by adopting the following procedures.

- (1) Remove the mechanism assembly using the disassembling procedure.
- (2) Turn gear (a) of the loading motor manually to set the mechanism assembly to the eject end mode. Make sure that the main deck is connected to the guide hole (a) of the drive lever and the seal (a) of the main deck is connected to the mark "E" of the control plate. This condition is called the mechanism-assembling mode.




Fig.2-3-2

2.3.4 Layout of the main mechanism parts




Fig.2-3-3




Fig.2-3-4




Fig.2-3-5




Fig.2-3-6

2.3.5 Disassembling procedure table

This table shows the order of parts removal when replacing each part. For replacement, remove the parts in the order of 1 to 13 shown in the table and install the parts in the reverse order.

The symbol number before each part name shows the number in the figure "Layout of the main mechanism parts". T and B on the right of each part name show the side from which the part should be removed (T: From the front of the mechanism, B: From the rear of the mechanism, T/B: From both sides).

Symbols and numbers				L1	-	-	L2	-	R1	T6	T12	T11	T4	T10	T16	T15	B12	B11	B13	B9	B10	B2	B4	B3	B1	B5	B8	B15	
Symbols and numbers	Removal parts	Front(T)/Back(B) of mechanism	Number of removal steps	Earth spring (1)	Top frame	Cassette holder	Side frame (L)	Drive arm	Side frame (R)	Lid guide	Idler arm	Idler gear 1/2	Main brake (T)	Reel disk (T)	Tension arm	Tension arm base	Press lever	Control cam	Capstan brake assy	Loading motor assy	Belt	Fixing plate	Load gear	Loading gear assy (S)	Loading gear assy (T)	Control plate	Clutch unit	Direct gear	
	(Reference items) Replacement parts																												
L1	2.1 Earth spring (1)	T	1																										
-	2.1 Top frame	T	2	1																									
-	2.1 Cassette holder	T	3	1	2																								
L2	2.1 Side frame (L)	T	3	1	2																								
-	2.1 Drive arm	T	5	1	2	3	4																						
R1	2.1 Side frame (R)	T	3	1	2																								
T3	2.2 A/C head	T	1																										
T17	- FE head	T/B	1																										
T7	2.3 Guide arm assy	T	1																										
T6	2.3 Lid guide	T	1																										
T5	2.3 Pinch roller arm assy	T	2							1																			
T12	2.4 Idler arm	T	4	1	2	3																							
T11	2.4 Idler gear 1/2	T	5	1	2	3					4																		
T4	2.5 Main brake assy (T)	T	6	1	2	3					4	5																	
T10	2.5 Reel disk (T)	T	7	1	2	3					4	5	6																
T16	2.5 Tension arm	T	6	1	2	3					4	5																	
T13	2.5 Reel disk (S)	T	7	1	2	3					4	5			6														
T15	2.5 Tension arm base	T	7	1	2	3					4	5			6														
-	- T-up head	T	8	1	2	3					4	5			6	7													
-	- T-up lever	T	8	1	2	3					4	5			6	7													
T8	2.5 Brake lever	T	8	1	2	3					4	5	6	7															
T14	2.5 Rec safety lever	T	7	1	2	3	4	5	6																				
B12	2.6 Press lever	B	1																										
B11	2.6 Control cam	B	2														1												
B13	2.6 Capstan brake assy	B	3															1	2										
B9	2.6 Loading motor assy	B	4															1	2	3									
B10	2.7 Belt	B	1																										
B14	2.7 Capstan motor	T/B	2																			1							
-	- Wire holder	T/B	1																										
B2	2.7 Fixing plate	B	1																										
B4	2.7 Load gear	B	2																				1						
B3	2.7 Loading gear assy(S)	B	3																				1	2					
B1	2.7 Loading gear assy(T)	B	4																				1	2	3				
T1	- Pole base assy(S)	T/B	4																				1	2	3				
T2	- Pole base assy(T)	T/B	5																				1	2	3	4			
-	- Load gear base	B	5																				1	2	3	4			
B5	2.7 Control plate	B	6															1	2			3	4	5					
T9	- Drive lever	T/B	10	1	2	3	4	5	6									7	8		9								
B8	2.8 Clutch unit	B	2																			1							
B15	2.8 Direct gear	B	3																									2	
B7	- Change lever	T/B	6								1	2										3						4	5
B6	- Tension arm lever	T/B	14	1	2	3					4	5			6	7	8	9				10	11	12		13			

2.3.6 REPLACEMENT OF THE MAIN MECHANISM PARTS

2.3.6.1 Cassette holder

2.3.6.1.1 Removal

- (1) Remove the screws (a) and (b).
- (2) Hold up the top frame, cassette holder assembly, drive arm assembly and side frames (L/R) all together and remove them by releasing the hooks (a) and (b).




Fig.2-3-7

2.3.6.1.2 Installation (phase adjustment)

- (1) Turn gear (a) of the loading motor assembly so that the main deck connects to the guide hole (a) of the drive lever.
- (2) Hook the main deck to hooks (a) and (b).
- (3) Place the projection of the drive lever to section (a) of the side frame (R) and install the cassette holder to the main deck. Make sure that the bosses of the side frame (L/R) connect with the holes (a) and (b) of the main deck.
- (4) Secure screws (a) and (b).




Fig.2-3-8

2.3.6.1.3 Disassembling

- (1) Release hook (a) to remove the earth spring (1) from the top frame.
- (2) Release the catches (a) and (b) and pull the top frame in the direction shown by the arrow (a) to remove it.
- (3) Pull out the side frame (R).
- (4) Pull out the cassette holder assembly and drive arm assembly from the side frame (L).




Fig.2-3-9

2.3.6.1.4 Assembling (installation and phase adjustment)

- (1) Turn gear (a) of the loading motor assembly so that the main deck connects to the guide hole (a) of the drive lever.
- (2) Place the projection of the drive lever on section (a) of the side frame (R) and install the side frame (R) to the main deck.
- (3) Secure screw (b).
- (4) Place section (b) of the drive arm on the gear of the side frame (R). Make sure that the pin of the door opener connects with section (c) of the drive arm.
- (5) Place the drive arm on section (d) of the side frame (L) and install the side frame (L) on the main deck. Be sure to connect the earth spring (1) to the side frame (L).
- (6) Secure screw (a).
- (7) Turn gear (a) of the loading motor assembly until the drive arm is vertical.
- (8) Place the slit of the side frame (L/R) at the foot of the cassette holder assembly and install the cassette holder.
- (9) Place the top frame on the position guide (a) of the side frame (L/R) and push it in the direction shown by the arrow (a) for installation.
- (10) Hook the earth spring (1) to the hook (a) of the top frame.




Fig.2-3-10

2.3.6.2 A/C head

2.3.6.2.1 Removal

- (1) Remove screws (a) and (b).
- (2) Remove the A/C head together with the head base.
- (3) Remove the screws (c), (d) and (e) to remove the spring (a) and the A/C head from the Head base.




Fig.2-3-11

2.3.6.2.2 Installation (initial setting)

To install the A/C head to the head base, secure the screws in the order of (c), (d) and (e). To make the adjustment easy, temporarily elevate the A/C head.




Fig.2-3-12

2.3.6.3 Guide arm, pinch roller arm

2.3.6.3.1 Removal

- (1) Remove the spring (a) from the hook (a) and detach the guide arm assembly.
- (2) Release the catch (a) to remove the lid guide.
- (3) Remove the spring (b) from the hook (b) and detach the pinch roller arm assembly.




Fig.2-3-13

2.3.6.4 Idler arm, idler gear 1/2

2.3.6.4.1 Removal

- (1) Release the catches (a) and (b) to detach the idler arm.
- (2) Detach the idler gear 1/2.




Fig.2-3-14

2.3.6.5 Main brake (T), brake lever, tension arm, reel disk (S/T), Rec safety lever

2.3.6.5.1 Removal

- (1) Remove the spring (a). (Detach section (b) of the spring (a).)
- (2) Release the catch (a) to detach the main brake (T).
- (3) Release the catch (b) to detach the reel disk (T) and the spacer.
- (4) Lift up and turn section (b) of the brake lever counterclockwise to remove the brake lever.
- (5) Remove the spring (b) from the hook (a).
- (6) Release the catch (c) to detach the tension arm.
- (7) Release the catch (d) to detach the reel disk (S) and the spacer.
- (8) Remove the spring (c) from the hook (b).
- (9) Turn the tension arm base in the direction shown by arrow (a) to release catch (e). Place the projections of the tension arm base to the holes (a) to detach the tension arm base.
- (10) While releasing the catch (f), turn the Rec safety lever counterclockwise to remove it.




Fig.2-3-15

2.3.6.6 Press lever, control cam, capstan brake assembly, loading motor assembly

2.3.6.6.1 Removal

- (1) Remove the slit washer (a) to detach the press lever.
- (2) Release the slit washer (b) to detach the control cam.
- (3) Release the catch (b) to detach the capstan brake assembly.
- (4) Remove the solder (a).
- (5) Remove the screw (a).
- (6) Release the catches (c) and (d) to detach the loading motor assembly.




Fig.2-3-16

2.3.6.6.2 Installation (phase adjustment)

- (1) Attach the loading motor assembly to the main deck.
- (2) Secure the screw (a).
- (3) Solder the wire to section (a).
- (4) Arrange the wire along with the position guide (b).
- (5) Attach the capstan brake assembly to the main deck.
- (6) Place the main deck on the guide hole (a) of the control plate.
- (7) Place the main deck on the guide hole (b) of the drive lever.
- (8) Place the main deck no guide hole (c) of the control cam to install the control cam.
- (9) Move the capstan brake in the direction shown by the arrow (a) to attach the press lever to the shaft (a). Make sure that the boss of the press lever fits in the control cam, and that the shaft (b) of the pinch roller arm assembly connects with the hole of the press lever.
- (10) Attach slit washer (a) to shaft (a).




Fig.2-3-17

Note:

- When replacing the worm bearing of the loading motor assembly, attach it according to the following specification.

If worm bearing is not attached correctly, a mechanism noise may occur. (See Fig. 2-3-18)




Fig.2-3-18

2.3.6.7 Capstan motor, load gear, control plate

2.3.6.7.1 Removal

- (1) Detach the belt.
- (2) Check that the FFC connector on the drum is disconnected.
- (3) Release the catch (a) to remove the FFC wire.
- (4) Remove the screws (a) to detach the capstan motor.
- (5) Remove the screws (b) to detach the fixing plate.
- (6) Release the catch (b) to detach the load gear.
- (7) Turn the load gear (S/T) in the loading direction to detach it.
- (8) Remove the control plate.




Fig.2-3-19

2.3.6.7.2 Installation (phase adjustment)

- (1) Place the main deck on the guide hole (a) of the tension arm lever.
- (2) Place the main deck on the guide hole (b) of the brake lever.
- (3) Attach the control plate to align with the position guide (a).
- (4) Place the hole (c) of the load arm (T) on the pole base (T) and the load gear (T) on the load gear base.
- (5) Place the hole (d) of the load arm (S) on the pole base (S) and the load gear (S) on the load gear base. Be sure to align the guide mark (e) of the load gear (T) to that of the load gear (S).
- (6) Turn the load gear (S/T) in the unloading direction to place the main deck on the guide hole (f) of the load gear (T).
- (7) Place the main deck on the guide hole (g) of the control plate.
- (8) Attach the load gear on the load gear base so that the control plate is placed on the edge (h) of the load gear.
- (9) Place the fixing plate on the shaft of the load gear base and secure the screws (b).




Fig.2-3-20

2.3.6.8 Clutch unit assembly, direct gear

2.3.6.8.1 Removal

- (1) Remove the slit washer (a) to detach the clutch unit assembly.
- (2) Remove the spring (a) and the direct gear.





Fig.2-3-21

2-40 (No.86700)



2.3.8 REMARKS

2.3.8.1 Cleaning

- (1) For cleaning of the upper drum (particularly video heads), use fine-woven cotton cloth with alcohol soaks through. Do not move the cloth but turn the upper drum counterclockwise.

NOTE:

Make sure not to move the cloth in the vertical direction to the video head, since it may cause damage of the video heads.

- (2) For cleaning of parts of the tape transport system except the upper drum, use fine-woven cotton cloth or cotton swab soaked alcohol.
- (3) After cleaning, confirm that the cleaned parts are completely dry before loading the deck with cassette tape.

2.3.8.2 Applying oil and grease

- (1) Periodical oiling and greasing are not required but should be done to new parts when replacing. If oil and grease on the other parts of the other party are old and dirty, wipe them clean and apply new oil or grease.
- (2) For parts and points to apply oil and grease, refer to the exploded view of the 3.3 VHS MECHANISM ASSEMBLY. Fig.2-3-22 specifies oil and grease to be used.
- (3) When oiling, clean the objective parts with alcohol first and apply one or two drop(s) of oil. Too much oiling causes rotary parts to slip because of oil leakage.

Classification	Part No.	Symbol in drawing
Grease	KYODO-SH-JB	AA
Oil	COSMO-HV56	BB

specifies oil and grease to be used

Fig.2-3-22



VICTOR COMPANY OF JAPAN, LIMITED

AV & MULTIMEDIA COMPANY CAMCORDER CATEGORY 12, 3-chome, Moriya-cho, kanagawa-ku, Yokohama, kanagawa-prefecture, 221-8528, Japan

(No.86700)



Printed in Japan
200304WPC


JVC

SCHEMATIC DIAGRAMS

DIGITAL VIDEO CAMERA

GR-D20EK, GR-D20EX, GR-D20EY, GR-D20EZ, GR-D21EK,
GR-D40EK, GR-D40EX, GR-D40EY, GR-D40EZ

CD-ROM No.SML200305



For disassembling and assembling of MECHANISM ASSEMBLY, refer to the SERVICE MANUAL No.86700 (MECHANISM ASSEMBLY).

SPECIFICATION

Camcorder		Connectors	
General		S-Video	
Power supply	: DC 11.0 V $\overline{\text{---}}$ (Using AC Adapter) DC 7.2 V $\overline{\text{---}}$ (Using battery pack)	Output	: Y : 1 V (p-p), 75 Ω , analogue C : 0.29 V (p-p), 75 Ω , analogue
Power consumption		Input*	: Y : 0.8 V (p-p) -1.2 V (p-p), 75 Ω , analogue C : 0.2 V (p-p) -0.4 V (p-p), 75 Ω , analogue
LCD monitor off, viewfinder on	: Approx. 3.4 W	AV	
LCD monitor on, viewfinder off	: Approx. 4.7 W	Video output	: 1 V (p-p), 75 Ω , analogue
Dimensions (W x H x D)	: 69 mm x 94 mm x 143 mm (with the LCD monitor closed and the viewfinder pushed back in)	Video input*	: 0.8 V (p-p) -1.2 V (p-p), 75 Ω , analogue
Weight	: Approx. 525 g	Audio output	: 300 mV (rms), 1 k Ω , analogue, stereo
Operating temperature	: 0°C to 40°C	Audio input*	: 300 mV (rms), 50 k Ω , analogue, stereo
Operating humidity	: 35% to 80%	DV	
Storage temperature	: -20°C to 50°C	Output	: 4-pin, IEEE 1394 compliant
Pickup	: 1/6" CCD	Input*	: 4-pin, IEEE 1394 compliant
Lens	: F 1.6, f = 2.7 mm to 43.2 mm, 16:1 power zoom lens	USB**	: 5-pin
Filter diameter	: $\varnothing$ 37 mm	EDIT	: $\varnothing$ 3.5 mm, 2-pole
LCD monitor	: 2.5" diagonally measured, LCD panel/TFT active matrix system		
Viewfinder	: Electronic viewfinder with 0.24" black/white LCD		
Speaker	: Monaural		
Digital Video Camera		AC Adapter	
Format	: DV format (SD mode)	Power requirement	: AC 110 V to 240 V ~, 50 Hz/60 Hz
Signal format	: PAL standard	Output	: DC 11 V $\overline{\text{---}}$, 1 A
Recording/Playback format	: Video: Digital component recording Audio: PCM digital recording, 32 kHz 4-channel (12-bit), 48 kHz 2-channel (16-bit)		
Cassette	: Mini DV cassette		
Tape speed	: SP : 18.8 mm/s LP : 12.5 mm/s		
Maximum recording time (using 80 min. cassette)	: SP : 80 min. LP : 120 min.		

Specifications shown are for SP mode unless otherwise indicated. E & O.E. Design and specifications subject to change without notice.

GR-D20EK, GR-D20EX, GR-D20EY, GR-D20EZ, GR-D21EK, GR-D40EK, GR-D40EX, GR-D40EY, GR-D40EZ M3D122, M3D124

COPYRIGHT © 2003 VICTOR COMPANY OF JAPAN, LTD.

No.86730SCH
2003/04

CHARTS AND DIAGRAMS

NOTES OF SCHEMATIC DIAGRAM

Safety precautions

The Components identified by the symbol  are critical for safety. For continued safety, replace safety critical components only with manufacturer's recommended parts.

1. Units of components on the schematic diagram

Unless otherwise specified.

- 1) All resistance values are in ohm. 1/6 W, 1/8 W (refer to parts list).
Chip resistors are 1/16 W.
K: K Ω (1000 Ω), M: M Ω (1000K Ω)
- 2) All capacitance values are in μ F, (P: PF).
- 3) All inductance values are in μ H, (m: mH).
- 4) All diodes are 1SS133, MA165 or 1N4148M (refer to parts list).

Note: The Parts Number, value and rated voltage etc. in the Schematic Diagram are for references only. When replacing the parts, refer to the Parts List.

2. Indications of control voltage


AUX : Active at high.

$\overline{\text{AUX}}$ or AUX(L) : Active at low.


3. Interpreting Connector indications




Removable connector



Wire soldered directly on board



Non-removable Board connector



Board to Board




Connected pattern on board
The arrows indicate signal path

Note: For the destination of each signal and further line connections that are cut off from the diagram, refer to "BOARD INTERCONNECTIONS"

4. Voltage measurement

- 1) Regulator (DC/DC CONV) circuits
REC : Colour bar signal.
PB : Alignment tape (Colour bar).
— : Unmeasurable or unnecessary to measure.
- 4) Indication on schematic diagram
Voltage Indications for REC and PB mode on the schematic diagram are as shown below.



Note: If the voltages are not indicated on the schematic diagram, refer to the voltage charts.

5. Signal path Symbols

The arrows indicate the signal path as follows.

NOTE : The arrow is DVC unique object.

-  Playback signal path
-  Playback and recording signal path
-  Recording signal path (including E-E signal path)
-  Capstan servo path
-  Drum servo path

(Example)

-  R-Y Playback R-Y signal path
-  Y Recording Y signal path

6. Indication of the parts for adjustments

The parts for the adjustments are surrounded with the circle as shown below.



7. Indication of the parts not mounted on the circuit board

"OPEN" is indicated by the parts not mounted on the circuit board.




CIRCUIT BOARD NOTES

1. Foil and Component sides

- 1) Foil side (B side) :
Parts on the foil side seen from foil face (pattern face) are indicated.
- 2) Component side (A side) :
Parts on the component side seen from component face (parts face) indicated.

2. Parts location guides


Parts location are indicated by guide scale on the circuit board.




Note: For general information in service manual, please refer to the Service Manual of GENERAL INFORMATION Edition 4 No. 82054D (January 1994).

BOARD INTERCONNECTIONS


NOTE)*: The number of patch cords are indicated by inter connected.



■ MAIN IF SCHEMATIC DIAGRAM



■ CPU SCHEMATIC DIAGRAM



NOTE: The parts with marked (※) is not used.

y10332001a_rev0.1



NOTE: The parts with marked (※) is not used.

DV_MAIN SCHEMATIC DIAGRAM


5

4

3

2

1




DIFFERENT PARTS LIST

	R30B1	R30B2	R30B3
NON_PIXELA	OPEN	0Ω	OPEN
PIXELA	470Ω	OPEN	0Ω


NOTE: The parts with marked (*) is not used.

■ VIDEO I/O SCHEMATIC DIAGRAM



NOTE: The parts with marked (※) is not used

■ CAMERA DSP SCHEMATIC DIAGRAM




	R4302	R4303
NTSC	0 Ω	*
PAL	*	0 Ω

NOTE: The parts with marked (※) is not used.


OP DRIVER SCHEMATIC DIAGRAM

0 1 MAIN(OP DRIVER)



NOTE: The parts with marked (※) is not used.

■ TG SCHEMATIC DIAGRAM





3

2

1

A

B

C

2-21 D


2-22

E


F

G

1




■ MONI-BW SCHEMATIC DIAGRAM



NOTE: The parts with marked (※) is not used.


y10337001a_rev0.1

■ BL-2.5 SCHEMATIC DIAGRAM




■ CCD SCHEMATIC DIAGRAM

NOTES : • IC5001 is incorporated in the CCD base assembly.
When IC 5001 needs replacement, replace the CCD base assembly in whole because it cannot be replaced alone.




	Q5002	R5005
DSC MODEL	2SC4081/QR/-X	4.7K
NON DSC MODEL	※	※


JACK SCHEMATIC DIAGRAM




PREMDA IF SCHEMATIC DIAGRAM



■ MDA SCHEMATIC DIAGRAM




■ PRE/REC SCHEMATIC DIAGRAM



NOTE: The parts with marked (※) is not used.


■ B/W-VF SCHEMATIC DIAGRAM



y40104001a_rev0.1

■ ZOOM UNIT SCHEMATIC DIAGRAM


NOTES : ● The schematic diagram is only for reference. Avoid replacing individual parts.
Replace the entire unit only.



■ MAIN CIRCUIT BOARD

<01> MAIN
YB 10404-01-01


FOIL SIDE(B)



■ MAIN CIRCUIT BOARD

<01> MAIN
YB 10404-01-01

COMPONENT SIDE(A)




COMPONENT PARTS LOCATION GUIDE <MAIN> YB 10404-01-01

REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION
CAPACITOR																					
C1001	A C 4B	C3011	A C 2A	C4214	A C 3B	C6604	B C 1A	IC1006	A C 4A	Q3704	B C 5B	R1084	B C 5B	R3068	A C 2A	R4355	A C 3C	R6309	A C 2A		
C1002	A C 4B	C3012	A C 2A	C4216	A C 3B	C6605	B C 1B	IC1007	A C 4A	Q3705	B C 5B	R1085	A C 4A	R3069	A C 3C	R4356	A C 3C	R6402	B C 1A		
C1003	A C 4B	C3013	A C 3B	C4301	A C 3B	C6606	B C 1B	IC2101	A C 5B	Q3731	B C 5A	R1086	B C 4A	R3071	A C 2A	R4804	B C 5C	R6403	B C 1A		
C1003	A C 4A	C3015	A C 2A	C4302	A C 3C	C6607	B C 1B	IC2201	A C 5A	Q3732	B C 5A	R1087	B C 4A	R3072	A C 2A	R4805	B C 5C	R6405	B C 1A		
C1004	A C 4A	C3016	A C 2A	C4303	A C 3C	C6608	B C 1B	IC3001	A C 3A	Q3733	B C 5A	R1088	B C 5A	R3073	A C 2A	R4806	B C 6C	R6406	B C 1A		
C1005	A C 5A	C3017	A C 3B	C4304	A C 3C	C6609	B C 2B	IC3002	A C 2B	Q3734	B C 5A	R1089	B C 5A	R3074	A C 2A	R4807	B C 6C	R6407	B C 1A		
C1006	A C 4A	C3020	A C 2A	C4305	A C 2C	C6701	B C 2C	IC3005	A C 2B	Q3735	B C 5A	R1091	B C 4A	R3075	A C 2B	R4808	B C 5C	R6502	B C 1A		
C1007	A C 3A	C3021	A C 2A	C4306	A C 3B	C6703	B C 2C	IC3701	B C 5A	Q4801	B C 5C	R1092	A C 4B	R3081	A C 3B	R4809	B C 5C	R6503	B C 1A		
C1008	A C 3A	C3022	A C 2B	C4307	A C 3B	C6704	B C 1A	IC3731	B C 5A	Q4802	B C 5C	R1093	B C 4B	R3082	A C 3B	R4810	B C 5C	R6505	B C 1A		
C1009	A C 4B	C3023	A C 2B	C4308	A C 3C	C6801	B C 1C	IC3801	A C 5B	Q4803	B C 5B	R1094	A C 4B	R3083	A C 3B	R4811	B C 5C	R6506	B C 1A		
C1010	B C 5B	C3024	A C 2B	C4309	A C 3C	C6802	B C 1B	IC3802	B C 5B	Q4804	B C 5C	R1095	A C 5A	R3701	B C 6B	R4812	B C 5C	R6602	B C 1A		
C1011	B C 5B	C3025	A C 3A	C4310	A C 2C	C6803	B C 2C	IC3851	B C 2C	Q4805	B C 5C	R1096	A C 4A	R3702	B C 5B	R4813	B C 5C	R6603	B C 1A		
C1012	B C 5B	C3026	A C 2B	C4311	A C 2C	C6804	B C 1B	IC4201	A C 3B	Q4806	B C 5C	R1097	A C 4A	R3703	B C 5A	R4814	B C 5C	R6604	B C 1A		
C1013	B C 5B	C3027	A C 3A	C4312	A C 2B	C6805	B C 2B	IC4202	A C 3C	Q4851	A C 5C	R1099	A C 3A	R3704	B C 5B	R4815	B C 5C	R6605	B C 1A		
C1014	B C 5B	C3028	A C 2A	C4313	A C 2B	C6806	B C 1C	IC4301	A C 3C	Q6101	B C 1B	R2001	A C 4B	R3705	B C 5B	R4816	B C 5C	R6606	B C 1B		
C1015	B C 4A	C3029	A C 3A	C4314	A C 2B	C6807	B C 1B	IC4302	A C 2B	Q6102	A C 2A	R2002	A C 4B	R3706	B C 5A	R4817	B C 5C	R6607	B C 1B		
C1016	B C 4A	C3030	A C 3B	C4315	A C 2B	C6809	B C 1C	IC4303	A C 2C	Q6201	A C 1B	R2003	A C 4B	R3707	B C 5A	R4818	B C 5C	R6608	B C 1B		
C1017	B C 4A	C3031	A C 2A	C4316	A C 3C	R8001	B C 3B	IC4802	B C 6C	Q6301	A C 1A	R2004	A C 4B	R3708	B C 6A	R4819	B C 5C	R6609	B C 1B		
C1018	A C 4A	C3032	A C 3B	C4317	A C 2C	R8002	B C 4B	IC4803	B C 5C	Q6302	A C 2A	R2005	A C 4B	R3709	B C 6A	R4820	B C 5C	R6610	B C 1B		
C1019	B C 5A	C3033	A C 3B	C4318	A C 3B	R8003	B C 3C	IC4804	B C 5C	Q6303	A C 2A	R2006	A C 4B	R3710	B C 5A	R4821	B C 5C	R6611	B C 1B		
C1020	B C 4A	C3036	A C 3B	C4803	B C 6B	R8004	B C 3C	IC4807	B C 5C	Q6401	A C 1A	R2007	A C 4B	R3711	B C 5A	R4822	B C 5C	R6612	B C 1B		
C1021	B C 4A	C3037	A C 3B	C4804	B C 5B	R8005	B C 3B	IC4851	A C 5B	Q6501	A C 5B	R2008	A C 4B	R3712	B C 5A	R4823	B C 5C	R6613	B C 1B		
C1022	A C 4B	C3038	A C 3A	C4806	B C 5C	R8006	B C 3B	IC5501	A C 4B	Q6601	B C 1B	R2009	A C 3B	R3713	B C 5A	R4824	B C 5C	R6614	B C 1B		
C1024	A C 3A	C3039	A C 3A	C4807	B C 5C	R8007	B C 3A	IC6001	B C 1A	Q6602	B C 1B	R2010	A C 3B	R3714	B C 5A	R4825	B C 5B	R6615	B C 1B		
C1025	A C 4B	C3040	A C 3B	C4808	B C 5C	R8008	B C 3B	IC6801	B C 1C	Q6603	B C 1B	R2011	A C 4B	R3715	B C 5A	R4826	B C 5C	R6616	B C 1A		
C1029	A C 4A	C3042	A C 3A	C4809	B C 6C	R8010	B C 4B	IC6802	B C 2C	Q6604	B C 1B	R2012	A C 3B	R3722	B C 5B	R4827	B C 5C	R6617	B C 2B		
C1030	A C 4A	C3043	A C 3B	C4810	B C 5C	R8011	B C 3B	IC8001	B C 4B	Q6605	B C 1B	R2013	A C 4B	R3724	B C 5B	R4828	B C 5C	R6618	B C 2B		
C1032	A C 4A	C3044	A C 2A	C4811	B C 5C	R8012	B C 3B	IC8002	B C 4B	Q6606	B C 2B	R2014	A C 4B	R3725	B C 5B	R4829	B C 5C	R6619	A C 1B		
C1035	A C 4A	C3045	A C 3A	C4812	B C 5C	R8013	B C 3B	IC8003	B C 4C	Q6701	B C 2C	R2015	A C 4B	R3726	B C 5B	R4830	B C 5B	R6701	B C 2C		
C1036	B C 5B	C3046	A C 3A	C4813	B C 5C	R8014	B C 3B	IC8004	B C 4C	Q6801	B C 1B	R2016	A C 3B	R3727	B C 5B	R4831	B C 5C	R6702	B C 1A		
C1037	A C 4A	C3047	A C 3B	C4814	B C 5C	R8015	B C 4B	IC8006	B C 4B	Q6802	B C 2C	R2017	A C 3B	R3728	B C 5B	R4833	B C 5C	R6703	B C 1A		
C1038	A C 4A	C3048	A C 2A	C4815	B C 4C	R8016	B C 3B	IC8007	B C 3C	Q6803	B C 2C	R2018	A C 3B	R3730	B C 5A	R4836	B C 5C	R6704	B C 1A		
C1039	B C 4A	C3049	A C 3A	C4819	B C 5C	R8017	B C 4B	IC8301	B C 3C	Q6804	B C 1C	R2101	A C 5A	R3731	B C 5A	R4837	B C 5C	R6705	B C 1A		
C1040	A C 4A	C3050	A C 3A	C4820	B C 5C	R8018	B C 4B	IC8302	B C 3C	Q6805	B C 1C	R2102	A C 5A	R3732	B C 5A	R4839	B C 5C	R6706	B C 1A		
C1041	A C 4A	C3055	A C 3A	C4822	B C 5C	R8019	B C 4B	IC8701	B C 2B	Q6806	B C 1C	R2105	A C 5A	R3733	B C 5A	R4840	B C 5C	R6707	B C 1A		
C1042	B C 5A	C3056	A C 3B	C4823	B C 5C	R8020	B C 4B	IC8702	B C 2A	Q6807	B C 3B	R2106	A C 5B	R3734	B C 5A	R4841	B C 5B	R6708	B C 1C		
C1043	A C 4A	C3059	A C 2B	C4851	A C 4C	R8021	B C 4B	COIL		Q8002	B C 4B	R2107	A C 4B	R3735	B C 5A	R4842	B C 5C	R6802	B C 1C		
C1044	A C 4A	C3060	A C 2B	C4852	A C 5C	R8022	B C 4B	L1001	B C 4A	RESISTOR		R2108	A C 4B	R3736	B C 5A	R4843	B C 4C	R6803	B C 1C		
C1045	A C 4A	C3064	A C 3B	C4853	A C 6C	R8023	B C 4B	L1002	B C 5A	R1001	A C 4B	R2109	A C 4B	R3737	B C 5A	R4844	B C 5C	R6804	B C 2B		
C1046	B C 5B	C3066	A C 2B	C4854	A C 5C	R8024	B C 4B	L2101	A C 5B	R1002	A C 4B	R2110	A C 4B	R3738	B C 5A	R4845	B C 5C	R6805	B C 1B		
C1047	B C 5B	C3067	A C 2A	C4855	A C 6C	R8025	B C 4B	L2401	A C 5A	R1003	A C 4B	R2111	A C 4B	R3739	B C 5A	R4846	B C 5B	R6806	B C 2C		
C1048	B C 5B	C3068	A C 2A	C4858	A C 5B	R8026	B C 3B	L2402	A C 5A	R1004	A C 4B	R2112	A C 4B	R3740	B C 5A	R4847	B C 5C	R6807	B C 2C		
C1049	B C 5B	C3069	A C 2A	C4859	A C 5B	R8027	B C 3C	L2604	A C 5A	R1005	B C 4A	R2113	A C 4B	R3741	B C 5A	R4849	B C 5B	R6808	B C 2B		
C1050	B C 5B	C3070	A C 2A	C4860	A C 5B	R8028	B C 3C	L3001	A C 2A	R1006	A C 3A	R2114	A C 4B	R3742	B C 6A	R4850	B C 5C	R6809	B C 2C		
C1051	B C 4A	C3701	B C 6B	C4861	A C 5B	R8029	B C 3C	L3002	A C 2B	R1007	A C 4B	R2201	A C 5A	R3743	B C 6A	R4852	A C 5B	R6810	B C 2C		
C1052	B C 5A	C3702	B C 5B	C4862	A C 5B	R8030	B C 3B	L3004	A C 2A	R1008	B C 5A	R2202	A C 5A	R3744	B C 5A	R4854	A C 5B	R6811	B C 1C		
C1053	B C 4A	C3703	B C 5B	C4863	A C 5B	R8301	B C 2C	L3005	A C 2B	R1009	B C 5A	R2203	A C 5A	R3745	B C 5A	R4855	A C 5B	R6812	B C 1C		
C1054	B C 4A	C3704	B C 5B	C4864	A C 5C	R8305	B C 2B	L3007	A C 2B	R1010	A C 4B	R2204	A C 5A	R3746	B C 5A	R4856	A C 5B	R6813	B C 2B		
C1055	B C 5A	C3705	B C 5B	C4865	A C 5C	R8306	B C 2B	L3008	A C 3B	R1011	B C 4A	R2206	A C 5A	R3747	B C 5A	R4857	A C 5C	R6815	B C 1C		
C1056	A C 4B	C3706	B C 5A	C4866	A C 5B	R8307	B C 2B	L3012	A C 2A	R1012	A C 3A	R2207	A C 5A	R3748	B C 5A	R4858	A C 5C	R8001	B C 4B		
C1057	A C 4A	C3707	B C 5A	C5501	A C 4C	R8308	B C 2C	L3014	A C 2B	R1013	A C 3A	R2208	A C 5A	R3801	A C 5B	R4859	A C 5C	R8002	B C 4B		
C1058	A C 4A	C3708	B C 5A	C5503	A C 4C	R8309	B C 2C	L3015	A C 2B	R1014	B C 5B	R2209	A C 5A	R3802	A C 5B	R4860	A C 5C	R8003	B C 4B		
C1059	A C 4A	C3709	B C 5A	C5504	A C 4C	R8310	B C 3C	L3701	A C 6B	R1015	A C 4A	R2210	A C 5A	R3803	A C 5B	R4862	A C 5C	R8004	B C 3B		
C1060	A C 4A	C3712	B C 5A	C5506	A C 5B	R8311	B C 3C	L3731	B C 5A	R1016	A C 3A	R2211	A C 4A	R3804	A C 5B	R4863	A C 5B	R8005	B C 3B		
C1061	A C 4A	C3713	B C 5A	C5507	A C 4C	R8701	B C 2B	L3732	B C 5A	R1017	B C 5B	R2212	A C 5A	R3805	A C 5B	R4864	A C 5B	R8006	B C 3B		
C1062	A C 4A	C3714	B C 5A	C5508	A C 4B	R8702	B C 2B	L3801	A C 5B	R1018	B C 5B	R2213	A C 5A	R3806	A C 5B	R4865	A C 5B	R8007	B C 3C		
C1063	A C 4A	C3715	B C 5B	C5509	A C 4B	R8703	B C 2B	L3802	A C 5B	R1019	A C 4A	R2217	A C 5A	R3807	B C 5B	R4866	A C 5B	R8008	B C 3B		
C1064	B C 4A	C3731	B C 5A	C5510	A C 4C	R8704	B C 2A	L3803	A C 5A	R1020	A C 4A	R2218	A C 5A	R3808	B C 5B	R4867	A C 5B	R8009	B C 3C		
C1065	A C 4A	C3732	B C 5A	C5511	A C 4B	R8705	B C 2B	L3804	A C 5A	R1021	A C 4A	R2219	A C 5A	R3809	B C 5B	R4868	A C 5B	R8010	B C 3B		
C2105	A C 5A	C3733	B C 5A	C5512	A C 4B	R8706	B C 3B	L4201	A C 3C	R1022	A C 4B	R2220	A C 5A	R3851	B C 5B	R4870	A C 5C	R8016	B C 3C		
C2106	A C 5A	C3734	B C 5A	C5513	A C 4B	R8707	B C 3B	L4301	A C 2B	R1023	A C 4B	R2221	A C 5A	R3852	B C 5B	R4871	A C 5B	R8017	B C 4B		
C2107	A C 4B	C3735	B C 5A	C5514	A C 4C	R8708	B C 3B	L4302	A C 2B	R1024	A C 4A	R2222	A C 5A	R3853	B C 5B	R4872	A C 5C	R8020	B C 3C		


■ PREMDA CIRCUIT BOARD

<05> PREMDA
YB 10405-01-01




■ PREMDA CIRCUIT BOARD

<05> PREMDA
YB 10405-01-01




■ MONI-BW CIRCUIT BOARD

COMPONENT SIDE(A)



<02> MONI-BW
YB 10433

FOIL SIDE(B)




<02> MONI-BW
YB 10433

COMPONENT PARTS LOCATION GUIDE <MONI-BW> YB10433

REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION	REF.NO.	LOCATION		
CAPACITOR																			
C1	A C 3C	C7827	A C 1C	C7667	B C 1B	L7601	B C 1B	R5	A C 2C	R7613	B C 3C	R7867	A C 2C	ZP1-3	B C 1A	ZP1-15	B C 1A		
C10	B C 1A	C7828	B C 3C	C7668	A C 1C	L7602	B C 1B	R6	A C 1C	R7614	B C 3C	R7868	A C 2C	ZP1-4	B C 1A	ZP1-16	B C 3B		
C11	B C 1A	C7829	B C 3B	C7669	A C 2C	L7603	B C 1C	R7	A C 2B	R7615	B C 3C	R7869	A C 2C	ZP1-6	B C 1B	ZP1-17	B C 2C		
C7601	B C 2B	C7831	B C 4C	CONNECTOR	CN761	B C 1A	L7604	B C 4C	R8	A C 1B	R7616	B C 3C	R7870	B C 2B	ZP1-7	B C 1A	ZP1-18	B C 2A	
C7602	B C 2B	C7832	B C 2C		CN762	B C 1A	L7605	B C 1A	R18	B C 1A	R7617	B C 4C	R7872	A C 2C	ZP1-8	B C 1A	ZP1-20	B C 2A	
C7603	A C 2B	C7833	B C 2C		CN763	B C 1C	L7606	B C 1B	R19	B C 1A	R7618	B C 4B	R7873	A C 2C	ZP1-9	B C 1B	ZP1-22	B C 2A	
C7604	B C 2B	C7834	B C 2C		CN764	B C 1C	L7607	B C 2C	R20	B C 1A	R7619	B C 3B	R7874	A C 2C	ZP2-2	B C 1A	ZP1-26	B C 2A	
C7605	B C 2B	C7835	B C 2C	TRANSISTOR	CN765	B C 2B	DIODE	D10	B C 1A	R21	B C 1A	R7620	B C 4B	ZP2-3	B C 1A	ZP1-27	B C 2A		
C7606	B C 2B	C7836	B C 3B		CN766	A C 1A		D11	B C 1A	R22	B C 1A	R7621	B C 3B	R7876	A C 2C	ZP2-4	B C 1A	ZP1-28	B C 2A
C7607	B C 2B	C7837	B C 3B		CN766	A C 1A	Q10	B C 1A	R23	B C 1A	R7622	B C 4B	OTHER	SW2	A C 3C	ZP2-5	B C 1A	ZP1-36	B C 3B
C7608	B C 2B	C7841	A C 3B		Q7601	B C 3C	R25	B C 1A	R24	B C 1A	R7623	B C 4B				ZP2-6	B C 1B	ZP1-40	B C 1A
C7609	B C 2B	C7843	B C 1B	Q7602	B C 3C	R26	B C 1A	R25	B C 1A	R7624	B C 3B	ZP2-7				B C 1A	ZP2-10	B C 1A	
C7610	B C 1B	C7844	B C 1B	Q7603	B C 4C	R28	B C 1A	R26	B C 1A	R7625	B C 3B	SW3				A C 2C	ZP2-8	B C 1A	ZP3-10
C7611	B C 1B	C7845	B C 3C	D10	B C 1A	R29	A C 1A	R30	A C 1A	R7626	B C 3B	SW4	A C 1C	ZP2-9	B C 1A	ZP3-11	B C 1C		
C7612	B C 1B	C7846	B C 1B	D11	B C 1A	R31	A C 1A	R31	A C 1A	R7627	B C 3B	SW5	A C 2C	ZP3-7	B C 1C	ZP3-12	B C 2C		
C7613	B C 1B	C7847	B C 1B	D7601	B C 2C	R32	A C 2A	R32	A C 2A	R7628	B C 3B	SW6	A C 3B	ZP3-8	B C 1B	ZP3-13	B C 1C		
C7614	B C 1B	C7848	B C 1B	D7602	B C 3C	R33	B C 2A	R33	B C 2A	R7629	B C 3B	SW7	A C 2B	ZP3-9	B C 1B	ZP3-14	B C 1B		
C7615	B C 1B	C7849	B C 1B	D7603	A C 3B	R34	B C 2A	R34	B C 2A	R7630	B C 3B	SW8	A C 1B	ZP5-1	B C 2B	ZP3-15	B C 1C		
C7616	B C 1B	C7851	B C 2B	IC	IC7601	B C 2B	R35	B C 2A	R35	B C 2A	R7631	A C 3B	SW7601	A C 4A	ZP5-2	B C 2B	ZP3-16	B C 1B	
C7617	B C 1B	C7852	B C 2B		IC7602	B C 2C	R36	B C 2A	R36	B C 2A	R7632	A C 3B	SW7602	A C 4A	ZP5-3	B C 2B	ZP3-17	B C 1B	
C7618	B C 1B	C7854	B C 1C		IC7603	B C 2B	R37	B C 2A	R37	B C 2A	R7633	A C 3B	TM1	A C 4A	ZP5-4	B C 2A	ZP3-18	B C 1B	
C7619	B C 1B	C7855	B C 1C		IC7604	B C 2B	R38	B C 2A	R38	B C 2A	R7634	A C 3B	TM2	A C 4A	ZP1-10	B C 1A	ZP3-19	B C 1B	
C7620	B C 2B	C7861	B C 2B	IC7605	B C 2C	R39	B C 2A	R39	B C 2A	R7635	A C 3B	TM3	A C 4A	ZP1-11	B C 1A	ZP3-20	B C 1B		
C7621	B C 2B	C7862	B C 2B	IC7606	A C 1C	R40	B C 2A	R40	B C 2A	R7636	A C 3B	TM4	A C 4A	ZP1-12	B C 1A	ZP3-21	B C 1B		
C7622	B C 2B	C7863	B C 2B	COIL	L10	B C 1A	RESISTOR	R3	A C 3C	R7637	B C 3B	TM5	A C 4A	ZP1-13	B C 1A	ZP5-17	B C 2A		
C7623	B C 2C	C7864	B C 2B		L11	B C 1A		R4	A C 2C	R7610	A C 1C	R7638	B C 3B	TM6	A C 4A	ZP1-14	B C 1A	ZP5-18	B C 2A
C7624	B C 1C	C7865	B C 2C		L12	B C 1A		R5	A C 3C	R7611	A C 1C	R7639	B C 3B	TP7601	B C 4A	ZP1-15	B C 1A	ZP5-19	B C 3B
C7625	B C 2C	C7866	A C 2C		L13	B C 1A		R6	A C 2C	R7612	B C 3C	R7666	A C 2C	TP7602	B C 4A				


■ JACK CIRCUIT BOARD

COMPONENT SIDE(A)



<06> JACK
YB 20943-01-01


FOIL SIDE(B)



<06> JACK
YB 20943-01-01


■ CCD CIRCUIT BOARD

COMPONENT SIDE(A)



<04> CCD
YB 20942


FOIL SIDE(B)



<04> CCD
YB 20942


■ B/W-VF CIRCUIT BOARD

COMPONENT SIDE(A)




<07> B/W-VF
YB 20940

FOIL SIDE(B)



<07> B/W-VF
YB 20940

■ POWER SYSTEM BLOCK DIAGRAM



VIDEO BLOCK DIAGRAM (1/2)


5

4

3

2

1



*1 WITH ANALOG INPUT MODEL
*2 WITHOUT ANALOG INPUT MODEL
*3 WITH EDIT MODEL
*4 WITH DSC MODEL

5



VOLTAGE CHARTS

<MAIN IF>		
MODE PIN NO.	REC	PLAY
Q2001		
1	0	0
2	0.5	0.5
3	3.0	3.0
4	0	0
5	0	0
6	0	0
Q2002		
1	0	0
2	0	0
3	0	2.9
4	0	0
5	0.5	0
6	0.5	0
Q2003		
1	0	0
2	0.5	0.5
3	3.0	2.3
4	0	0
5	0	0
6	0	0
Q2004		
1	0	0
2	0.5	0
3	2.9	0
4	0	0
5	0	0.5
6	0	0.5
Q2005		
1	0	0
2	0.5	0.5
3	2.9	2.9
4	0	0
5	0	0
6	0	0
Q2006		
1	0	0
2	0.4	0.4
3	2.9	2.9
4	0	0
5	0	0
6	0	0

<CPU>		
MODE PIN NO.	REC	PLAY
IC1001	-	-
IC1002		
1	2.8	2.8
2	2.5	2.5
3	2.7	2.7
4	3	3
5	3.1	3.1
6	3.1	3.1
7	1.4	1.4
8	1.5	1.5
9	0	0
10	0	0
11	0	0
12	0	0
13	0	0
14	0	0
15	0	0
16	0	0
17	0	0
18	0	0
19	3	3
20	2.8	2.8
IC1003		
1	0	0
2	3	3
3	0	0
4	3	3
5	3	3
IC1004		
1	1.2	1.2
2	0	0
3	1.4	1.4
4	0	0
5	3	3
IC1005		
1	3	3
2	0	0
3	3	3
4	0	0
5	3	3
6	3	3
7	3	3
8	3	3
IC1006		
1	0	0
2	3	3
3	3	3
4	0	0
5	3	-
6	0.5	0.5
7	0.4	0.8
8	3	3.2
IC1007		
1	3	3
2	3	3
3	0	0
4	0	0
Q1001		
E	3.1	3.1
C	3.1	3.1
B	3	3
Q1002		
1	0	0
2	3	3
3	0	3.1
4	0	2.9
5	0	0
Q1003		
1	0	0
2	3	0
3	3.1	3.1
4	-0.8	-0.4
5	3.1	3.1
Q1004		
1	0	0
2	3	3
3	3	3
4	3	3
5	0	0
Q1005		
E	0	0
C	1	0.4
B	0	0
Q1006		
1	0	0
2	3	0
3	3.1	3.1
4	3	-0.2
5	0	3.1
Q1007		
E	0	0
C	3.1	3.1
B	0.5	0.5
Q1008		
E	0	0
C	0	0
B	3	0

<DV MAIN>		
MODE PIN NO.	REC	PLAY
IC3001	-	-
IC3002		
1	0	0
2	0.5	0.5
3	0.4	0.4
4	1.7	1.7
5	0.7	0.7
6	2.4	2.4
7	1.2	1.2
8	3.1	3.1
9	3.1	3.1
10	3.1	3.1
11	3.1	3.1
12	2.1	2.1
13	1.1	1.1
14	0	0
15	0	0
16	3	3
17	3	3
18	1.4	1.4
19	1.3	1.3
20	0	0
IC3005		
1	0	0.4
2	0	0.4
3	0	0
4	0.8	1.7
5	0	0
6	0	0
7	0	0
8	0	3.1
Q3001		
E	1.8	1.8
C	2.9	2.9
B	2.4	2.4
Q3002		
E	0.3	1.2
C	3.1	3.1
B	0.8	1.7

<VIDEO I/O>		
MODE PIN NO.	REC	PLAY
IC3701		
1	0	0
2	2.3	2.3
3	0	0
4	0	0
5	0	0
6	0	0
7	1.9	1.9
8	0	0
9	2.3	2.3
10	0	0
11	2.1	2.1
12	2.1	2.1
13	4.8	4.8
14	1.9	1.9
15	1.9	1.9
16	4.8	4.8
IC3731		
1	3	3
2	2	2
3	4.8	4.8
4	1.7	1.7
5	0	0
6	2.3	2.3
IC3801	-	-
IC3851	-	-
Q3701		
1	1.2	1.2
2	0.6	0.6
3	0	0
4	1.4	1.4
5	0.8	0.8
6	0	0
Q3702		
1	0.2	0
2	0	0
3	0	0
4	4.8	4.8
5	4.9	4.7
6	4.9	4.7
Q3704		
E	0.9	0.9
C	0	0
B	0.3	0.3
Q3705		
1	0.9	0.9
2	0.3	0.3
3	0	0
4	0.9	0.9
5	0.3	0.3
6	0	0
Q3731		
E	0	0
C	4.8	4.8
B	0	0
Q3732		
E	0	0
C	0	0
B	3	3
Q3733		
1	0	0
2	0.4	0.4
3	0	0
4	4.8	4.8
5	4.8	4.8
6	4.8	4.8
Q3734		
E	0	0
C	4.8	4.8
B	0	0
Q3735		
1	0.1	0.1
2	0.4	0.4
3	0	0
4	2.1	2.1
5	1.5	1.5
6	4.8	4.8

<CDS/DSP>		
MODE PIN NO.	REC	PLAY
IC4201		
1	1.2	0
2	1.2	0
3	0.5	0
4	0.2	0
5	0	3
6	0	0
7	0	0
8	0	0
9	1.2	0
10	3	3
11	0	0
12	1.5	1.5
13	3	3
14	2.5	0
15	3	0
16	2.4	0
17	2.5	0
18	0	0
19	3	3
20	1.9	0
21	1.9	0
22	2	0
23	1.9	0
24	1.2	0
25	3	3
26	0	0
27	0	0
28	1.4	0
29	2	0
30	0.9	0
31	3	3
32	0	0
33	3	3
34	3	3
35	3	3
36	1.2	0
IC4202		
1	4.8	4.8
2	0	0
3	1.2	1.2
4	3	3
5	4.8	4.8
IC4301	-	-
IC4302		
1	1.6	1.8
2	0	0
3	1.8	1.8
4	1.8	1.8
5	1.4	1.4

<OP DRIVE>		
MODE PIN NO.	REC	PLAY
IC4802		
1	3.1	3.1
2	2.6	2.6
3	2.6	2.6
4	0	0
5	2.6	2.6
6	2.6	2.6
7	2.6	2.6
8	4.8	4.8
IC4803		
1	1.3	1.3
2	0.6	0.6
3	0.6	0.6
4	0	0
5	2.6	2.6
6	2.6	2.6
7	1.6	2.8
8	4.8	4.8
IC4804		
1	1.3	0.3
2	1.6	2.6
3	1.6	0
4	0	0
5	1.5	3
6	1.5	3
7	2	0
8	4.8	4.8
IC4807		
1	1.5	3
2	1.5	3
3	4.8	4.8
4	0	0
5	1.5	3
6	1.5	3
7	4.8	4.8
8	4.8	4.8
IC4851		
1	0	0
2	0.6	0.6
3	0.3	0.3
4	0	0
5	0	0.3
6	0.3	0
7	0	0
8	3.1	3.1
9	4.6	4.6
10	0.6	0.6
11	0	0
12	0.7	0.5
13	4.6	4.6
14	0.7	0.7
15	0	0
16	0.7	0.7
17	0	0
18	0	0
19	0	0
20	0	0
21	0	0
22	0	0
23	4.6	4.6
24	0.8	1.5
25	0	0
26	0.8	1.5
27	4.8	4.6
28	0.8	1.5
29	0	0
30	0.8	1.5
31	3.1	3.1
32	0	0
33	0	0
34	3	3
35	3	3
36	1.5	1.5
37	1.5	1.5
38	3	3
Q4801		
E	0.6	0.6
C	2.1	2.1
B	1.3	1.3
Q4802		
E	0	0
C	1.5	3
B	0	0
Q4803		
E	0	0
C	4.8	4.8
B	0	0
Q4804		
E	4.8	4.8
C	1.5	3
B	4.8	4.8
Q4805		
E	4.8	4.8
C	1.5	3
B	4.8	4.8

MODE PIN NO.	REC	PLAY
Q4806		
E	1.2	0
C	4.8	4.8
B	2	0
Q4851		
E	0	0
C	3.5	3.7
B	0	0

<TG>		
MODE PIN NO.	REC	PLAY
IC5501		
1	0	0
2	3	3
3	3	3
4	3	3.1
5	0	0
6	3	3.1
7	0.3	0
8	0.3	0
9	0	0
10	3	3.1
11	1.6	0
12	3	3.1
13	0	0
14	1.3	0
15	0	0
16	3.1	3.1
17	2.3	0
18	2.3	0
19	2.4	0
20	0	0
21	0	0
22	1.2	1.4
23	0	0
24	3	3.1
25	0	0.6
26	3.1	0
27	2.5	0
28	0	0
29	-7.1	0
42	-0.3	15.1
43	15.1	15.1
44	-7.1	15.1
45	-7.1	15.1
46	-7.6	-7.6
47	0	0
48	3	3

<REG>		
MODE PIN NO.	REC	PLAY
IC6001		
1	3.1	3.1
2	3	3
3	3	3
4	3	3
5	3	3
6	0	0
7	1.2	1.2
8	11.1	11.1
9	1	1
10	1.2	1.2
11	2.2	2.2
12	0	0
13	0	0
14	0	0
15	0	0
16	0	0
17	0.1	0.1
18	0	0
19	2.2	2.2
20	1	1
21	0	0
22	2.2	2.2
23	1	1
24	0.6	0.6
25	1	1
26		



VICTOR COMPANY OF JAPAN, LIMITED

AV & MULTIMEDIA COMPANY CAMCORDER CATEGORY 12, 3-chome, Moriya-cho, kanagawa-ku, Yokohama, kanagawa-prefecture, 221-8528, Japan

(No.86733)



Printed in Japan
200304WPC

PARTS LIST

SAFETY PRECAUTION

Parts identified by the $\triangle$ symbol are critical for safety. Replace only with specified part numbers.


BEWARE OF BOGUS PARTS

Parts that do not meet specifications may cause trouble in regard to safety and performance. We recommend that genuine JVC parts be used.

1. EXPLODED VIEW



1.1 PACKING AND ACCESSORY ASSEMBLY <M1>

The instruction manual to be provided with this product will differ according to the destination.




3-2(No.86730)






<UPPER ASSEMBLY>



1.3 MECHANISM ASSEMBLY <M3>




Classification	Part No.	Symbol in drawing
Grease	KYODO-SH-JB	AA
Oil	YTU94027	BB
Grease (HANARL)	RX-410R	CC

NOTE1: The section marked in AA and BB, CC indicate lubrication and greasing areas.


NOTE2: Mark * is not contained in 900A.

1.4 ELECTRONIC VIEWFINDER ASSEMBLY <M4>



1.5 MONITOR ASSEMBLY (2.5 INCH) <M5>

500



MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

2. PARTS LIST

PACKING AND ACCESSORY ASSEMBLY <M1>

△ Symbol No.	Part No.	Part Name	Description	Local
1	LY33063-012A	PACKING CASE		A,B,C,D
1	LY33063-015A	PACKING CASE		E
1	LY33063-003A	PACKING CASE		F,G,H,J
2	LY33065-001B	CUSHION		A,B,C,D,E,F,G
2	LY33065-001C	CUSHION		H,J
3	LY30023-027A	POLY BAG		
4	YQM30061-3	POLY BAG		A,E,F
4	QPA02003506	POLY BAG	20cm x 35cm	B,C,D,G,H,J
△ 5	LYT1134-001A	INST BOOK	(ENGLISH)	E
△ 5	LYT1098-001A	INST BOOK	(ENGLISH)	A,F
△ 5	LYT1098-003A	INST BOOK	(FRENCH)	B,G
△ 5	LYT1098-004A	INST BOOK	(DUTCH)	B,G
△ 5	LYT1098-005A	INST BOOK	(SPANISH)	B,G
△ 5	LYT1098-006A	INST BOOK	(ITALIAN)	B,G
△ 5	LYT1098-002A	INST BOOK	(GERMAN)	B,C,G,H
△ 5	LYT1098-007A	INST BOOK	(DANISH)	C,H
△ 5	LYT1098-008A	INST BOOK	(FINNISH)	C,H
△ 5	LYT1098-009A	INST BOOK	(SWEDISH)	C,H
△ 5	LYT1098-010A	INST BOOK	(NORWEGIAN)	C,H
△ 5	LYT1098-011A	INST BOOK	(RUSSIAN)	D,J
△ 5	LYT1098-012A	INST BOOK	(CZECH)	D,J
△ 5	LYT1098-013A	INST BOOK	(POLISH)	D,J
△ 5	LYT1098-014A	INST BOOK	(HUNGARIAN)	D,J
6	LYT1135-001A	INST BOOK	(SOFT.ENGLISH)	E
6	LYT1086-001A	INST BOOK	(SOFT.ENGLISH)	F
6	LYT1086-003A	INST BOOK	(SOFT.FRENCH)	G
6	LYT1086-004A	INST BOOK	(SOFT.DUTCH)	G
6	LYT1086-005A	INST BOOK	(SOFT.SPANISH)	G
6	LYT1086-006A	INST BOOK	(SOFT.ITALIAN)	G
6	LYT1086-002A	INST BOOK	(SOFT.GERMAN)	G,H
6	LYT1086-007A	INST BOOK	(SOFT.DANISH)	H
6	LYT1086-008A	INST BOOK	(SOFT.FINNISH)	H
6	LYT1086-009A	INST BOOK	(SOFT.SWEDISH)	H
6	LYT1086-010A	INST BOOK	(SOFT.NORWEGIAN)	H
6	LYT1086-011A	INST BOOK	(SOFT.RUSSIAN)	J
7	BT-54008-4	WARRANTY CARD		A,E,F
7	BT-54013-5	WARRANTY CARD		B,C,D,G,H,J
8	YU30878	REGIST. CARD		E,F
9	LYT0194-001B	Q.CARD(JUK)		A,E,F
20	QPA01703005	POLY BAG	17cm x 30cm	
23	QAM0451-001	USB CABLE		F,G,H,J
24	QQR0491-002	FERRITE CORE	TDK (BLACK)	F,G,H,J
25	QAM0212-001	A/V CABLE		
26	QQR0918-002	CORE FILTER		
△ 27	LY20955-001C	AC ADAPTER	AP-V13E	
△ 27	or LY20956-001B	AC ADAPTER	AP-V11E	
28	QQR0917-002	CORE FILTER		
△ 29	QMPP110-190-JR	POWER CORD(EK)	1.9m BLACK	A,E,F
△ 29	QMPL120-190-JR	POWER CORD(EU)	1.9m BLACK	B,C,D,G,H,J
30	QPA02503505P	POLY BAG	25cm x 35cm	
△ 31	LY32566-001A	BATT.PACK ASSY	BN-V408U-B	
32	LY20186-004A	SHOULDER STRAP		
33	LY21020-001A	REMOCON	RM-V718U	
34	QQR0491-002	FERRITE CORE	TDK (BLACK)	
36	LY44002-001B	CAP(HOOD)ASSY		
37	LY32210-059A	CD ROM ASSY		E
37	LY32210-048A	CD ROM ASSY		F,G,H,J
40	QQR0491-002	FERRITE CORE	TDK (BLACK)	
41	QAM0302-001	ADAPTOR PLUG		

FINAL ASSEMBLY <M2>

△ Symbol No.	Part No.	Part Name	Description	Local
101	LY20941-007J	U.CASE(2.5)ASSY		A,B,C,D,E
101	LY20941-003J	U.CASE(2.5)ASSY		F,G,H,J
101A	LY40664-001A	SPACER	(x2)	
101E	LY33042-001A	C.LABEL(VF)		
101F	LY30030-0F2A	SPACER(A)		
102	LY30018-0D6A	SPECIAL SCREW	(x2)	
103	LY33044-001D	BKT(HINGE2.5)		

△ Symbol No.	Part No.	Part Name	Description	Local
104	LY30018-096A	SPECIAL SCREW	(x2)	
105	QAS0126-001	SPEAKER		
106	LY30018-017A	SPECIAL SCREW	(x2)	
108	LY30018-059A	SPECIAL SCREW	(x4)	
109	LY33049-002A	COVER(UPPER2.5)		
110	LY30018-056A	SPECIAL SCREW	(x2)	
111	LY30018-0E6A	SPECIAL SCREW	(x2)	
112	LY33050-002C	COVER(JIG)		
114	QUQ105-4007AA	FFC WIRE MONI CN761-MAIN CN101		
115	LY33033-001A	ORNAMENT(2.5 2)		A,B,C,D,E
115	LY33009-001A	ORNAMENT(2.5 1)		F,G,H,J
116	LY30018-0E6A	SPECIAL SCREW	(x2)	
117	LY30018-0A1A	SPECIAL SCREW		
118	LY30018-096A	SPECIAL SCREW	(x2)	
119	LY30018-096A	SPECIAL SCREW		
120	LY33025-001B	TOP COVER ASSY		
120A	LY40162-001A	BKT		
121	LY30018-096A	SPECIAL SCREW		
122	LY30018-096A	SPECIAL SCREW		
123	LY44187-006A	STICKER(2)		A,B,C,D,E
123	LY44187-004A	STICKER(2)		F,G,H,J
125	LY30018-0E6A	SPECIAL SCREW	(x2)	
126	LY30030-0E3B	SPACER(A)		
127	LY30030-0E5A	SPACER(A)		
135	LY20943-002E	F.COVER ASSY		
135A	LY33056-001B	HOOD		
135B	LY33057-001A	RING		
135C	LY33058-001A	HOOD(SCREW)		
135D	LY33059-001B	BKT(FRONT)		
135E	LY44186-002A	STICKER(1)		
135F	LY30018-0E6A	SPECIAL SCREW		
135G	LY30018-052A	SPECIAL SCREW	(x3)	
136	LY20944-001B	MIC		
137	LY30018-0G6A	SPECIAL SCREW		
△ 145	LY20938-001E	REAR UNIT		
146	LY30018-0G6A	SPECIAL SCREW	(x2)	
147	LY30018-0J1A	SPECIAL SCREW	(x2)	
148	LY30018-0H3A	SPECIAL SCREW		
155	LY20935-002E	LOWER CASE ASSY		
155A	LY33402-001A	COVER(LOWER)		
155B	LY30018-0E6A	SPECIAL SCREW	(x2)	
156	LY20939-001F	ARM ASSY		
156A	LY30002-046B	COMPRES. SPRING	(x2)	
156B	LY43973-001A	TENSION SPRING		
157	QUQ105-2203AA	FFC WIRE JACK CN501-MAIN CN102		
158	LY30018-096A	SPECIAL SCREW		
159	LY30018-059A	SPECIAL SCREW	(x2)	
160	LY30018-096A	SPECIAL SCREW	(x2)	
161	LY10453-001E	ZOOM UNIT		
162	LY30018-0E6A	SPECIAL SCREW		
163	LY33395-001A	BRACKET(ZOOM)		
164	LY30018-059A	SPECIAL SCREW		
165	LY20937-003B	C.COVER ASSY		
165A	LY33027-001B	KNOB(LOCK)		
165B	LY33028-001A	HOLDER(LOCK)		
165C	LY33397-001A	HOOK(G.B)		
165D	LY33039-001A	BKT(G.BELT)		
165E	LY20945-003A	GRIP BELT		
165F	LY44178-001A	SHEET(C.COV)		
165G	LY30018-0E6A	SPECIAL SCREW		
165H	QYSLSF2040D	TAP SCREW	2mm x 4mm(x2)	
165J	QYSLSF2040D	TAP SCREW	2mm x 4mm(x2)	
165K	QYSLSF2040D	TAP SCREW	2mm x 4mm	
165L	LY30018-0H1A	SPECIAL SCREW	(x2)	
166	LY30018-0K3A	SPECIAL SCREW	(x2)	
167	LY30018-096A	SPECIAL SCREW	(x2)	
168	LY30018-059A	SPECIAL SCREW	(x2)	
169	LY31019-001A	BASE		
170	LY30018-0E6A	SPECIAL SCREW	(x2)	
171	LY33396-001B	HOLDER(JACK)		
172	LY30018-0E6A	SPECIAL SCREW		
173	LY33037-001B	COVER(ZOOM)		
174	LY30018-084A	SPECIAL SCREW	(x3)	
175	LY33029-001B	COVER(ADJUST)		
176	LY33024-001C	COVER(JACK)		
178	LY30018-017A	SPECIAL SCREW		
191	LY33019-001B	BKT(MECHA)ASSY		

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
191A	LY42796-003A	BUSH	(x3)	
192	LY30019-028A	SPECIAL SCREW	(x3)	
193	LY30018-056A	SPECIAL SCREW	(x2)	
194	LY40699-002A	LABEL(PUSH)		
195	LY32001-002A	LABEL(HOUSING)		
196	LY33388-001C	SHIELD COVER(PR)		
197	QYSPSPT1414M	SCREW	1.4mm x 1.4mm(x2)	
198	LY30018-096A	SPECIAL SCREW	(x2)	
199	LY30019-038A	SPECIAL SCREW	(x2)	
200	LY30018-096A	SPECIAL SCREW	(x2)	
201	LY30018-017A	SPECIAL SCREW		
202	QUQ105-24X8AA	FPC WIRE OP BLOCK-MAIN CN108		
203	QAL0465-001	FPC CCD CN5001-MAIN CN107		
215	LY43965-001D	BKT(OP)ASSY		
215A	LY30030-095A	SPACER(A)		
215B	LY30030-096A	SPACER(A)		
215C	LY43966-001A	RUBBER(OP)	(x2)	
215D	LY30030-0E5A	SPACER(A)		
216	LY30018-0G9A	SPECIAL SCREW	(x2)	
217	LY30030-057A	SPACER(A)		
218	LY30030-050A	SPACER(A)		
219	LY30030-060A	SPACER(A)		
251	LY33085-001F	OP BLOCK ASSY		
251A	LY30724-001B	FOCUS MOTOR		
251B	LY30723-001B	ZOOM MOTOR		
251C	PTY33085-001	SCREW	(x7)	
251D	PTY31727-116	SCREW	(x2)	
251E	PTY33085-007	IRIS MOTOR UNIT		
252	LY44120-001A	OP LPF		
253	LY44005-001A	SHEET		
254	LY33288-001A	SPACER		
255	LYH30446-002A	CCD BASE ASSY		
256	LY30018-0E7A	SPECIAL SCREW	(x2)	
257	LY30030-093A	SPACER(A)		
258	LY30030-094A	SPACER(A)		
259	LY30029-0Q7A	SPACER(A)		

MECHANISM ASSEMBLY <M3>

△ Symbol No.	Part No.	Part Name	Description	Local
900	YMA0029H	MECHA(A)ASSY		
900A	YMA0029D	MECHA(A)ASSY		
901	LY32870-001G	CASSETTEHOUSING ASSY		
902	YQ43893-8	MINI SCREW	(x3)	
903	LYH30420-001A	UPPER BASE ASSY		
904	QYSPSPU1425M	SCREW		
905	YDV2102B	DRUM ASSY		
906	LY42820-001A	DAMP.SCREW ASSY	(x2)	
907	LY42820-002A	DAMP.SCREW ASSY		
908	LY31538-001F	REEL DISK ASSY		
909	LY31538-002H	REEL DISK ASSY		
910	YQ44246	SLIT WASHER		
911	LY10372-001D	REEL COVER ASSY		
912	LY42120-002A	MINI SCREW		
913	LY41945-003A	MINI SCREW	(x2)	
914	YQ44246	SLIT WASHER		
915	LY43725-001D	TENSION ARM ASSY		
916	LYH40269-001A	SLANT POLE ARM ASSY		
917	LY43731-001F	TU ARM ASSY		
918	LY31531-001D	SWING ARM ASSY		
919	YQ43893	MINI SCREW		
920	LYH30424-001A	SLIDE DECK FINAL ASSY		
921	YQ43893	MINI SCREW	(x2)	
922	LY43023-001A	MINI SCREW		
924	LYH30419-001A	PAD ARM ASSY		
925	YQ44246	SLIT WASHER		
928	LYH40270-001A	TU BRAKE ASSY		
929	YQ44246	SLIT WASHER		
930	LY43684-001A	TENSION CONTROL LEVER ASSY		
931	LY32861-001A	CENTER GEAR		
932	LY31516-001F	PINCH ROLLER ARM FINAL ASSY		
933	YQ44246	SLIT WASHER		
934	LY43681-001A	TENSION CONTROL PLATE ASSY		
935	LY43687-001A	BRAKE CONTROL LEVER ASSY		
936	LYH30421-001A	MOTOR BRACKET ASSY		

△ Symbol No.	Part No.	Part Name	Description	Local
936A	QAR0138-001	LOADING MOTOR		
936B	LY41940-001A	TAPPING SCREW	(x2)	
937	YQ43893	MINI SCREW	(x3)	
938	LYH30422-001A	GUIDE RAIL ASSY		
939	YQ43893	MINI SCREW		
940	YQ44246	SLIT WASHER	(x2)	
941	LY32843-001A	SLIDE LEVER2 ASSY		
942	LY43690-001A	LOADING PLATE ASSY		
943	YQ44246	SLIT WASHER		
944	LY32858-001A	EJECT LEVER		
945	YQ44246	SLIT WASHER		
946	LYH40271-001A	BASE R ASSY		
947	YQ43893	MINI SCREW		
948	LY41945-001B	MINI SCREW		
949	LY43665-001A	MODE GEAR		
950	QSW0876-003	ROTARY ENCODER		
951	YQ43893	MINI SCREW	(x2)	
952	LY32860-001A	GEAR COVER ASSY		
953	YQ43893	MINI SCREW	(x2)	
954	YQ43893-4	MINI SCREW		
955	LY43676-001A	MAIN CAM ASSY		
956	LY41941-001B	SLIDE ARM ASSY		
957	LY43678-001A	CONNECT GEAR 2		
958	LY41954-001C	SUB CAM ASSY		
959	LY42120-001A	MINI SCREW		
960	LY43692-001A	CONTROL ARM ASSY		
961	LY32859-001A	REEL GEAR 1		
962	LY31508-002B	DRUM BASE ASSY		
963	QYSPSPU1425M	SCREW	1.4mm x 2.5mm(x3)	
964	QAR0142-001	CAPSTAN MOTOR		
965	YQ43893	MINI SCREW		
966	LY10367-001D	MAIN DECK ASSY		
976	YQ44246	SLIT WASHER		
977	YQ44246-6	SLIT WASHER		
978	LY42047-005A	WASHER		
979	LY43987-001B	SPACER		

ELECTRONIC VIEWFINDER ASSEMBLY<M4>

△ Symbol No.	Part No.	Part Name	Description	Local
300	LY21043-001E	VF ASSY		
301	LY32995-001B	EYE CUP		
302	LY43961-001B	SHEET(LENS)		
303	LY32472-001A	LENS ASSY		
304	LY43868-001A	SPRING(LENS)		
305	LY32993-001C	GUIDE LENS(VF)		
306	LY33006-001C	LEVER(LENS)		
307	LY33442-001B	LCD UNIT ASSY		
308	LY20931-001B	U.CASE(VF)R		
309	LY20930-001B	U.CASE(VF)F		
310	LY33083-001A	PROTECTOR(VF)	(x2)	
311	QAL0466-002	FPC		
312	NSW0200-001X	LEVER SWITCH VF SW		
313	LY30030-059B	SPACER(A)		
314	LY30018-031A	SPECIAL SCREW	(x2)	
315	LY32996-001B	COVER(VF)		
316	LY30018-022A	SPECIAL SCREW	(x6)	
317	LY20929-001C	B.CASE(VF)		
318	LY33076-001E	VF HINGE ASSY		
318A	LY43962-001C	TOR.SPRING		
318B	LY30019-048A	SPECIAL SCREW		
319	LY30018-084A	SPECIAL SCREW	(x7)	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

MONITOR ASSEMBLY (2.5 INCH) <M5>

△ Symbol No.	Part No.	Part Name	Description	Local
500	LY21042-004B	MONITOR ASSY		
501	LY20932-003E	M.COVER(2.5)ASSY		
501A	LY33007-001C	KNOB(LOCK)M		
501B	LY33008-001A	HOLDER(LOCK)M		
501C	LY30002-047A	COMPRES. SPRING		
501D	LY30018-0C8A	SPECIAL SCREW	(x2)	
501E	LY30030-0E5A	SPACER(A)		
502	LY10407-001C	MONI.CASE(2.5)		
503	QYSPSPT1730R	SCREW	1.7mm x 3mm(x2)	
504	LY30018-0K9A	SPECIAL SCREW	(x2)	
506	LY33011-001C	LCD FRAME(2.5)		
507	QLD0262-001	LCD MODULE		
508	LY30029-0R5A	SPACER(A)	(x3)	
510	LY33010-001A	SHIELD CASE(2.5)		
512	QYSPSPT1720R	SCREW	1.7mm x 2mm	
513	LY33012-001A	DIFF.SHEET(2.5)		
514	LY43938-001A	LIGHT SCREEN		
515	LY33013-003B	MONI.HINGE ASSY		
515A	LY33015-002A	HINGE COVER(U)		
515B	LY32969-002A	HINGE COVER(L)		
515C	LY30018-0K1A	SPECIAL SCREW	(x2)	
516	LY43936-001A	HOLDER(LAMP)	(x2)	
517	LY43396-001A	SHEET(REFLECT)		
518	QLL0142-001	LAMP		

MAIN BOARD ASSEMBLY <01>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	YB10404J-02	MAIN BOARD ASSY		A,B,C,D,E
PW1	YB10404K-02	MAIN BOARD ASSY		F,G,H,J
IC1001	MN103S33NJD	IC(MICRO C ROM)		
IC1001 or	MN103SF33NY4JD	IC(MICRO C ROM)		
IC1002	MB90097PFV149-X	IC(MICRO C ROM)		
IC1003	SN74AHC1G00K-X	IC		
IC1003 or	SN74AHC1G00DC-X	IC		
IC1004	S-89220ACNC-W	IC		
IC1005	X25330S8I-2.5-X	IC		
IC1005 or	AT25320N-10SI-X	IC		
IC1005 or	M95320-WMN6-X	IC		
IC1005 or	25LC320-I/SN-X	IC		
IC1005 or	CAT25C32SI-X	IC		
IC1006	RS5C314-X	IC		
IC1007	IC-PST3423U-X	IC		
IC1007 or	S-80823CNNB-X	IC		
IC2101	AK5355VT-X	IC		F,G,H,J
IC2201	AK4564VQ	IC		
IC3001	JCY0152	IC		
IC3002	BU2501FV-X	IC		
IC3005	JCY0136-X	IC		
IC3701	BA7665FS-X	IC		
IC3851	JCP8055FP	IC		
IC4201	HD49340NP-X	IC		
IC4202	MM1613AN-X	IC		
IC4301	JCY0200	IC		
IC4302	R1160N151B-X	IC		
IC4802	BA10358FVM-W	IC		
IC4803	BA10358FVM-W	IC		
IC4804	UPC358G2/5/-W	IC		
IC4851	UPD16879GS-X	IC		
IC5501	JCY0185	IC		
IC6001	FA3698F	IC		
IC6801	R1224N102G-X	IC		
IC8701	PIX-MC10	IC		F,G,H,J
IC8702	MT48LC1M16TG-6S	IC		F,G,H,J
Q1001	DTA114EE-X	DIGI TRANSISTOR		
Q1001 or	PDTA114EE-X	DIGI TRANSISTOR		
Q1001 or	RN2102-X	DIGI TRANSISTOR		
Q1001 or	BCR183T-X	DIGI TRANSISTOR		
Q1002	UMC3N-W	DIGI TRANSISTOR		
Q1003	UMC3N-W	DIGI TRANSISTOR		
Q1004	UMC3N-W	DIGI TRANSISTOR		
Q1005	DTC143XE-X	DIGI TRANSISTOR		
Q1006	UMC3N-W	DIGI TRANSISTOR		
Q1007	2SC4617/QR/-X	TRANSISTOR		
Q1007 or	BC847BT-X	TRANSISTOR		
Q1008	DTC124EE-X	DIGI TRANSISTOR		
Q1008 or	PDTC124EE-X	DIGI TRANSISTOR		
Q1008 or	BCR141T-X	DIGI TRANSISTOR		
Q1009	2SJ347-X	MOS FET		
Q2001	UMX1N-W	PAIR TRANSISTOR		
Q2001 or	BC847S-X	PAIR TRANSISTOR		
Q2002	UMX1N-W	PAIR TRANSISTOR		
Q2002 or	BC847S-X	PAIR TRANSISTOR		
Q2003	UMX1N-W	PAIR TRANSISTOR		
Q2003 or	BC847S-X	PAIR TRANSISTOR		
Q2004	UMX1N-W	PAIR TRANSISTOR		
Q2004 or	BC847S-X	PAIR TRANSISTOR		
Q2005	UMX1N-W	PAIR TRANSISTOR		
Q2005 or	BC847S-X	PAIR TRANSISTOR		
Q2006	UMX1N-W	PAIR TRANSISTOR		
Q2006 or	BC847S-X	PAIR TRANSISTOR		
Q2202	UMX1N-W	PAIR TRANSISTOR		
Q2202 or	BC847S-X	PAIR TRANSISTOR		
Q2401	2SC4617/QR/-X	TRANSISTOR		
Q2401 or	BC847BT-X	TRANSISTOR		
Q2403	2SC4617/QR/-X	TRANSISTOR		
Q2403 or	BC847BT-X	TRANSISTOR		
Q3001	2SC4617/RS/-X	TRANSISTOR		
Q3001 or	BC847BT-X	TRANSISTOR		
Q3002	2SC4617/RS/-X	TRANSISTOR		
Q3002 or	BC847BT-X	TRANSISTOR		
Q3701	UMT1N-W	PAIR TRANSISTOR		

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
Q3701	or XP4401-W	TRANSISTOR		
Q3701	or BC856S-X	PAIR TRANSISTOR		
Q3702	UMZ1N-W	PAIR TRANSISTOR		
Q3702	or XP4601-W	TRANSISTOR		
Q3704	2SA1774/RS/-X	TRANSISTOR		
Q3704	or BC857BT-X	TRANSISTOR		
Q3705	UMT1N-W	PAIR TRANSISTOR		
Q3705	or XP4401-W	TRANSISTOR		
Q3705	or BC856S-X	PAIR TRANSISTOR		
Q4801	2SC4655/BC/-X	TRANSISTOR		
Q4806	2SC4617/QR/-X	TRANSISTOR		
Q4806	or BC847BT-X	TRANSISTOR		
Q4851	2SC4617/RS/-X	TRANSISTOR		
Q4851	or BC847BT-X	TRANSISTOR		
Q6101	SSM5G01TU-X	MOS FET		
Q6102	2SA1577/QR/-X	TRANSISTOR		
Q6102	or BC807-25W-X	TRANSISTOR		
Q6201	SSM5G01TU-X	MOS FET		
Q6301	SSM5G01TU-X	MOS FET		
Q6302	2SA1577/QR/-X	TRANSISTOR		
Q6302	or BC807-25W-X	TRANSISTOR		
Q6303	2SC4617/QR/-X	TRANSISTOR		
Q6303	or BC847BT-X	TRANSISTOR		
Q6401	SSM5G01TU-X	MOS FET		
Q6501	SSM5G01TU-X	MOS FET		
Q6601	CPH3314-X	MOS FET		
Q6602	UMX1N-W	PAIR TRANSISTOR		
Q6602	or HN1C01FU/G/-X	PAIR TRANSISTOR		
Q6602	or BC847S-X	PAIR TRANSISTOR		
Q6603	2SA1577/QR/-X	TRANSISTOR		
Q6603	or BC807-25W-X	TRANSISTOR		
Q6604	DTC144EE-X	DIGI TRANSISTOR		
Q6604	or BCR148T-X	DIGI TRANSISTOR		
Q6605	UMT1N-W	PAIR TRANSISTOR		
Q6605	or HN1A01FU/G/-X	PAIR TRANSISTOR		
Q6605	or BC856S-X	PAIR TRANSISTOR		
Q6606	2SC4617/QR/-X	TRANSISTOR		
Q6606	or BC847BT-X	TRANSISTOR		
Q6701	CPH3314-X	MOS FET		
Q6801	FML9-W	TRANSISTOR		
D1001	DA221-X	DIODE ARRAY		
D3001	EC2C01C-X	VARI CAP DIODE		
D3002	EC2C01C-X	VARI CAP DIODE		
D3003	EC2C01C-X	VARI CAP DIODE		
D3004	MA2Z720-X	SB DIODE		
D5501	1SS355-X	SI DIODE		
D6601	RB481K-X	SB DIODE		
D6602	RB480Y-W	SB DIODE		
D6701	RB160M-30-X	SB DIODE		
D6702	RB160M-30-X	SB DIODE		
△ D6801	RB715F-X	SB DIODE		
D8702	EMZ6.8N-X	Z DIODE		F,G,H,J
D8703	EMZ6.8N-X	Z DIODE		F,G,H,J
C1001	NDCA1HJ-8R0W	C CAPACITOR	8pF 50V J	
C1002	NDCA1HJ-100W	C CAPACITOR	10pF 50V J	
C1004	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1005	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1007	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1008	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1009	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1010	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1011	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1012	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1013	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1014	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1015	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1019	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1020	NCBA1EK-682W	C CAPACITOR	6800pF 25V K	
C1021	NCBA1EK-682W	C CAPACITOR	6800pF 25V K	
C1022	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1024	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1025	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1029	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1030	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C1032	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1035	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	

△ Symbol No.	Part No.	Part Name	Description	Local
C1036	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1037	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1038	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1039	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1040	NDCA1HJ-100W	C CAPACITOR	10pF 50V J	
C1041	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1042	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1043	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1044	NDCA1HJ-470W	C CAPACITOR	47pF 50V J	
C1045	NDCA1HJ-470W	C CAPACITOR	47pF 50V J	
C1046	NCF31AZ-105X	C CAPACITOR	1uF 10V Z	
C1047	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1048	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1049	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1050	NCFA1HZ-103W	C CAPACITOR	0.01uF 50V Z	
C1051	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C1052	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C1053	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C1054	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C1055	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C1064	NBE20JM-226X	TA E CAPACITOR	22uF 6.3V M	
C2105	NCBA1HK-222W	C CAPACITOR	2200pF 50V K	F,G,H,J
C2106	NCBA1HK-222W	C CAPACITOR	2200pF 50V K	F,G,H,J
C2107	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	F,G,H,J
C2108	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C2109	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C2110	NBE20JM-475X	TA E CAPACITOR	4.7uF 6.3V M	F,G,H,J
C2201	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2202	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2203	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2204	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2205	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2209	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2210	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2211	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2212	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2213	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2214	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2215	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2216	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2217	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2218	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2223	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2224	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2401	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2402	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2403	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2404	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2405	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C2406	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C2603	NCBA1CK-153W	C CAPACITOR	0.015uF 16V K	
C2604	NCBA1CK-153W	C CAPACITOR	0.015uF 16V K	
C2605	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C2606	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C2607	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C2608	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C2611	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2612	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2613	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C2614	NDCA1HJ-101W	C CAPACITOR	100pF 50V J	
C2615	NDCA1HJ-101W	C CAPACITOR	100pF 50V J	
C3001	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3003	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3005	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3006	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3007	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C3008	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3009	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3011	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3012	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3013	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3015	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3016	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3017	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3020	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3021	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3022	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3023	NDCA1HJ-330W	C CAPACITOR	33pF 50V J	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local	△ Symbol No.	Part No.	Part Name	Description	Local
C3024	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		C4307	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3025	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4308	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3026	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C4309	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3027	NCBA1EK-472W	C CAPACITOR	4700pF 25V K		C4310	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3028	NDCA1EJ-271W	C CAPACITOR	270pF 25V J		C4311	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3029	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4312	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3030	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4313	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3031	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4314	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3032	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		C4315	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3033	NDCA1HJ-220W	C CAPACITOR	22pF 50V J		C4316	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3036	NDCA1HJ-8R0W	C CAPACITOR	8pF 50V J		C4317	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3037	NDCA1HJ-8R0W	C CAPACITOR	8pF 50V J		C4803	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3038	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4804	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3039	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4806	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3042	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4808	NCB30JK-105X	C CAPACITOR	1uF 6.3V K	
C3043	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4809	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3044	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4810	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3045	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4811	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3046	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4812	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3047	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4813	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3048	NCB31CK-473X	C CAPACITOR	0.047uF 16V K		C4814	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3049	NCBA1HK-222W	C CAPACITOR	2200pF 50V K		C4815	NCB31HK-152X	C CAPACITOR	1500pF 50V K	
C3050	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4819	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C3055	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4851	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3059	NBE20GM-226X	TA E CAPACITOR	22uF 4V M		C4852	NCFA1AZ-104W	C CAPACITOR	0.1uF 10V Z	
C3060	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C4853	NBE21AM-335X	TA E CAPACITOR	3.3uF 10V M	
C3064	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		C4854	NBE21AM-106X	TA E CAPACITOR	10uF 10V M	
C3066	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C4855	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C3067	NCBA1HK-102W	C CAPACITOR	1000pF 50V K		C4858	NDCA1HJ-330W	C CAPACITOR	33pF 50V J	
C3069	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C4859	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C3701	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C4860	NCBA1CK-223W	C CAPACITOR	0.022uF 16V K	
C3702	NDCA1HJ-560W	C CAPACITOR	56pF 50V J		C4861	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3703	NDCA1HJ-270W	C CAPACITOR	27pF 50V J		C4862	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C3704	NDCA1HJ-680W	C CAPACITOR	68pF 50V J		C4864	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	
C3705	NDCA1HJ-270W	C CAPACITOR	27pF 50V J		C4865	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3706	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C5501	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3707	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5503	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3708	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C5504	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3709	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5506	NBE40GM-476X	TA E CAPACITOR	47uF 4V M	
C3712	NEA70GM-337X	E CAPACITOR	330uF 4V M		C5507	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3713	NEA70GM-337X	E CAPACITOR	330uF 4V M		C5508	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3715	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5509	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3801	NCB21AK-105X	C CAPACITOR	1uF 10V K		C5510	NBP21VM-105X	TA E CAPACITOR	1uF 35V M	
C3802	NCB21AK-105X	C CAPACITOR	1uF 10V K		C5511	NBZ0003-475X	TA E CAPACITOR	4.7uF 20V M	
C3803	NBE20GM-476X	TA E CAPACITOR	47uF 4V M		C5512	NBE21AM-106X	TA E CAPACITOR	10uF 10V M	
C3804	NBE20GM-476X	TA E CAPACITOR	47uF 4V M		C5513	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C3851	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5514	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3852	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5515	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3853	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5516	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3854	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5517	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C3855	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C5518	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3856	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C5519	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	
C3857	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6002	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C3858	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6003	NEA71CM-106X	E CAPACITOR	10uF 16V M	
C3859	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C6004	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C3860	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6021	NCB21CK-104X	C CAPACITOR	0.1uF 16V K	
C3861	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K		C6022	NCB21CK-104X	C CAPACITOR	0.1uF 16V K	
C4201	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M		C6023	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4202	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6024	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4203	NCB21AK-105X	C CAPACITOR	1uF 10V K		C6025	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4204	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6026	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C4205	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6027	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C4206	NCB21CK-105X	C CAPACITOR	1uF 16V K		C6029	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4207	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6030	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4208	NCB30JK-105X	C CAPACITOR	1uF 6.3V K		C6031	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4209	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6032	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C4210	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6033	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C4211	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6034	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4212	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6035	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4213	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6036	NDCA1HJ-101W	C CAPACITOR	100pF 50V J	
C4214	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6037	NCB21CK-473X	C CAPACITOR	0.047uF 16V K	
C4216	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6038	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	
C4301	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6039	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C4302	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6040	NCB31CK-473X	C CAPACITOR	0.047uF 16V K	
C4303	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6041	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C4304	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6042	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C4305	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6043	NCB31CK-223X	C CAPACITOR	0.022uF 16V K	
C4306	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K		C6044	NCBA1CK-103W	C CAPACITOR	0.01uF 16V K	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
C6045	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6101	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6103	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C6104	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C6105	NCBA1HK-561W	C CAPACITOR	560pF 50V K	
C6106	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6201	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6203	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C6204	NCBA1EK-472W	C CAPACITOR	4700pF 25V K	
C6301	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6303	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C6304	NCBA1HK-102W	C CAPACITOR	1000pF 50V K	
C6401	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6403	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6405	NCB31CK-683X	C CAPACITOR	0.068uF 16V K	
C6501	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6503	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6505	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6601	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6602	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6603	NCB11EK-105X	C CAPACITOR	1uF 25V K	
C6605	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6606	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6607	NCB11EK-105X	C CAPACITOR	1uF 25V K	
C6608	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C6609	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6701	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6703	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6801	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6802	NBE40JM-476X	TA E CAPACITOR	47uF 6.3V M	
C6804	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C6807	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C6809	NDCA1HJ-151W	C CAPACITOR	150pF 50V J	
C8701	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	F,G,H,J
C8702	NBE20JM-106X	TA E CAPACITOR	10uF 6.3V M	F,G,H,J
C8703	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8704	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8705	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8706	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8707	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8708	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8709	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8710	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8711	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8712	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
C8719	NCBA1AK-104W	C CAPACITOR	0.1uF 10V K	F,G,H,J
R1001	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R1002	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1003	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1006	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1007	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1008	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1009	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1010	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1011	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1012	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1013	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1014	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1015	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1016	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1017	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1018	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R1019	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1020	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1021	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1022	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1023	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1024	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1025	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1027	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1030	NRSA6AJ-753W	MG RESISTOR	75kΩ 1/16W J	
R1031	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
R1032	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1033	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1034	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1035	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1037	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J	

△ Symbol No.	Part No.	Part Name	Description	Local
R1038	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1039	NRSA6AJ-152W	MG RESISTOR	1.5kΩ 1/16W J	
R1040	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1041	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1042	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R1043	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1044	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1045	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R1046	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1047	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1048	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1049	NRSA6AJ-623W	MG RESISTOR	62kΩ 1/16W J	
R1050	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
R1051	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R1052	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1053	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R1054	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1055	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
R1056	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
R1057	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1058	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1059	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1060	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1061	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J	
R1062	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	
R1063	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R1064	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1065	NRSA6AJ-153W	MG RESISTOR	15kΩ 1/16W J	
R1066	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1067	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
R1068	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1069	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1070	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J	
R1071	NRSA6AJ-272W	MG RESISTOR	2.7kΩ 1/16W J	
R1072	NRSA6AJ-183W	MG RESISTOR	18kΩ 1/16W J	
R1073	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1074	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R1075	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R1076	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R1077	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1078	NRSA6AJ-393W	MG RESISTOR	39kΩ 1/16W J	
R1079	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J	
R1080	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J	
R1081	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1082	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J	
R1083	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1084	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1085	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1086	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1087	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1088	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1089	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R1091	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1092	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1093	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1094	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R1095	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R1096	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1097	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R1099	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R2001	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2002	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2003	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2004	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2005	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2006	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2007	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2008	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2009	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2010	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2011	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2012	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R2101	NRSA6AJ-471W	MG RESISTOR	470Ω 1/16W J	F,G,H,J
R2102	NRSA6AJ-471W	MG RESISTOR	470Ω 1/16W J	F,G,H,J
R2105	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R2107	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R2108	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R2109	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local	△ Symbol No.	Part No.	Part Name	Description	Local
R2110	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J	R3705	NRSA6AD-301W	MG RESISTOR	300Ω 1/16W D	
R2201	NRSA6AJ-684W	MG RESISTOR	680kΩ 1/16W J		R3706	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R2202	NRSA6AJ-564W	MG RESISTOR	560kΩ 1/16W J		R3707	NRSA6AD-680W	MG RESISTOR	68Ω 1/16W D	
R2203	NRSA6AJ-393W	MG RESISTOR	39kΩ 1/16W J		R3708	NRSA6AD-680W	MG RESISTOR	68Ω 1/16W D	
R2204	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J		R3709	NRSA6AD-680W	MG RESISTOR	68Ω 1/16W D	
R2206	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J		R3710	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R2207	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J		R3711	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R2208	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J		R3712	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R2209	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J		R3713	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R2210	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3714	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
R2211	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3715	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R2212	NRSA6AJ-2R7W	MG RESISTOR	2.7Ω 1/16W J		R3722	NRSA6AD-131W	MG RESISTOR	130Ω 1/16W D	
R2213	NRSA6AJ-2R7W	MG RESISTOR	2.7Ω 1/16W J		R3724	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R2217	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R3725	NRSA6AD-131W	MG RESISTOR	130Ω 1/16W D	
R2218	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R3726	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R2219	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3727	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R2220	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3728	NRSA6AD-131W	MG RESISTOR	130Ω 1/16W D	
R2221	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3730	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R2222	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R3807	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R2223	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R3851	NRSA6AJ-101W	MG RESISTOR	100Ω 1/16W J	
R2224	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R3852	NRSA6AD-821W	MG RESISTOR	820Ω 1/16W D	
R2225	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3853	NRSA6AD-273W	MG RESISTOR	27kΩ 1/16W D	
R2226	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R3854	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D	
R2229	NRSA6AJ-564W	MG RESISTOR	560kΩ 1/16W J		R3855	NRSA6AD-821W	MG RESISTOR	820Ω 1/16W D	
R2230	NRSA6AJ-564W	MG RESISTOR	560kΩ 1/16W J		R4201	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R2231	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R4202	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2401	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R4203	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2402	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R4204	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R2403	NRSA6AJ-183W	MG RESISTOR	18kΩ 1/16W J		R4205	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R2406	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4301	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R2407	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R4303	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2601	NRSA6AJ-182W	MG RESISTOR	1.8kΩ 1/16W J		R4304	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2602	NRSA6AJ-182W	MG RESISTOR	1.8kΩ 1/16W J		R4306	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2607	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R4307	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R2608	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R4308	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R2609	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J		R4309	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R2610	NRSA6AJ-223W	MG RESISTOR	22kΩ 1/16W J		R4310	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3002	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4315	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3004	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4317	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3005	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R4319	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3006	NRSA6AJ-100W	MG RESISTOR	10Ω 1/16W J		R4321	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3007	NRSA6AJ-562W	MG RESISTOR	5.6kΩ 1/16W J		R4326	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R3008	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R4327	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3009	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4328	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3010	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4329	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3011	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J		R4330	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3013	NRSA6AJ-242W	MG RESISTOR	2.4kΩ 1/16W J		R4331	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3014	NRSA6AJ-392W	MG RESISTOR	3.9kΩ 1/16W J		R4332	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3015	NRSA6AJ-392W	MG RESISTOR	3.9kΩ 1/16W J		R4333	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3016	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D		R4334	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3017	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D		R4335	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3018	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D		R4336	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3019	NRVA6AD-560W	CMF RESISTOR	56Ω 1/16W D		R4337	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3020	NRVA6AD-512W	CMF RESISTOR	5.1kΩ 1/16W D		R4338	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R3021	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4339	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3025	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J		R4341	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3027	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4342	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3029	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J		R4343	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3030	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J		R4344	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3031	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J		R4345	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R3032	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J		R4346	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R3034	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J		R4348	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3036	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4349	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3037	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J		R4350	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3057	NRSA6AJ-151W	MG RESISTOR	150Ω 1/16W J		R4351	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3066	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J		R4352	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3067	NRSA6AJ-561W	MG RESISTOR	560Ω 1/16W J		R4353	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3068	NRSA6AJ-181W	MG RESISTOR	180Ω 1/16W J		R4354	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3069	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J		R4355	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3071	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J		R4356	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R3074	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J		R4804	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R3081	NRSA6AJ-471W	MG RESISTOR	470Ω 1/16W J	F,G,H,J	R4805	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R3082	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	A,B,C,D,E	R4806	NRSA6AJ-683W	MG RESISTOR	68kΩ 1/16W J	
R3083	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J	R4807	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
R3701	NRSA6AD-271W	MG RESISTOR	270Ω 1/16W D		R4808	NRSA6AJ-243W	MG RESISTOR	24kΩ 1/16W J	
R3702	NRSA6AD-271W	MG RESISTOR	270Ω 1/16W D		R4809	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J	
R3703	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J		R4810	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R3704	NRSA6AD-301W	MG RESISTOR	300Ω 1/16W D		R4811	NRSA6AJ-824W	MG RESISTOR	820kΩ 1/16W J	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
R4812	NRSA6AJ-153W	MG RESISTOR	15kΩ 1/16W J	
R4814	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R4815	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R4816	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	
R4817	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	
R4818	NRSA6AJ-154W	MG RESISTOR	150kΩ 1/16W J	
R4819	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R4820	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R4821	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R4822	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R4823	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4824	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R4827	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4828	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4833	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R4836	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4841	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4842	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4843	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4844	NRSA6AJ-151W	MG RESISTOR	150Ω 1/16W J	
R4854	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4856	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R4857	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R4858	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R4859	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4860	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4862	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R4863	NRSA6AJ-6R8W	MG RESISTOR	6.8Ω 1/16W J	
R4864	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4865	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4866	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4867	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R4868	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4870	NRSA6AJ-271W	MG RESISTOR	270Ω 1/16W J	
R4871	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4874	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R4875	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R5501	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R5503	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R5504	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R5505	NRSA6AJ-220W	MG RESISTOR	22Ω 1/16W J	
R5506	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R5507	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R5509	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R5511	NRSA6AJ-470W	MG RESISTOR	47Ω 1/16W J	
R5512	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R5513	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R5514	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6021	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6022	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6023	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6024	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6025	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6026	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6027	NRSA6AD-103W	MG RESISTOR	10kΩ 1/16W D	
R6028	NRSA6AD-751W	MG RESISTOR	750Ω 1/16W D	
R6029	NRSA6AD-103W	MG RESISTOR	10kΩ 1/16W D	
R6030	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R6031	NRSA6AJ-472W	MG RESISTOR	4.7kΩ 1/16W J	
R6033	NRSA6AJ-562W	MG RESISTOR	5.6kΩ 1/16W J	
R6034	NRSA6AJ-153W	MG RESISTOR	15kΩ 1/16W J	
R6035	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6036	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6037	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D	
R6038	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6039	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6040	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R6042	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R6044	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	
R6102	NRVA6AD-223W	CMF RESISTOR	22kΩ 1/16W D	
R6103	NRVA6AD-103W	CMF RESISTOR	10kΩ 1/16W D	
R6104	NRSA6AJ-474W	MG RESISTOR	470kΩ 1/16W J	
R6105	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6106	NRSA6AJ-332W	MG RESISTOR	3.3kΩ 1/16W J	
R6107	NRSA6AD-183W	MG RESISTOR	18kΩ 1/16W D	
R6108	NRSA6AD-123W	MG RESISTOR	12kΩ 1/16W D	
R6109	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R6202	NRSA6AD-123W	MG RESISTOR	12kΩ 1/16W D	

△ Symbol No.	Part No.	Part Name	Description	Local
R6203	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D	
R6302	NRSA6AD-183W	MG RESISTOR	18kΩ 1/16W D	
R6303	NRSA6AD-472W	MG RESISTOR	4.7kΩ 1/16W D	
R6305	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6306	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J	
R6308	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R6309	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R6402	NRSA6AD-243W	MG RESISTOR	24kΩ 1/16W D	
R6403	NRSA6AD-302W	MG RESISTOR	3kΩ 1/16W D	
R6405	NRSA6AJ-123W	MG RESISTOR	12kΩ 1/16W J	
R6406	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R6407	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6502	NRSA6AD-473W	MG RESISTOR	47kΩ 1/16W D	
R6503	NRSA6AD-562W	MG RESISTOR	5.6kΩ 1/16W D	
R6505	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	
R6506	NRSA6AJ-273W	MG RESISTOR	27kΩ 1/16W J	
R6602	NRSA6AD-114W	MG RESISTOR	110kΩ 1/16W D	
R6603	NRSA6AD-392W	MG RESISTOR	3.9kΩ 1/16W D	
R6604	NRSA6AD-114W	MG RESISTOR	110kΩ 1/16W D	
R6605	NRSA6AJ-222W	MG RESISTOR	2.2kΩ 1/16W J	
R6606	NRSA6AD-104W	MG RESISTOR	100kΩ 1/16W D	
R6607	NRSA6AD-473W	MG RESISTOR	47kΩ 1/16W D	
R6608	NRSA6AJ-273W	MG RESISTOR	27kΩ 1/16W J	
R6609	NRSA6AJ-822W	MG RESISTOR	8.2kΩ 1/16W J	
R6610	NRSA6AD-473W	MG RESISTOR	47kΩ 1/16W D	
R6611	NRSA6AD-683W	MG RESISTOR	68kΩ 1/16W D	
R6612	NRSA6AJ-104W	MG RESISTOR	100kΩ 1/16W J	
R6613	NRSA6AJ-823W	MG RESISTOR	82kΩ 1/16W J	
R6614	NRSA6AD-104W	MG RESISTOR	100kΩ 1/16W D	
R6615	NRSA6AD-104W	MG RESISTOR	100kΩ 1/16W D	
R6616	NRSA6AJ-103W	MG RESISTOR	10kΩ 1/16W J	
R6617	NRSA6AJ-333W	MG RESISTOR	33kΩ 1/16W J	
R6618	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6619	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R6701	NRZ0058-R20X	MG RESISTOR	0.2Ω 1/2W J	
R6702	NRSA6AD-114W	MG RESISTOR	110kΩ 1/16W D	
R6703	NRSA6AD-153W	MG RESISTOR	15kΩ 1/16W D	
R6704	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	
R6706	NRSA6AD-823W	MG RESISTOR	82kΩ 1/16W D	
R6707	NRSA6AD-333W	MG RESISTOR	33kΩ 1/16W D	
R6801	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6803	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	
R6804	NRVA6AD-563W	CMF RESISTOR	56kΩ 1/16W D	
△ R6805	NRSA6AJ-102W	MG RESISTOR	1kΩ 1/16W J	
R6813	NRVA6AD-273W	CMF RESISTOR	27kΩ 1/16W D	
R6815	NRSA6AJ-681W	MG RESISTOR	680Ω 1/16W J	
R8059	NRSA6AJ-473W	MG RESISTOR	47kΩ 1/16W J	A,B,C,D,E
R8701	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8702	NRS181J-220X	MG RESISTOR	22Ω 1/8W J	F,G,H,J
R8703	NRS181J-220X	MG RESISTOR	22Ω 1/8W J	F,G,H,J
R8704	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	F,G,H,J
R8705	NRSA6AJ-152W	MG RESISTOR	1.5kΩ 1/16W J	F,G,H,J
R8706	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	F,G,H,J
R8707	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8708	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8709	NRSA6AJ-105W	MG RESISTOR	1MΩ 1/16W J	F,G,H,J
R8710	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8711	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8712	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8713	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8715	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8716	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8717	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8718	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8720	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8721	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
R8722	NRSA6AJ-224W	MG RESISTOR	220kΩ 1/16W J	F,G,H,J
R8723	NRSA6AJ-334W	MG RESISTOR	330kΩ 1/16W J	F,G,H,J
R8724	NRSA6AJ-0R0W	MG RESISTOR	0Ω 1/16W J	F,G,H,J
RA1001	NRZ0034-473W	NET RESISTOR	47kΩ 1/32W J	
RA1002	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J	
RA1004	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J	
RA1005	NRZ0034-103W	NET RESISTOR	10kΩ 1/32W J	
RA1006	NRZ0034-102W	NET RESISTOR	1kΩ 1/32W J	
RA1007	NRZ0034-102W	NET RESISTOR	1kΩ 1/32W J	
RA1008	NRZ0034-104W	NET RESISTOR	100kΩ 1/32W J	
RA3001	NRZ0034-560W	NET RESISTOR	56Ω 1/32W J	
RA3002	NRZ0034-560W	NET RESISTOR	56Ω 1/32W J	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
RA3003	NRZ0034-100W	NET RESISTOR	10Ω 1/32W J	
RA3004	NRZ0034-103W	NET RESISTOR	10kΩ 1/32W J	
RA3005	NRZ0040-0R0X	NET RESISTOR	0Ω 1/16W J	
L1001	NQL402M-100X	COIL	10uH M	
L1002	NQL402M-100X	COIL	10uH M	
L2101	NQL315K-100X	COIL	10uH K	F,G,H,J
L2401	NQL402M-100X	COIL	10uH M	
L2402	NQL402M-100X	COIL	10uH M	
L2604	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
L3001	NQR0129-002X	FERRITE BEADS		
L3002	NQR0129-002X	FERRITE BEADS		
L3004	NQR0006-001X	FERRITE BEADS		
L3005	NQR0006-001X	FERRITE BEADS		
L3007	NQL085J-2R2X	COIL	2.2uH J	
L3008	NQL085J-120X	COIL	12uH J	
L3012	NQR0129-002X	FERRITE BEADS		
L3014	NQL38DK-100X	P COIL	10uH K	
L3015	NQR0006-001X	FERRITE BEADS		
L3701	NQL38DK-100X	P COIL	10uH K	
L3801	NQR0129-002X	FERRITE BEADS		
L3802	NQR0129-002X	FERRITE BEADS		
L3803	NQR0006-001X	FERRITE BEADS		
L3804	NQL38DK-100X	P COIL	10uH K	
L4201	NQR0129-002X	FERRITE BEADS		
L4301	NQR0129-002X	FERRITE BEADS		
L4302	NQR0129-002X	FERRITE BEADS		
L4802	NQL302N-100X	COIL	10uH N	
L4851	NQR0129-002X	FERRITE BEADS		
L4852	NQL315K-100X	COIL	10uH K	
L4853	NQL315K-100X	COIL	10uH K	
L5501	NQL315K-100X	COIL	10uH K	
L5502	NQR0129-002X	FERRITE BEADS		
L5503	NQR0129-002X	FERRITE BEADS		
L5504	NQR0129-002X	FERRITE BEADS		
L5505	NQL315K-100X	COIL	10uH K	
L5506	NQL315K-100X	COIL	10uH K	
L6001	NQLZ011-4R7X	COIL	4.7uH N	
L6002	NQLZ011-4R7X	COIL	4.7uH N	
L6101	NQL52EM-390X	COIL	39uH M	
L6201	NQL52EM-390X	COIL	39uH M	
L6301	NQL52EM-390X	COIL	39uH M	
L6302	NQL144K-220X	P COIL	22uH K	
L6401	NQL52EM-470X	COIL	47uH M	
L6501	NQL52EM-470X	COIL	47uH M	
L6601	NQL52EM-221X	COIL	220uH M	
L6701	NQL73EM-100X	COIL	10uH M	
L6801	NQL034K-470X	P COIL	47uH K	
L8701	NQR0129-002X	FERRITE BEADS		F,G,H,J
L8702	NQR0129-002X	FERRITE BEADS		F,G,H,J
CN101	QGF0528F1-40X	CONNECTOR	FFC/FPC (1-40)	
CN102	QGF0505F1-22X	CONNECTOR	FFC/FPC (1-22)	
CN104	QGA1002C1-11X	CONNECTOR	W-B (1-11)	
CN105	QGB0509M1-30X	CONNECTOR	B-B (1-30)	
CN106	QGA1201C2-05X	CONNECTOR	W-B (1-5)	
CN107	QGF0503C1-20X	CONNECTOR	FFC/FPC (1-20)	
CN108	QGF0503C1-24V	CONNECTOR	FFC/FPC (1-24)	
CN109	QGF0503F1-16X	CONNECTOR	FFC/FPC (1-16)	
CN110	QGF0528F1-40X	CONNECTOR	FFC/FPC (1-40)	
CN111	QGF0528F1-40X	CONNECTOR	FFC/FPC (1-40)	
△ F6001	NMFZ007-2R0X-K	FUSE	2A 32V	
△ F6301	NMFZ007-1R25X-K	FUSE	1.25A 32V	
△ F6701	NMFZ007-1R25X-K	FUSE	1.25A 32V	
△ F6801	NMFZ007-R50X-K	FUSE	0.5A 50V	
J501	NNZ0041-001X	D CONNECTOR	IEEE1394(4pin)	
J502	QNZ0616-001	USB CONNECTOR		F,G,H,J
X1001	NAX0578-001X	CRYSTAL		
X1002	NAX0564-001X	CRYSTAL		
X3002	NAX0480-001X	CRYSTAL	24.576MHz	
X5501	NAX0587-001X	CXO		
X8701	NAX0398-001X	C OSCILLATOR		F,G,H,J
OT1	LY30030-069A	SPACER(A)		
OT2	LY44158-001A	SHEET(SHIELD)		
WR1	QAL0474-001	FPC	MAIN-PREMDA CN401	
WR2	QAL0474-001	FPC	MAIN-PREMDA CN408	

MONI-BW BOARD ASSEMBLY <02>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	YB10433E	MONI-BW BOARD ASSY		
IC7601	AN12550A	IC		
IC7602	BA4558F-X	IC		
Q7601	2SC4617/QR/-X	TRANSISTOR		
Q7601 or	2SC4738/YG/-X	TRANSISTOR		
Q7601 or	2SD2216J/QR/-X	TRANSISTOR		
Q7601 or	BC847BT-X	TRANSISTOR		
Q7602	2SA1774/QR/-X	TRANSISTOR		
Q7602 or	2SA1832/YG/-X	TRANSISTOR		
Q7602 or	BC857BT-X	TRANSISTOR		
Q7603	2SC4617/QR/-X	TRANSISTOR		
Q7603 or	2SC4738/YG/-X	TRANSISTOR		
Q7603 or	2SD2216J/QR/-X	TRANSISTOR		
Q7603 or	BC847BT-X	TRANSISTOR		
Q7604	2SA1774/QR/-X	TRANSISTOR		
Q7604 or	2SA1832/YG/-X	TRANSISTOR		
Q7604 or	BC857BT-X	TRANSISTOR		
Q7608	DTC144EE-X	DIGI TRANSISTOR		
Q7608 or	UN9213J-X	DIGI TRANSISTOR		
Q7608 or	RN1104-X	DIGI TRANSISTOR		
Q7608 or	BCR148T-X	DIGI TRANSISTOR		
Q7609	2SC4617/QR/-X	TRANSISTOR		
Q7609 or	2SC4738/YG/-X	TRANSISTOR		
Q7609 or	2SD2216J/QR/-X	TRANSISTOR		
Q7609 or	BC847BT-X	TRANSISTOR		
Q7610	DTA114EE-X	DIGI TRANSISTOR		
Q7610 or	BCR183T-X	DIGI TRANSISTOR		
Q7611	DTC144EE-X	DIGI TRANSISTOR		
Q7611 or	UN9213J-X	DIGI TRANSISTOR		
Q7611 or	RN1104-X	DIGI TRANSISTOR		
Q7611 or	BCR148T-X	DIGI TRANSISTOR		
Q7612	DTA144EE-X	DIGI TRANSISTOR		
Q7612 or	UN9113J-X	DIGI TRANSISTOR		
Q7612 or	RN2104-X	DIGI TRANSISTOR		
Q7612 or	BCR198T-X	DIGI TRANSISTOR		
Q7613	2SD2654/VW/-X	TRANSISTOR		
D7602	1SS355-X	SI DIODE		
C1	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C10	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7601	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7602	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7603	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7604	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7605	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7606	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7607	NCB41CK-106X	C CAPACITOR	10uF 16V K	
C7608	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7609	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7613	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7614	NCB31HK-152X	C CAPACITOR	1500pF 50V K	
C7615	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7616	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7617	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7618	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C7619	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
C7620	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7621	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7622	NCB21CK-105X	C CAPACITOR	1uF 16V K	
C7623	NBE21AM-106X	TA E CAPACITOR	10uF 10V M	
C7624	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7626	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7627	NCF31CZ-104X	C CAPACITOR	0.1uF 16V Z	
C7628	NBP41EM-475X	TA E CAPACITOR	4.7uF 25V M	
C7629	NBP21CM-335X	TA E CAPACITOR	3.3uF 16V M	
C7630	NBP41EM-475X	TA E CAPACITOR	4.7uF 25V M	
C7631	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7632	NBP41EM-475X	TA E CAPACITOR	4.7uF 25V M	
C7633	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7634	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7635	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7637	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7646	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

△ Symbol No.	Part No.	Part Name	Description	Local
C7647	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7651	NCB11CK-225X	C CAPACITOR	2.2uF 16V K	
C7661	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7662	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7663	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7664	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7665	NBP41CM-226X	TA E CAPACITOR	22uF 16V M	
C7666	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
R3	NRSA63J-103X	MG RESISTOR	10kΩ 1/16W J	
R4	NRSA63J-332X	MG RESISTOR	3.3kΩ 1/16W J	
R5	NRSA63J-682X	MG RESISTOR	6.8kΩ 1/16W J	
R6	NRSA63J-223X	MG RESISTOR	22kΩ 1/16W J	
R7	NRSA63J-103X	MG RESISTOR	10kΩ 1/16W J	
R8	NRSA63J-332X	MG RESISTOR	3.3kΩ 1/16W J	
R7601	NRVA63D-622X	CMF RESISTOR	6.2kΩ 1/16W D	
R7602	NRSA63J-153X	MG RESISTOR	15kΩ 1/16W J	
R7603	NRSA63J-683X	MG RESISTOR	68kΩ 1/16W J	
R7608	NRSA63J-153X	MG RESISTOR	15kΩ 1/16W J	
R7609	NRVA63D-223X	CMF RESISTOR	22kΩ 1/16W D	
R7610	NRVA63D-433X	CMF RESISTOR	43kΩ 1/16W D	
R7611	NRVA63D-821X	CMF RESISTOR	820Ω 1/16W D	
R7612	NRVA63D-223X	CMF RESISTOR	22kΩ 1/16W D	
R7613	NRVA63D-223X	CMF RESISTOR	22kΩ 1/16W D	
R7614	NRVA63D-223X	CMF RESISTOR	22kΩ 1/16W D	
R7615	NRSA63J-223X	MG RESISTOR	22kΩ 1/16W J	
R7616	NRSA63J-223X	MG RESISTOR	22kΩ 1/16W J	
R7617	NRSA02J-561X	MG RESISTOR	560Ω 1/10W J	
R7618	NRSA02J-561X	MG RESISTOR	560Ω 1/10W J	
R7620	NRSA63J-335X	MG RESISTOR	3.3MΩ 1/16W J	
R7621	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7630	NRSA63J-223X	MG RESISTOR	22kΩ 1/16W J	
R7634	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7636	NRSA63J-101X	MG RESISTOR	100Ω 1/16W J	
R7637	NRSA63J-101X	MG RESISTOR	100Ω 1/16W J	
R7638	NRSA63J-101X	MG RESISTOR	100Ω 1/16W J	
R7661	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7662	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7663	NRSA63J-103X	MG RESISTOR	10kΩ 1/16W J	
R7666	NRSA63J-153X	MG RESISTOR	15kΩ 1/16W J	
R7667	NRVA63D-273X	CMF RESISTOR	27kΩ 1/16W D	
R7668	NRVA63D-273X	CMF RESISTOR	27kΩ 1/16W D	
R7669	NRVA63D-392X	CMF RESISTOR	3.9kΩ 1/16W D	
R7672	NRSA63D-394X	MG RESISTOR	390kΩ 1/16W D	
R7673	NRVA63D-473X	CMF RESISTOR	47kΩ 1/16W D	
R7674	NRVA63D-473X	CMF RESISTOR	47kΩ 1/16W D	
R7675	NRSA63J-274X	MG RESISTOR	270kΩ 1/16W J	
L7601	NQL365K-100X	COIL	10uH K	
L7602	NQL365K-470X	COIL	47uH K	
L7603	NQL365K-470X	COIL	47uH K	
L7604	NQL365K-100X	COIL	10uH K	
L7605	NQL365K-100X	COIL	10uH K	
L7607	NQL365K-100X	COIL	10uH K	
CN761	QGF0508F1-40X	CONNECTOR	FFC/FPC (1-40)	
CN763	QGF0507F3-20X	CONNECTOR	FFC/FPC (1-20)	
CN765	QGF0506F2-32X	CONNECTOR	FFC/FPC (1-32)	
SW2	NSW0145-001X	TACT SWITCH STOP		
SW3	NSW0145-001X	TACT SWITCH REW		
SW4	NSW0145-001X	TACT SWITCH FF		
SW5	NSW0145-001X	TACT SWITCH PLAY/PAUSE		
SW7	NSW0145-001X	TACT SWITCH INDEX		
SW8	NSW0145-001X	TACT SWITCH SELECT		
SW7601	NSW0200-001X	LEVER SWITCH MONI SW		

BL-2.5 BOARD ASSEMBLY <03>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	YB20938A	BL-2.5 BOARD ASSY		
IC7604	DN8797MS-X	IC		
Q7501	2SD1664/QR/-W	TRANSISTOR		

△ Symbol No.	Part No.	Part Name	Description	Local
Q7502	2SD1664/QR/-W	TRANSISTOR		
Q7503	DTA144EE-X	DIGI TRANSISTOR		
Q7503 or	UN9113J-X	DIGI TRANSISTOR		
Q7503 or	RN2104-X	DIGI TRANSISTOR		
Q7503 or	BCR198T-X	DIGI TRANSISTOR		
Q7504	DTC144EE-X	DIGI TRANSISTOR		
Q7504 or	UN9213J-X	DIGI TRANSISTOR		
Q7504 or	RN1104-X	DIGI TRANSISTOR		
Q7504 or	BCR148T-X	DIGI TRANSISTOR		
C7501	NCZ1016-120X	C CAPACITOR	12pF 2kV J	
C7502	NCB21EK-273X	C CAPACITOR	0.027uF 25V K	
C7503	NCB31EK-103X	C CAPACITOR	0.01uF 25V K	
C7504	NCB10JK-106X	C CAPACITOR	10uF 6.3V K	
R7501	NRSA63J-102X	MG RESISTOR	1kΩ 1/16W J	
R7502	NRSA63J-102X	MG RESISTOR	1kΩ 1/16W J	
R7503	NRSA63J-102X	MG RESISTOR	1kΩ 1/16W J	
R7504	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7511	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7512	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
R7513	NRSA63J-0R0X	MG RESISTOR	0Ω 1/16W J	
L7501	NQLZ010-680X	COIL	68uH M	
△ T7501	NQS0056-001X	SW TARN SF		
CN7601	QGF0507F3-16X	CONNECTOR	FFC/FPC (1-16)	
CN7602	QGF0507F3-16X	CONNECTOR	FFC/FPC (1-16)	
CN7603	QGF0508F1-24X	CONNECTOR	FFC/FPC (1-24)	
△ F7501	NMFZ007-R40X-K	FUSE	0.4A 50V	
WR1	QAL0464-001	FPC		

CCD BOARD ASSEMBLY <04>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	YB20942A-SS	CCD BOARD ASSY		
Q5001	2SC3931/CD/-X	TRANSISTOR		
C5001	NBP41EM-475X	TA E CAPACITOR	4.7uF 25V M	
C5002	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5003	NBE21AM-106X	TA E CAPACITOR	10uF 10V M	
C5004	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5005	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5006	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C5007	NCB31EK-222X	C CAPACITOR	2200pF 25V K	
R5001	NRSA63J-472X	MG RESISTOR	4.7kΩ 1/16W J	
R5002	NRSA63J-104X	MG RESISTOR	100kΩ 1/16W J	
L5001	NQL315K-100X	COIL	10uH K	
L5002	NQL315K-100X	COIL	10uH K	
CN5001	QGF0517F2-20X	CONNECTOR	FFC/FPC (1-20)	

PREMDA BOARD ASSEMBLY <05>

△ Symbol No.	Part No.	Part Name	Description	Local
PW1	YB10405A-01	PREMDA BOARD ASSY		
IC1601	BD6637KS	IC		
IC1701	LM358DMR2-X	IC		
IC1702	LM393DMR2-X	IC		
IC3501	JCY0132	IC		
IC3502	SN74AHC1G04K-X IC			
Q1601	UMC3N-W	DIGI TRANSISTOR		
D1602	DAP222-X	DIODE ARRAY		
D1602 or	MA132WA-X	SI DIODE		

MODEL	MARK	MODEL	MARK	MODEL	MARK
GR-D20EK	A	GR-D20EZ	D	GR-D40EX	G
GR-D20EX	B	GR-D21EK	E	GR-D40EY	H
GR-D20EY	C	GR-D40EK	F	GR-D40EZ	J

 Symbol No.	Part No.	Part Name	Description	Local
R502	NRSA63J-684X	MG RESISTOR	680k Ω 1/16W J	
R503	NRSA63J-182X	MG RESISTOR	1.8k Ω 1/16W J	
R504	NRSA63J-222X	MG RESISTOR	2.2k Ω 1/16W J	
R505	NRSA63J-103X	MG RESISTOR	10k Ω 1/16W J	
R506	NRSA63J-824X	MG RESISTOR	820k Ω 1/16W J	
R507	NRSA63J-104X	MG RESISTOR	100k Ω 1/16W J	
R508	NRSA63J-683X	MG RESISTOR	68k Ω 1/16W J	
R509	NRSA63J-822X	MG RESISTOR	8.2k Ω 1/16W J	
R510	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R511	NRSA63J-302X	MG RESISTOR	3k Ω 1/16W J	
R512	NRSA63J-470X	MG RESISTOR	47 Ω 1/16W J	
R513	NRSA63J-101X	MG RESISTOR	100 Ω 1/16W J	
R514	NRSA63J-101X	MG RESISTOR	100 Ω 1/16W J	
R515	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R516	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R517	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R518	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R519	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R520	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R521	NRSA63J-0R0X	MG RESISTOR	0 Ω 1/16W J	
R522	NRSA63J-221X	MG RESISTOR	220 Ω 1/16W J	
R523	NRSA63J-331X	MG RESISTOR	330 Ω 1/16W J	
L501	NQR0251-004X	FERRITE BEADS		
L502	NQR0251-004X	FERRITE BEADS		
L503	NQR0251-004X	FERRITE BEADS		
CN501	QGF0503C1-22X	CONNECTOR	FFC/FPC (1-22)	
J501	QNS0078-001	3.5 JACK		
J502	QND0004-001	S JACK		
J503	PEMC1203	MINI JACK		
SW501	NSW0122-001X	DETECT SWITCH EJECT SW		

B/W-VF BOARD ASSEMBLY <07>


 Symbol No.	Part No.	Part Name	Description	Local
PW1	YB20940A	B/W-VF BOARD ASSY		
Q7001	PUMX1-W	PAIR TRANSISTOR		
Q7001 or	BC847S-X	PAIR TRANSISTOR		
D7001	E1S35AW0C501-X	LED		
C7001	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7002	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7003	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
C7004	NCB31CK-104X	C CAPACITOR	0.1uF 16V K	
R7001	NRSA63J-332X	MG RESISTOR	3.3k Ω 1/16W J	
R7002	NRSA63J-561X	MG RESISTOR	560 Ω 1/16W J	
R7003	NRSA63J-470X	MG RESISTOR	47 Ω 1/16W J	
R7004	NRSA63J-102X	MG RESISTOR	1k Ω 1/16W J	
CN7001	QGF0532F1-18X	CONNECTOR	FFC/FPC (1-18)	
CN7002	QGF0507F3-20X	CONNECTOR	FFC/FPC (1-20)	

JVC


SERVICE MANUAL

MECHANISM ASSEMBLY


DVC MECHANISM VHS-C MECHANISM VHS MECHANISM



<DVC MECHANISM>



<VHS-C MECHANISM>



<VHS MECHANISM>

TABLE OF CONTENTS

1	JIGS AND TOOLS	1-1
2	SPECIFIC SERVICE INSTRUCTIONS	2-1
3	PARTS LIST	3-1

SECTION 1

JIGS AND TOOLS

1.1 TOOLS REQUIRED FOR ADJUSTMENTS







1. Torque driver YTU94088	2. Bit YTU94088-003
	
3. Tweezers P-895	4. Chip IC replacement jig PTS40844-2
	
5. Slit washer installation jig YTU94121A	6. Cleaning cloth KSMM-01
	

Fig.1-1-1

1. Torque driver

Be sure to use to fastening the mechanism and exterior parts because those parts must strictly be controlled for tightening torque.

Torque setting value of torque driver is limited. At the values over the maximum torque setting value, fasten a screw manually not to damage the screw thread.

2. Bit

This bit is slightly longer than those set in conventional torque drivers.

3. Tweezers

To be used for removing and installing parts and wires.

4. Chip IC replacement jig

To be used for replacement of part.

5. Slit washer installation jig

To be used to install slit washers.

6. Cleaning cloth

Recommended cleaning cloth to wipe down the video heads, mechanism (tape transport system), optical lens surface.

SECTION 2

SPECIFIC SERVICE INSTRUCTIONS

2.1 DVC MECHANISM

2.1.1 Precautions

- (1) When fastening parts, pay careful attention to the tightening torque of each screw. Unless otherwise specified, tighten a screw with the torque of 0.055 N•m (0.56 kgf•cm).
- (2) Be sure to disconnect the set from the power supply before fastening and soldering parts.
- (3) When disconnecting/connecting wires, be careful not to get them and their connectors damaged.
- (4) When replacing parts, be very careful neither to damage other parts nor to fit wrong parts by mistake.

2.1.2 Notes on procedure for disassembly/assembly

The disassembling procedure table (Fig. 2-1-10 on page 2-4, a part of the table is shown below for reference) shows the procedure to disassemble/reassemble mechanism parts.

Carefully read the following explanation before starting actual disassembling/reassembling work. The item numbers (circled numbers) in the following explanation correspond to those appearing under respective columns of the table.

Example

NO.	PART NAME	FIG.	POINT	NOTE	REMARKS
[1]	CASSETTE HOUSING ASSY	T	Fig.2-4-3	3(S1),(L1a)-(L1e)	NOTE 1 a,b,c,d
[2]	UPPER BASE ASSY	T	Fig.2-4-4	(S2),(L2a),(L2b)	NOTE 2
[3]	DRUM ASSY	T		(S3a),2(S3b)	NOTE 3 a,b
[4]	REEL DISK ASSY(SUP)	T	Fig.2-4-5	(W4)	NOTE 4 a
[5]	REEL DISK ASSY(TU)	T		(W5a),(W5b),(W5c)	NOTE 5 a,b
[6]	REEL COVER ASSY	T		(W6),(S6a),2(S6b)	NOTE 6

*1

*2

*3

*4

*5

*6

*7

*1 Numbers appearing in this column indicate the order to remove parts. When reassembling, follow these numbers in the reverse order. Circled numbers in this column correspond to those appearing in drawings of this section.

*2 This column shows part names corresponding to numbers in the left column.

*3 The symbol (T or B) appearing in this column shows the side which the objective part is mounted on.

T =the upper side, B =the lower side

*4 Symbols appearing in this column indicate drawing numbers.

*5 This column indicates parts and points such as screws, washers, springs, and others to be removed/fitted for disassembling/reassembling the mechanism. Besides such the parts, this column occasionally indicates working points.

P = Spring

W = Washer

S = Screw

* = Lock (L), soldering (SD), shield, connector (CN), etc.

*6 Numbers in this column represent the numbers of notes in the text.

(For parts that need phase adjustment after reassembling, refer to "MECHANISM ADJUSTMENTS".)

*7 This column indicates required after-disassembling/-reassembling work such as phase adjustment or mechanism adjustment.

Example

- Remove (W1)=Washer W1.
- Remove the solder at (SD1)=Point SD1.
- Disconnect A = Connector A.

2.1.3 DISASSEMBLY AND ASSEMBLY OF MECHANISM ASSEMBLY

2.1.3.1 General statement

The mechanism should generally be disassembled/assembled in the C.IN mode (ASSEMBLY mode). (Refer to Fig. 2-1-1,2-1-2.) However, when the mechanism is removed from the main body, it is set in the STOP mode. Therefore, after the mechanism is removed from the main body, supply 3 V DC to the electrode on the top of the loading motor to enter the mechanism mode into the C IN mode compulsory.

<Mechanism assembly/Cassette housing assembly>




Fig.2-1-1

<Back side of the mechanism assembly>




Fig.2-1-2

2.1.3.2 Explanation of mechanism mode

The mechanism mode of this model is classified into five modes as shown in Fig. 2-1-9. Each mechanism mode can be distinguished from others by the relative position of "△", "○", "○", "□" marks on the sub cam gear to the inner or outer protrusion on the main deck.

Refer to Fig. 2-1-3 to 2-1-8 below.




Fig.2-1-3




Fig.2-1-4




Fig.2-1-5




Fig.2-1-6




Fig.2-1-7




Fig.2-1-8

2.1.3.3 Mechanism timing chart




Fig.2-1-9

2.1.4 DISASSEMBLY PROCEDURE TABLE

MARK: # After assembly, perform adjustments.

NO.	PART NAME		FIG.	POINT	NOTE	REMARKS
[1]	CASSETTE HOUSING ASSY	T	Fig.2-1-14	3(S1),(L1a)-(L1e)	NOTE 1 a,b,c,d	ADJUSTMENT
[2]	UPPER BASE ASSY	T	Fig.2-1-15	(S2),(L2a),(L2b)	NOTE 2	
[3]	DRUM ASSY	T		(S3a),2(S3b)	NOTE 3 a,b	ADJUSTMENT
[4]	REEL DISK ASSY(SUP)	T	Fig.2-1-16	(W4)	NOTE 4	
[5]	REEL DISK ASSY(TU)	T		(W5a),(W5b)	NOTE 5 a,b	
[6]	REEL COVER ASSY	T		(W6),2(S6a),(S6b)	NOTE 6	
[7]	TENSION ARM ASSY	T	Fig.2-1-17	(L7)	NOTE 7	ADJUSTMENT / #
[8]	SLANT POLE ARM ASSY	T		(P8)	NOTE 8	ADJUSTMENT
[9]	TU ARM ASSY	T		(L9)	NOTE 9	ADJUSTMENT
[10]	SWING ARM ASSY	T		(S10)	NOTE 10	ADJUSTMENT
[11]	SLIDE DECK ASSY	T	Fig.2-1-18	2(S11a),(S11b),2(L11a), 2(L11b),(L11c)	NOTE 11a,b	ADJUSTMENT / #
[12]	PAD ARM ASSY	T	Fig.2-1-19	(P12),(L12),(W12)	NOTE 12	ADJUSTMENT / #
[13]	-	-		-	-	
[14]	TU BRAKE ASSY	T		(P14),(L14),(W14)	NOTE 14	ADJUSTMENT
[15]	TENSION CTL LEVER ASSY	T	Fig.2-1-20	(W15)	NOTE 15	ADJUSTMENT
[16]	CENTER GEAR	T		-	NOTE 16	
[17]	PINCH ROLLER ARM F. ASSY	T		(W17)	NOTE 17	ADJUSTMENT
[18]	TENSION CTL PLATE ASSY	T		-	NOTE 18	ADJUSTMENT
[19]	BRAKE CTL LEVER ASSY	T		-	NOTE 19	ADJUSTMENT
[20]	MOTOR BRACKET ASSY	T	Fig.2-1-21	3(S20),(L20a),2(L20b)	NOTE 20	ADJUSTMENT
[21]	GUIDE RAIL ASSY	T		2(W21),(S21),2(L21a),(L21b)	NOTE 21	ADJUSTMENT
[22]	SLIDE LEVER 2 ASSY	T		-	NOTE 22	ADJUSTMENT / #
[23]	LOADING PLATE ASSY	T		(W23)	NOTE 23	ADJUSTMENT
[24]	MODE GEAR	T		-	NOTE 24	
[25]	EJECT LEVER	T		(W25)	NOTE 25	ADJUSTMENT
[26]	BASE R ASSY	T	Fig.2-1-22	(S26a),(S26b),2(L26)	NOTE 26	ADJUSTMENT
[27]	ROTARY ENCODER	T		2(S27)	NOTE 27	PHASE ADJUSTMENT
[28]	GEAR COVER ASSY	T		(S28a),2(S28b)	-	
[29]	MAIN CAM ASSY	T		-	NOTE 29	PHASE ADJUSTMENT
[30]	SLIDE ARM ASSY	T	Fig.2-1-23	-	NOTE 30	ADJUSTMENT
[31]	CONNECT GEAR 2	T		-	NOTE 31	
[32]	SUB CAM ASSY	T		(S32)	NOTE 32	PHASE ADJUSTMENT
[33]	CONTROL ARM ASSY	T		-	NOTE 33	ADJUSTMENT
[34]	REEL GEAR 1	T		-	NOTE 34	
[35] / [36]	DRUM BASE ASSY/ CAPSTAN MOTOR	T	Fig.2-1-24	3(S35)	NOTE 35a,b	ADJUSTMENT
[36]	CAPSTAN MOTOR	T		(S36)	NOTE 36	ADJUSTMENT
[37]	MAIN DECK ASSY	T		-	-	

Fig.2-1-10




Fig.2-1-11

< TOP VIEW >




Fig.2-1-12

< BOTTOM VIEW >




Fig.2-1-13

2.1.5 DISASSEMBLY/ASSEMBLY

2.1.5.1 [1] CASSETTE HOUSING ASSY

NOTE 1a:

Be careful not to damage any of the parts during work.

NOTE 1b:

Special care is required in mounting.

NOTE 1c:

When mounting, the CASSETTE HOUSING ASSY should be attached in the Eject status. Pay heed to the positions of the LOCK LEVER and EJECT LEVER during mounting.

NOTE 1d:

When mounting, be sure to locate the FPC in the gap.





Fig.2-1-14

2.1.5.2 [2] UPPER BASE ASSY

[3] DRUM ASSY

NOTE 2:

When mounting, be sure to insert the FPC reinforcing sheet.

NOTE 3a:

Be mindful of scratches or damage during work.

NOTE 3b:

Be careful not to attach screws incorrectly.





Fig.2-1-15

2.1.5.3 [4] REEL DISK ASSY(SUP)
[5] REEL DISK ASSY(TU)
[6] REEL COVER ASSY

NOTE 4:

Be careful not to attach the REEL DISK wrongly. The Supply side can be identified by the white color at the center.

NOTE 5a:

Be careful not to attach the REEL DISK wrongly. The Take-up side can be identified by the black color at the center.

NOTE 5b

The washer is inserted under the REEL DISK.

Be careful not to lose the washer.

Two washers are inserted under the REEL DISK in some products manufactured earlier, but one washer is inserted in the products manufactured recently and in the future.

See the parts list, and use the parts written in the parts list.


NOTE 6:

Perform the following steps for mounting.

- (1) Align the hole with the pin.
- (2) Attach the [17] PINCH ROLLER ARM FINAL ASSY by aligning the positions.
- (3) Attach the SLIDE DECK ASSY (POINT[A]) by aligning the positions.
- (4) Check that the parts below them are located in the correct positions.
- (5) Tighten the 2 screws.
- (6) Tighten the screw.
- (7) Attach the 1 SLIT WASHER parts.

NOTE 4, 5

REEL DISK ASSY



NOTE 6





Fig.2-1-16

2.1.5.4 [7] TENSION ARM ASSY
 [8] SLANT POLE ARM ASSY
 [9] TU ARM ASSY
 [10] SWING ARM ASSY

NOTE 7:

When detaching, remove the spring of the [12] PAD ARM ASSY in advance.

Pay attention to the attachment position.

NOTE 8:

When mounting the SLANT POLE ARM ASSY, hook the spring onto the lug as in diagram A, and fit the combination onto the SLIDE DECK ASSY. After fitting, hook the spring onto the lug of the SLIDE DECK ASSY as in diagram B.

Be careful not to lose the spring.

NOTE 9:

Pay attention to the attachment position.

NOTE 10:

When detaching, remove the screw then remove the SWING ARM ASSY by pulling it up and turning it.





Fig.2-1-17

2.1.5.5 [11] SLIDE DECK ASSY

NOTE 11a:

Each of the parts on the SLIDE DECK ASSY can be replaced separately.

When detaching the assembly, if there is no need to replace any of its parts, remove the SLIDE DECK ASSY as it is.

NOTE 11b:

When mounting, pay attention to the positions of the [22] SLIDE LEVER 2 ASSY studs and the [19] BRAKE CTL LEVER ASSY.

When mounting, position the CONTROL PLATE on the left side.

Pay attention to the position of the SLIDE GUIDE PLATE during mounting.

NOTE 11b





Fig.2-1-18

2.1.5.6 [12] PAD ARM ASSY

[13] -

[14] TU BRAKE ASSY

NOTE 12:

The spring may have already been disengaged when the [8] SLANT POLE ARM ASSY was removed.

NOTES 14:

When mounting, pay attention to the correct positioning. Mount the CONTROL PLATE by moving it fully toward the left side.

NOTE 12,14





Fig.2-1-19

- 2.1.5.7 [15] TENSION CTL LEVER ASSY
 [16] CENTER GEAR
 [17] PINCH ROLLER ARM FINAL ASSY
 [18] TENSION CTL PLATE ASSY
 [19] BRAKE CTL LEVER ASSY

NOTES 15/16:

When mounting, pay attention to the correct positioning.

NOTE 17:

Take care against grease attachment during work.

NOTES 18/19:

When mounting, pay attention to the correct positioning.





Fig.2-1-20

- 2.1.5.8 [20] MOTOR BRACKET ASSY
 [21] GUIDE RAIL ASSY
 [22] SLIDE LEVER 2 ASSY
 [23] LOADING PLATE ASSY
 [24] MODE GEAR
 [25] EJECT LEVER

NOTE 20:

When mounting, pay attention to the positioning of the sliding parts.

NOTE 21:

When mounting, take care that no part is allowed to float or rattle.

NOTES 22/23/24/25:

When mounting, pay attention to the correct positioning.





Fig.2-1-21

2.1.5.9 [26] BASE R ASSY
[27] ROTARY ENCODER
[28] GEAR COVER ASSY
[29] MAIN CAM ASSY

NOTE 26:

When mounting, fold the sliding part to the inner side.

NOTE 27:

When mounting, pay attention to the correct positioning and the FPC layout.

NOTE 29:

When mounting, pay attention to the correct positioning.





Fig.2-1-22

2.1.5.10 [30] SLIDE ARM ASSY
[31] CONNECT GEAR 2
[32] SUB CAM ASSY
[33] CONTROL ARM ASSY
[34] REEL GEAR 1

NOTE 30:

When mounting, pay attention to the correct positioning.

NOTE 31:

When mounting, pay attention to the position of the front and back.

NOTES 32/33/34:

When mounting, pay attention to the correct positioning.





Fig.2-1-23

**2.1.5.11 [35] DRUM BASE ASSY
[36] CAPSTAN MOTOR
[37] MAIN DECK ASSY**

NOTES 35a/36:

Since [36]CAPSTAN MOTOR is attached to [35]DRUM BASE ASSY, remove [36]CAPSTAN MOTOR together with [35]DRUM BASE ASSY when removing [36]CAPSTAN MOTOR.

[36]CAPSTAN MOTOR should not be separated from [35]DRUM BASE ASSY except when replacing them.


NOTE 35b:

It is very important to attach [35]DRUM BASE ASSY to the proper position.

Especially, improper engagement of [36]CAPSTAN MOTOR with [34]REEL GEAR 1 causes operational deflection or abnormal sound. Therefore, confirm the attachment position before disassembly procedure.


See the following figure as for the proper attachment position.

NOTE 35b



When [35]DRUM BASE ASSY is properly attached, the screw hole tends to be located at the center of the oval.

When the screw hole is located far from the center of the oval, operational deflection or abnormal sound may occur.



Before removing [35]DRUM BASE ASSY, confirm the position of [35]DRUM BASE ASSY by seeing the length (A), as shown in the left figure.

When reattaching [35]DRUM BASE ASSY, confirm the position to reattach [35]DRUM BASE ASSY by seeing the length (A). Be sure to reattach [35]DRUM BASE ASSY to the same position as it has been before the removing procedure.




Fig.2-1-24

2.1.6 CHECKUP AND ADJUSTMENT OF MECHANISM PHASE

[24]MODE GEAR

Align the MODE GEAR with the Main Deck Assembly hole.

Note:

The MODE GEAR may be displaced during the mechanism operation, however it can be checked from the rear and realigned during manual assembly.

[27]ROTARY ENCODER

Mount the ROTARY ENCODER by aligning its mark (Δ) and the mark (∇) of the Main Deck Assembly.

Note:

Be careful when handling the FPC during mounting.

[34]REEL GEAR 1

Align the REEL GEAR 1 with the Main Deck Assembly hole.

Note:

The REEL GEAR 1 may be displaced during mechanism operation, however this can be checked from the rear and realigned during manual assembly.

[29]MAIN CAM ASSY/[30]SLIDE ARM ASSY

When mounting the SLIDE ARM ASSY align it with the Main Deck Assembly and MAIN CAM ASSY holes.

Note:

During the mounting procedure, make sure that the [32] SUB CAM ASSY is in the correct mounting position.

[32]SUB CAM ASSY/[33] CONTROL ARM ASSY

Mount the SUB CAM ASSY hole to align with the CONTROL ARM ASSY and Main Deck Assembly holes and then tighten them all together with a screw.

Note:

When mounting it, make sure that the [29]MAIN CAM ASSY is in the correct mounting position.




Fig.2-1-25

2.1.7 MECHANISM ADJUSTMENTS

2.1.7.1 Adjustment of the slide guide plate

Use Fig. 2-1-26 as the reference unless otherwise specified.

- (1) Set the PLAY mode. See Fig. 2-1-8.
- (2) Loosen the screws (A, B).
- (3) With the Main Deck and Slide Deck Assemblies pushed into the unit, tighten the screws (A, B) while applying pressure to the stud (shaft) on the Slide Guide plate.
The pressure applied should be enough to enable utilization of the rebounding force of the springs.
The tightening torque should be 0.069 N•m (0.7 kgf•cm).
- (4) Check the operation.
Repeat unloading and loading several times and make sure that these operations can be performed smoothly without producing rattles.




Fig.2-1-26

2.1.7.2 Adjustment of the Tension Arm and Pad Arm Assemblies

Use Fig. 2-1-27 as the reference unless otherwise specified.

- (1) Set the PLAY mode.
See Fig. 2-1-8.
- (2) Loosen the screw **A**.
- (3) With the take-up side at the bottom, align the extreme end of the Tension Arm Assembly with the crossed grooves on the screw **B** that retains the Loading Motor Assembly and then tighten the screw **A**.
The tightening torque should be 0.069 N•m (0.7 kgf•cm).
- (4) Check the operation.
Repeat unloading and loading several times and make sure that the Tension Arm Assembly is located within the normal range.




Fig.2-1-27




Fig.2-1-28

2.1.7.3 Adjustment of the Slide Lever 2

Use Fig. 2-1-28 as the reference unless otherwise specified.

- (1) Set the C IN mode.
See Fig. 2-1-4.
- (2) Loosen the screw **A**.
- (3) Set the Main Deck and Slide Deck Assemblies apart so that they do not rattle, then tighten the screw **A** by screwing it fully toward the Drum Assembly.
The tightening torque should be 0.069 N•m (0.7 kgf•cm).
- (4) Check the operation.
Repeat unloading and loading several times and make sure that these operations can be performed smoothly without producing rattles.

2.1.8 SERVICE NOTE

Use the following chart to manage mechanism parts that are removed for disassembling the mechanism.









Fig.2-1-14	[1] CASSETTE HOUSING ASSY			Fig.2-1-15			[2] UPPER BASE ASSY			
										
Fig.2-1-15	[3] DRUM ASSY		Fig.2-1-16	[4] REEL DISK ASSY(SUP)		[6] REEL COVER ASSY				
				[5] REEL DISK ASSY(TU)						
Fig.2-1-17	[7] TENSION ARM ASSY		[8] SLANT POLE ARM ASSY		[9] TU ARM ASSY		[10] SWING ARM ASSY			
										
Fig.2-1-18	[11] SLIDE DECK ASSY			Fig.2-1-19	[12] PAD ARM ASSY		[13]		[14] TU BRAKE ASSY	
							—			

Fig.2-1-29












Fig.2-1-20	[15] TENSION CTL LEVER ASSY	[16] CENTER GEAR	[17] PINCH ROLLER ARM F ASSY	[18] TENSION CTL PLATE ASSY	[19] BRAKE CTL LEVER ASSY	
						
Fig.2-1-21	[20] MOTOR BRACKET ASSY		[21] GUIDE RAIL ASSY		[22] SLIDE LEVER 2 ASSY	[23] LOADING PLATE ASSY
						
Fig.2-1-22	[26] BASE R ASSY		[27] ROTARY ENCODER		[24] MODE GEAR	[25] EJECT LEVER
						
Fig.2-1-23	[28] GEAR COVER ASSY		[29] MAIN CAM ASSY		[30] SLIDE ARM ASSY	
Fig.2-1-24	[35] DRUM BASE ASSY		[36] CAPSTAN MOTOR		[37] MAIN DECK ASSY	

Fig.2-1-30

2.1.9 SERVICE NOTE
 Use the following chart to manage screws.

Symbol No.	[1]	[2]	[3]	[6]	[10]	[11]	[20]	[21]	[22]
Removing order of screw	1 2 3	4	5 6 7	8 9 10	11	12 13 14	15 16 17	18	19 20
Place to stick screw									
Reference drawing (Fig. No.2-1-**)	14		15	16	17	18	21		22
Screw tightening torque	I	II							
									III

Symbol No.	[27]	[28]	[32]	[35]	[36]
Removing order of screw	21 22 23 24 25	26	27 28 29	30	
Place to stick screw					
Reference drawing (Fig. No.2-1-**)	22	23	24		
Screw tightening torque	II		IV		V

<NOTE>

•Pay careful attention to tightening torque for each screw.

I : 0.069N・m(0.7kgf・cm)

II : 0.055N・m(0.56kgf・cm)

III : 0.0198N・m(0.2kgf・cm)

IV : 0.078N・m(0.8kgf・cm)

V : 0.039N・m(0.4kgf・cm)

Fig.2-1-31

2.1.10 REMARKS

2.1.10.1 Cleaning

- (1) For cleaning of the upper drum (particularly video heads), use fine-woven cotton cloth with alcohol soaks through. Do not move the cloth but turn the upper drum counterclockwise.

NOTE:

Make sure not to move the cloth in the vertical direction to the video head, since it may cause damage of the video heads.

- (2) For cleaning of parts of the tape transport system except the upper drum, use fine-woven cotton cloth or cotton swab soaked alcohol.
- (3) After cleaning, confirm that the cleaned parts are completely dry before loading the deck with cassette tape.

2.1.10.2 Applying oil and grease

- (1) Periodical oiling and greasing are not required but should be done to new parts when replacing. If oil and grease on the other parts of the other party are old and dirty, wipe them clean and apply new oil or grease.
- (2) For parts and points to apply oil and grease, refer to the exploded view of the 3.1 DVC MECHANISM ASSEMBLY. Fig.2-1-32 specifies oil and grease to be used.
- (3) When oiling, clean the objective parts with alcohol first and apply one or two drop(s) of oil. Too much oiling causes rotary parts to slip because of oil leakage.

Classification	Part No.	Symbol in drawing
Grease	KYODO-SH-JB	AA
Oil	YTU94027	BB
Grease (HANARL)	RX-410R	CC

specifies oil and grease to be used

Fig.2-1-32

2.2 VHS-C MECHANISM

2.2.1 Precautions

- (1) When fastening parts, pay careful attention to the tightening torque of each screw. Unless otherwise specified, tighten a screw with the torque of 0.216 N•m (2.2 kgf•cm). Torque setting value of torque driver is limited. At the values over the maximum torque setting value, fasten a screw manually not to damage the screw thread.
- (2) Be sure to disconnect the set from the power supply before fastening and soldering parts.
- (3) When disconnecting/connecting wires, be careful not to get them and their connectors damaged.
- (4) When replacing parts, be very careful neither to damage other parts nor to fit wrong parts by mistake.

Example

STEP/LOC. No.	PART NAME		FIG.	REMOVAL	INSTALLATION
				POINT	ADJUSTMENT CONDITION NOTE
[1]	ROLLER BASE ASSEMBLY	T	M1	(S1)	—
[2]	TENSION ARM ASSEMBLY	T	M1	(P1), (W1a)	—
[3]	REEL DISC (SUP)	T	M1	(W1a), (W1b)	—

↑
*1

↑
*2

↑
*3

↑
*4

↑
*5

↑
*6

2.2.2 How to read the disassembly and assembly

*1 Order of steps in Procedure

When reassembling, perform the step(s) in the reverse order. These numbers are also used as the identification (location) No. of parts Figures.

*2 Part to Name be removed or installed.

*3 Location of part.

T = The Upper side
B = The Lower side

*4 Fig. No. showing Procedure or Part Location.

M = Mechanism

*5 Identification of part to be removed, unhooked, unlocked, released, unplugged, unclamped or unsoldered.

P = Spring

W = Washer

S = Screw

* = Unhook, unlock, release, unplug or unsolder.

Example

- Remove (W1)=Washer W1.
- Remove the solder at (SD1)=Point SD1.
- Disconnect A = Connector A.

*6 Adjustment information for installation.

(+) = Refer to Exploded Views for Lubrication information.

2.2.3 DISASSEMBLY/ASSEMBLY PROCEDURE TABLE

This procedure starts with the condition that the cabinet parts and deck parts. Also, all the following procedures for adjustment and parts replacement should be performed in STOP mode. When reassembling, perform the step(s) in the reverse order.

STEP/LOC. No.	PART NAME		FIG.	REMOVAL	INSTALLATION
				POINT	ADJUSTMENT CONDITION NOTE
[1]	ROLLER BASE ASSY	T	M1	(1)	—
[2]	TENSION ARM ASSY	T	M1	(P1), (W1a)	—
[3]	REEL DISC	T	M1	(W1a), (W1b)	—
[4]	SLANT ARM ASSY	T	M1	(W1a)	—
[5]	CANCEL LEVER ASSY	T	M2	(W2)	—
[6]	EJECT LEVER ASSY	T	M2	(W2)	—
[7]	CASSETTE GUIDE (LEFT)	T	M2	(2)	—
[8]	SUPPLY CLUTCH ASSY	T	M2	(W2)	—
[9]	WHEEL GEAR	T	M2	(W2)	See, Adjustment procedure for Section 2.2.5
[10]	ROTARY ENCODER	B	M3	4(S3a)	The function of this part varies according to the ASSY (VHS/SVHS) which this part is incorporated in. (Refer to fig. 2-2-6)
[11]	TIMING BELT	B	M3	—	—
[12]	CENTER PULLEY UNIT	T/B	M3	2(S3a)	—
[13]	CASSETTE GUIDE (R) ASSY	T	M3	(S3b), (P3)	(Only use SVHS model)
[14]	TAKE UP GEAR	T	M3	(W3a)	—
[15]	BRAKE SUB GEAR	T	M3	(W3a)	—
[16]	PINCH ROLLER ARM ASSY	T	M3	(W3b)	—
[17]	TAKE UP GUIDE ARM ASSY	T	M3	(W3a)	—
[18]	LINK ARM ASSY	T	M4	(W4)	—
[19]	LED GUIDE	T	M4	(S4a)	—
[20]	A/C HEAD UNIT	T	M4	2(S4b)	—
[21]	SLANT POLE BASE ASSY	T	M5	(S5a)	—
[22]	CAPSTAN MOTOR	T	M5	3(S5a)	—
[23]	MOTOR BASE	T	M5	2(S5b), (S5c)	—
[24]	BRUSH	B	M6	(S6a)	—
[25]	DRUM FINAL ASSY	T/B	M6	2(S6b), 2(S6c) *CATCHER	—
[26]	GUIDE RAIL	T	M6	7(S6d), 8(S6d)	(Refer to part list.)
[27]	POLE BASE (S)ASSY	T	M6	—	—
[28]	POLE BASE (T)ASSY	T	M6	—	—
[29]	COVER PLATE	T	M7	—	—
[30]	DRIVE LEVER ASSY	T	M7	—	—
[31]	MOTOR BRACKET ASSY	T	M7	3(S7)	—
[32]	CONTROL CAM	T	M8	(W8a)	See, Adjustment procedure for Section 2.2.5
[33]	LINK LEVER	T	M8	—	See, Adjustment procedure for Section 2.2.5
[34]	MIDDLE GEAR	T	M8	—	—
[35]	LOADING GEAR(T) ASSY	T	M8	(W8b)	See, Adjustment procedure for Section 2.2.5
[36]	LOADING GEAR(S) ASSY	T	M8	(W8b)	—
[37]	LOADING RING ASSY	T	M8	4(S8)	See, Adjustment procedure for Section 2.2.5

Fig.2-2-1




Fig.2-2-2

<TOP VIEW>




Fig.2-2-3

<BOTTOM VIEW>




Fig.2-2-4




Fig.M1




Fig.M3





Fig.M2



* 0.118 N·m (1.2 kgf·cm)

Fig.M4




Fig.M5




Fig.M7




Fig.M6




Fig.M8

2.2.4 CHECKUP AND ADJUSTMENT OF MECHANISM PHASE

NOTE:

Pay careful attention to the installing order and phase of mechanism parts of the loading system.




Fig.2-2-5 Top of main deck




Fig.2-2-6 Rotary encoder

2.2.5 SERVICE NOTE

Use the following chart to manage screws.

Symbol No.	[1]	[7]	[10]				[12]	[13]	[19]	[20]	[21]	[22]	[23]										
Removing order of screw	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19				
Place to stick screw																							
Reference drawing (Fig. No.)	M1	M2	M3								M4				M5								
Screw tightening torque	I										II										I		

Symbol No.	[24]	[25]				[26]				[31]				[37]						
Removing order of screw	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39
Place to stick screw																				
Reference drawing (Fig. No.)						M6				M7				M8						
Screw tightening torque	III	I																		

Fig.2-2-7

<NOTE>

・Pay careful attention to tightening torque for each screw.
 Torque setting value of torque driver is limited. At the values over the maximum torque setting value, fasten a screw manually not to damage the screw thread.

I : 0.216N・m(2.2kgf・cm) II : 0.118N・m(1.2kgf・cm) III : 0.112N・m(1.1kgf・cm)

2.2.6 REMARKS

2.2.6.1 Cleaning

- (1) For cleaning of the upper drum (particularly video heads), use fine-woven cotton cloth with alcohol soaks through. Do not move the cloth but turn the upper drum counterclockwise.

NOTE:

Make sure not to move the cloth in the vertical direction to the video head, since it may cause damage of the video heads.

- (2) For cleaning of parts of the tape transport system except the upper drum, use fine-woven cotton cloth or cotton swab soaked alcohol.
- (3) After cleaning, confirm that the cleaned parts are completely dry before loading the deck with cassette tape.

2.2.6.2 Applying oil and grease

- (1) Periodical oiling and greasing are not required but should be done to new parts when replacing. If oil and grease on the other parts of the other party are old and dirty, wipe them clean and apply new oil or grease.
- (2) For parts and points to apply oil and grease, refer to the exploded view of the 3.2 VHS-C MECHANISM ASSEMBLY. Fig.2-2-8 specifies oil and grease to be used.
- (3) When oiling, clean the objective parts with alcohol first and apply one or two drop(s) of oil. Too much oiling causes rotary parts to slip because of oil leakage.

Classification	Part No.	Symbol in drawing
Grease	KYODO-SH-JB	AA
Oil	YTU94027	BB

specifies oil and grease to be used

Fig.2-2-8

2.3 VHS MECHANISM

2.3.1 Notes

This model's mechanism relates closely to the rotary encoder and system control circuit (the rotary encoder is meshed with the control cam).

The system control circuit detects the mechanism condition using the rotary encoder's phase (internal switch phase). Therefore, the parts such as the rotary encoder, control plate, loading gear and control cam need to be installed correctly in order for the mechanism to operate properly. (For the mechanism phase adjustment, refer to the installation of each part.)

- Before using a soldering iron, be sure to disconnect the power plug from the AC outlet.
- Do not touch any of the adjustment points until a defect position is specified.
- When plugging or unplugging the connector, be sure not to damage the wire.
- Be sure the springs are hooked all the way around and in the correct direction.
- When performing repairs, take care not to damage a catch, etc.




Fig.2-3-1

2.3.2 Mechanism operation check

When the mechanism is operated without a cassette loaded, operate the mechanism in the mechanism service mode.

2.3.3 Setting the mechanism assembling mode

The mechanism-assembling mode is provided with this mechanism. When disassembling and assembling, it is required to engage this mode.

Set the mode by adopting the following procedures.

- (1) Remove the mechanism assembly using the disassembling procedure.
- (2) Turn gear (a) of the loading motor manually to set the mechanism assembly to the eject end mode. Make sure that the main deck is connected to the guide hole (a) of the drive lever and the seal (a) of the main deck is connected to the mark "E" of the control plate. This condition is called the mechanism-assembling mode.




Fig.2-3-2

2.3.4 Layout of the main mechanism parts




Fig.2-3-3




Fig.2-3-4




Fig.2-3-5




Fig.2-3-6

2.3.5 Disassembling procedure table

This table shows the order of parts removal when replacing each part. For replacement, remove the parts in the order of 1 to 13 shown in the table and install the parts in the reverse order.

The symbol number before each part name shows the number in the figure "Layout of the main mechanism parts". T and B on the right of each part name show the side from which the part should be removed (T: From the front of the mechanism, B: From the rear of the mechanism, T/B: From both sides).

Symbols and numbers				L1	-	-	L2	-	R1	T6	T12	T11	T4	T10	T16	T15	B12	B11	B13	B9	B10	B2	B4	B3	B1	B5	B8	B15
Symbols and numbers	Removal parts	Front(T)/Back(B) of mechanism	Number of removal steps	Earth spring (1)	Top frame	Cassette holder	Side frame (L)	Drive arm	Side frame (R)	Lid guide	Idler arm	Idler gear 1/2	Main brake (T)	Reel disk (T)	Tension arm	Tension arm base	Press lever	Control cam	Capstan brake assy	Loading motor assy	Belt	Fixing plate	Load gear	Loading gear assy (S)	Loading gear assy (T)	Control plate	Clutch unit	Direct gear
	(Reference items) Replacement parts																											
L1	2.1 Earth spring (1)	T	1																									
-	2.1 Top frame	T	2	1																								
-	2.1 Cassette holder	T	3	1	2																							
L2	2.1 Side frame (L)	T	3	1	2																							
-	2.1 Drive arm	T	5	1	2	3	4																					
R1	2.1 Side frame (R)	T	3	1	2																							
T3	2.2 A/C head	T	1																									
T17	- FE head	T/B	1																									
T7	2.3 Guide arm assy	T	1																									
T6	2.3 Lid guide	T	1																									
T5	2.3 Pinch roller arm assy	T	2							1																		
T12	2.4 Idler arm	T	4	1	2	3																						
T11	2.4 Idler gear 1/2	T	5	1	2	3					4																	
T4	2.5 Main brake assy (T)	T	6	1	2	3					4	5																
T10	2.5 Reel disk (T)	T	7	1	2	3					4	5	6															
T16	2.5 Tension arm	T	6	1	2	3					4	5																
T13	2.5 Reel disk (S)	T	7	1	2	3					4	5			6													
T15	2.5 Tension arm base	T	7	1	2	3					4	5			6													
-	- T-up head	T	8	1	2	3					4	5			6	7												
-	- T-up lever	T	8	1	2	3					4	5			6	7												
T8	2.5 Brake lever	T	8	1	2	3					4	5	6	7														
T14	2.5 Rec safety lever	T	7	1	2	3	4	5	6																			
B12	2.6 Press lever	B	1																									
B11	2.6 Control cam	B	2														1											
B13	2.6 Capstan brake assy	B	3														1	2										
B9	2.6 Loading motor assy	B	4														1	2	3									
B10	2.7 Belt	B	1																									
B14	2.7 Capstan motor	T/B	2																		1							
-	- Wire holder	T/B	1																									
B2	2.7 Fixing plate	B	1																									
B4	2.7 Load gear	B	2																			1						
B3	2.7 Loading gear assy(S)	B	3																			1	2					
B1	2.7 Loading gear assy(T)	B	4																			1	2	3				
T1	- Pole base assy(S)	T/B	4																			1	2	3				
T2	- Pole base assy(T)	T/B	5																			1	2	3	4			
-	- Load gear base	B	5																			1	2	3	4			
B5	2.7 Control plate	B	6														1	2			3	4	5					
T9	- Drive lever	T/B	10	1	2	3	4	5	6								7	8		9								
B8	2.8 Clutch unit	B	2																		1							
B15	2.8 Direct gear	B	3																		1							2
B7	- Change lever	T/B	6								1	2									3						4	5
B6	- Tension arm lever	T/B	14	1	2	3					4	5			6	7	8	9			10	11	12			13		

2.3.6 REPLACEMENT OF THE MAIN MECHANISM PARTS

2.3.6.1 Cassette holder

2.3.6.1.1 Removal

- (1) Remove the screws (a) and (b).
- (2) Hold up the top frame, cassette holder assembly, drive arm assembly and side frames (L/R) all together and remove them by releasing the hooks (a) and (b).




Fig.2-3-7

2.3.6.1.2 Installation (phase adjustment)

- (1) Turn gear (a) of the loading motor assembly so that the main deck connects to the guide hole (a) of the drive lever.
- (2) Hook the main deck to hooks (a) and (b).
- (3) Place the projection of the drive lever to section (a) of the side frame (R) and install the cassette holder to the main deck. Make sure that the bosses of the side frame (L/R) connect with the holes (a) and (b) of the main deck.
- (4) Secure screws (a) and (b).




Fig.2-3-8

2.3.6.1.3 Disassembling

- (1) Release hook (a) to remove the earth spring (1) from the top frame.
- (2) Release the catches (a) and (b) and pull the top frame in the direction shown by the arrow (a) to remove it.
- (3) Pull out the side frame (R).
- (4) Pull out the cassette holder assembly and drive arm assembly from the side frame (L).




Fig.2-3-9

2.3.6.1.4 Assembling (installation and phase adjustment)

- (1) Turn gear (a) of the loading motor assembly so that the main deck connects to the guide hole (a) of the drive lever.
- (2) Place the projection of the drive lever on section (a) of the side frame (R) and install the side frame (R) to the main deck.
- (3) Secure screw (b).
- (4) Place section (b) of the drive arm on the gear of the side frame (R). Make sure that the pin of the door opener connects with section (c) of the drive arm.
- (5) Place the drive arm on section (d) of the side frame (L) and install the side frame (L) on the main deck. Be sure to connect the earth spring (1) to the side frame (L).
- (6) Secure screw (a).
- (7) Turn gear (a) of the loading motor assembly until the drive arm is vertical.
- (8) Place the slit of the side frame (L/R) at the foot of the cassette holder assembly and install the cassette holder.
- (9) Place the top frame on the position guide (a) of the side frame (L/R) and push it in the direction shown by the arrow (a) for installation.
- (10) Hook the earth spring (1) to the hook (a) of the top frame.




Fig.2-3-10

2.3.6.2 A/C head

2.3.6.2.1 Removal

- (1) Remove screws (a) and (b).
- (2) Remove the A/C head together with the head base.
- (3) Remove the screws (c), (d) and (e) to remove the spring (a) and the A/C head from the Head base.




Fig.2-3-11

2.3.6.2.2 Installation (initial setting)

To install the A/C head to the head base, secure the screws in the order of (c), (d) and (e). To make the adjustment easy, temporarily elevate the A/C head.




Fig.2-3-12

2.3.6.3 Guide arm, pinch roller arm

2.3.6.3.1 Removal

- (1) Remove the spring (a) from the hook (a) and detach the guide arm assembly.
- (2) Release the catch (a) to remove the lid guide.
- (3) Remove the spring (b) from the hook (b) and detach the pinch roller arm assembly.




Fig.2-3-13

2.3.6.4 Idler arm, idler gear 1/2

2.3.6.4.1 Removal

- (1) Release the catches (a) and (b) to detach the idler arm.
- (2) Detach the idler gear 1/2.




Fig.2-3-14

2.3.6.5 Main brake (T), brake lever, tension arm, reel disk (S/T), Rec safety lever

2.3.6.5.1 Removal

- (1) Remove the spring (a). (Detach section (b) of the spring (a).)
- (2) Release the catch (a) to detach the main brake (T).
- (3) Release the catch (b) to detach the reel disk (T) and the spacer.
- (4) Lift up and turn section (b) of the brake lever counterclockwise to remove the brake lever.
- (5) Remove the spring (b) from the hook (a).
- (6) Release the catch (c) to detach the tension arm.
- (7) Release the catch (d) to detach the reel disk (S) and the spacer.
- (8) Remove the spring (c) from the hook (b).
- (9) Turn the tension arm base in the direction shown by arrow (a) to release catch (e). Place the projections of the tension arm base to the holes (a) to detach the tension arm base.
- (10) While releasing the catch (f), turn the Rec safety lever counterclockwise to remove it.




Fig.2-3-15

2.3.6.6 Press lever, control cam, capstan brake assembly, loading motor assembly

2.3.6.6.1 Removal

- (1) Remove the slit washer (a) to detach the press lever.
- (2) Release the slit washer (b) to detach the control cam.
- (3) Release the catch (b) to detach the capstan brake assembly.
- (4) Remove the solder (a).
- (5) Remove the screw (a).
- (6) Release the catches (c) and (d) to detach the loading motor assembly.




Fig.2-3-16

2.3.6.6.2 Installation (phase adjustment)

- (1) Attach the loading motor assembly to the main deck.
- (2) Secure the screw (a).
- (3) Solder the wire to section (a).
- (4) Arrange the wire along with the position guide (b).
- (5) Attach the capstan brake assembly to the main deck.
- (6) Place the main deck on the guide hole (a) of the control plate.
- (7) Place the main deck on the guide hole (b) of the drive lever.
- (8) Place the main deck on guide hole (c) of the control cam to install the control cam.
- (9) Move the capstan brake in the direction shown by the arrow (a) to attach the press lever to the shaft (a). Make sure that the boss of the press lever fits in the control cam, and that the shaft (b) of the pinch roller arm assembly connects with the hole of the press lever.
- (10) Attach slit washer (a) to shaft (a).




Fig.2-3-17

Note:

- When replacing the worm bearing of the loading motor assembly, attach it according to the following specification.

If worm bearing is not attached correctly, a mechanism noise may occur. (See Fig. 2-3-18)




Fig.2-3-18

2.3.6.7 Capstan motor, load gear, control plate

2.3.6.7.1 Removal

- (1) Detach the belt.
- (2) Check that the FFC connector on the drum is disconnected.
- (3) Release the catch (a) to remove the FFC wire.
- (4) Remove the screws (a) to detach the capstan motor.
- (5) Remove the screws (b) to detach the fixing plate.
- (6) Release the catch (b) to detach the load gear.
- (7) Turn the load gear (S/T) in the loading direction to detach it.
- (8) Remove the control plate.




Fig.2-3-19

2.3.6.7.2 Installation (phase adjustment)

- (1) Place the main deck on the guide hole (a) of the tension arm lever.
- (2) Place the main deck on the guide hole (b) of the brake lever.
- (3) Attach the control plate to align with the position guide (a).
- (4) Place the hole (c) of the load arm (T) on the pole base (T) and the load gear (T) on the load gear base.
- (5) Place the hole (d) of the load arm (S) on the pole base (S) and the load gear (S) on the load gear base. Be sure to align the guide mark (e) of the load gear (T) to that of the load gear (S).
- (6) Turn the load gear (S/T) in the unloading direction to place the main deck on the guide hole (f) of the load gear (T).
- (7) Place the main deck on the guide hole (g) of the control plate.
- (8) Attach the load gear on the load gear base so that the control plate is placed on the edge (h) of the load gear.
- (9) Place the fixing plate on the shaft of the load gear base and secure the screws (b).




Fig.2-3-20

2.3.6.8 Clutch unit assembly, direct gear

2.3.6.8.1 Removal

- (1) Remove the slit washer (a) to detach the clutch unit assembly.
- (2) Remove the spring (a) and the direct gear.





Fig.2-3-21

2-40 (No.86700)



2.3.8 REMARKS

2.3.8.1 Cleaning

- (1) For cleaning of the upper drum (particularly video heads), use fine-woven cotton cloth with alcohol soaks through. Do not move the cloth but turn the upper drum counterclockwise.

NOTE:

Make sure not to move the cloth in the vertical direction to the video head, since it may cause damage of the video heads.

- (2) For cleaning of parts of the tape transport system except the upper drum, use fine-woven cotton cloth or cotton swab soaked alcohol.
- (3) After cleaning, confirm that the cleaned parts are completely dry before loading the deck with cassette tape.

2.3.8.2 Applying oil and grease

- (1) Periodical oiling and greasing are not required but should be done to new parts when replacing. If oil and grease on the other parts of the other party are old and dirty, wipe them clean and apply new oil or grease.
- (2) For parts and points to apply oil and grease, refer to the exploded view of the 3.3 VHS MECHANISM ASSEMBLY. Fig.2-3-22 specifies oil and grease to be used.
- (3) When oiling, clean the objective parts with alcohol first and apply one or two drop(s) of oil. Too much oiling causes rotary parts to slip because of oil leakage.

Classification	Part No.	Symbol in drawing
Grease	KYODO-SH-JB	AA
Oil	COSMO-HV56	BB

specifies oil and grease to be used

Fig.2-3-22



VICTOR COMPANY OF JAPAN, LIMITED

AV & MULTIMEDIA COMPANY CAMCORDER CATEGORY 12, 3-chome, Moriya-cho, kanagawa-ku, Yokohama, kanagawa-prefecture, 221-8528, Japan

(No.86700)



Printed in Japan
200304WPC